

ABB INDUSTRIAL DRIVES

ACS880-104LC inverter modules

Hardware manual



ACS880-104LC inverter modules

Hardware manual

Table of contents



5. Electrical installation



7. Start-up



Table of contents

1 Introduction to the manual

Contents of this chapter	13
Applicability	13
Safety instructions	13
Target audience	13
Categorization by frame size and option code	14
Use of component designations	15
Related documents	15
Terms and abbreviations	16

2 Operation principle and hardware description

Contents of this chapter	19
Overview diagram of the drive system	20
Cooling system	20
Inverter module hardware	21
General	21
Frame R8i and multiples	21
DC connection and capacitor charging	21
Frame R8i hardware	22
Overview circuit diagram of a frame R8i inverter unit	25
Overview circuit diagram of a frame 2×R8i inverter unit	26
Cabinet layout and cooling	26
Control interfaces	27
Overview of the control connections of the BCU control unit	27
The ACx-AP-x control panel	28
Control by PC tools	28
Type designation label	29

3 Moving and unpacking the module

Contents of this chapter	31
Moving and unpacking the module	31

4 Cabinet construction

Contents of this chapter	33
Limitation of liability	33
General	33
Installation examples	34
One R8i module in a 400 mm wide Rittal VX25 enclosure	35
Layout drawing	35
Pipe routing example	36
Installation stages	37
Overview of kits	38
Stage 1: Installation of common parts	39
Stage 2: Installation of side plates, module mounting mechanics and quick connector	40



Stage 3A: Installation of output terminals (for cabling) and cable entries	41
Stage 3B: Installation of AC busbars (for common AC bus)	42
Stage 4: Installation of cooling components and PE busbar	43
Stage 5A: Installation of DC busbars (units without DC switch)	44
Stage 5B: Installation of DC switch and busbars	45
Stage 6: Installation of module	46
Stage 7: Installation of swing-out frame and shrouding	47
Two R8i modules in a 600 mm wide Rittal VX25 enclosure	48
Layout drawing	48
Pipe routing example	49
Installation stages	50
Overview of kits	51
Stage 1: Installation of common parts	52
Stage 2: Installation of side plates, module mounting mechanics and quick connector	53
Stage 3A: Installation of output terminals (for cabling) and cable entry	54
Stage 3B: Installation of AC busbars (for common AC bus)	55
Stage 4: Installation of cooling components and PE busbar	56
Stage 5A: Installation of DC busbars (units without DC switch)	57
Stage 5B: Installation of DC switch and busbars	58
Stage 6: Installation of module	59
Stage 7: Installation of swing-out frame and shrouding	60
Three R8i modules in a 800 mm wide Rittal VX25 enclosure	61
Layout drawing	61
Pipe routing example	62
Installation stages	63
Overview of kits	64
Stage 1: Installation of common parts	65
Stage 2: Installation of side plates, module mounting mechanics and quick connector	66
Stage 3A: Installation of output terminals (for cabling) and cable entry	67
Stage 3B: Installation of AC busbars (for common AC bus)	68
Stage 4: Installation of cooling components	69
Stage 5A: Installation of DC busbars (units without DC switch)	70
Stage 5B: Installation of DC switch and busbars	71
Stage 6: Installation of module	72
Stage 7: Installation of swing-out frame and shrouding	73
One R8i module in a 400 mm wide generic enclosure	74
Two R8i modules in a 600 mm wide generic enclosure	76
Three R8i modules in a 800 mm wide generic enclosure	78

5 Electrical installation

Contents of this chapter	81
Safety and liability	81
Electrical safety precautions	82
General notes	83
Printed circuit boards	83
Optical components	83
Checking the insulation of the drive system	83
Checking the insulation of the motor and motor cable	83
Power connections - Frame R8i	84
R8i inverter module	84

2×R8i inverter unit	85
Connection procedure	86
Grounding the motor cable shield at the motor end	87
Connecting the control cables - All frame sizes	87
Installing optional modules	89
Installation of I/O extension and fieldbus adapter modules	89
Installation of an FSO-xx safety functions module	89
Installation of an FSO-xx safety functions module onto BCU	89
Installation of FSO-xx beside the control unit	91
Connecting a PC	92
Panel bus (Control of several inverter units from one control panel)	92
6 Installation checklist of the drive	
Contents of this chapter	95
Checklist	95
7 Start-up	
Contents of this chapter	97
Start-up procedure	98
8 Maintenance	
Contents of this chapter	103
Maintenance intervals	104
Maintenance timers and counters	105
Cooling system	105
Cabinet	105
Cleaning the interior of the cabinet	105
Power connections	105
Retightening the power connections	105
Cooling fans	106
Frame R8i fan replacement	106
Inverter module	107
Replacing an inverter module	107
Removing the module	107
Reinstalling the module	109
Control panel	111
Cleaning the control panel	111
Replacing the control panel battery	111
Control unit	112
Replacing the memory unit	112
Replacing the BCU control unit battery	112
Capacitors	113
Reforming the capacitors	113
LED indications	114
Control panel and panel platform/holder LEDs	114
R8i module LEDs	114
9 Ordering information	
Contents of this chapter	115
Kit code key	116



Frame R8i and multiples	117
Inverter modules	117
Control panel	119
Control electronics	120
Inverter control unit	120
Fiber optic cables	120
Mechanical installation accessories	121
Side plate kit	121
Module top/bottom guides	122
Swing-out frame	124
Shrouding	125
Lifting device	126
DC-side components	126
DC bus installation parts (for Rittal VX25 enclosures)	127
DC connection parts 1 of 2 (for Rittal VX25 enclosures)	128
DC connection parts 1 of 2 (for generic enclosures)	132
DC switch/disconnector kits (for Rittal VX25 enclosures)	133
DC charging kits (for units with DC switch/disconnector)	133
Charging resistors (for units with DC switch/disconnector)	134
DC fuses (IEC)	134
DC connection parts 2 of 2 (for Rittal VX25 or generic enclosures)	135
Common mode filters	136
AC-side components	137
Quick connector	137
Output busbars	137
Cable entry kit	139
Cooling system parts	139
Coolant distribution manifold kits	139
Piping	141
Heat exchanger	141
Cooling fan	142
Miscellaneous	142
CIO-01 I/O module	142

10 Internal cooling circuit

Contents of this chapter	143
Applicability	143
Internal cooling system	143
Connection to a cooling unit	145
Connection to an ACS880-1007LC cooling unit	145
Connection to a custom cooling unit	145
General requirements	145
Coolant temperature control	145
Filling up and bleeding the internal cooling circuit	146
Drive line-ups with an ACS880-1007LC cooling unit	146
Drive line-ups with a custom cooling unit	146
Draining the internal cooling circuit	148
Maintenance intervals	148
Technical data	148
Coolant specification	148
Coolant type	148
Temperature limits	148

Pressure limits	150
Coolant flow rate limits	150
Cooling circuit materials	150
11 Technical data	
Contents of this chapter	153
Ratings	154
Definitions	154
Derating	155
Supply voltage derating	155
Ambient temperature derating	155
Coolant temperature derating	155
Antifreeze content derating	156
Altitude derating	156
Switching frequency derating	156
Output frequency derating	156
Cooling characteristics	157
Modules used, noise, DC capacitance	158
Dimensions and weights	158
Free space requirements	159
Allowable mounting orientations	159
Typical power cable sizes	160
Input power (DC) connection	162
Motor (AC) connection	162
Control connections	162
Coolant connections	162
Efficiency	162
Degree of protection	163
Optical components	163
Ambient conditions	163
Materials	165
Standards	165
Markings	165
Auxiliary power consumption	166
Control equipment	166
Cooling fans	166
Definitions	166
Fuse data	167
Flush-end fuse blocks used with 690 V units	167
Tightening torques	168
Electrical connections	168
Mechanical connections	168
Insulation supports	168
Cable lugs	168
Disclaimers	169
Generic disclaimer	169
Cybersecurity disclaimer	169
12 Control units of the drive	
Contents of this chapter	171
General	171



BCU-x2 control unit layout and connections	172
Default I/O diagram of the inverter control unit (A41)	174
External power supply for the control unit (XPOW)	175
DI6 as a PTC sensor input	175
AI1 or AI2 as a Pt100, Pt1000, PTC or KTY84 sensor input	176
DIIL input	176
The XD2D connector	176
Safe torque off (XSTO, XSTO OUT)	177
FSO-xx safety functions module connection (X12)	177
SDHC memory card slot	177
Connector data	178
BCU-x2 ground isolation diagram	180

13 The Safe torque off function

Contents of this chapter	181
Description	181
Compliance with the European Machinery Directive	182
Wiring	183
Activation switch	183
Cable types and lengths	183
Grounding of protective shields	183
Dual-channel connection with internal power supply	184
Frame R8i and multiples	184
Single-channel connection of activation switch	185
Multiple drives	186
Internal power supply	186
External power supply	187
Operation principle	188
Start-up including acceptance test	189
Competence	189
Acceptance test reports	189
Acceptance test procedure	189
Use	191
Maintenance	192
Competence	192
Fault tracing	193
Safety data	194
Abbreviations	194
TÜV certificate	195

14 Dimension drawings

Contents of this chapter	197
Frame R8i inverter module	198
Quick connector	199
Control electronics	200
BCU control unit	200
DPMP-01 door mounting kit	201
DC fuse blocks (Bussmann)	202
Switchgear and charging components	203
OT_ DC switch/disconnectors	203
OT1600E11, OT1600E22	203

OT2500E22	204
OS_ charging switches	205
OS160GD04F	205
OS200DZ22F	206
OHB_ switch handles	207
OHB65J6	207
OHB150J12P	207
OHB274J12	208
Auxiliary contacts	208
OA1G10	208
OA3G01	208
ZRF 30/165 S charging resistor	209
BSFC-12C charging controller	210
CIO-01 I/O module	211

15 Example circuit diagrams

Contents of this chapter	213
Frame R8i without DC switch/disconnector	214
001a	214
005a	215
020a	216
022a	217
026a	218
040a	219
040b	220
040c	221
061a	222
Frame 2×R8i with DC switch/disconnector	223
001a	223
002a	224
005a	225
020a	226
022a	227
026a	228
040a	229
040b	230
040c	231
061a	232
Frame 4×R8i without DC switch/disconnector	233
001a	233
005a	234
005b	235
020a	236
022a	237
026a	238
040a	239
040b	240
040c	241
061a	242

Further information





1

Introduction to the manual

Contents of this chapter

This chapter gives basic information on the manual.

Applicability

This manual is applicable to ACS880-104LC inverter modules for user-defined cabinet installations.

Safety instructions

Follow all safety instructions delivered with the drive.

- Read the **complete safety instructions** before you install, commission, use or service the drive. The complete safety instructions are given in *ACS880 liquid-cooled multidrive cabinets and modules safety instructions (3AXD50000048633 [English])*.
- Read the **software-function-specific warnings and notes** before changing the default settings of a function. For each function, the warnings and notes are given in the section describing the related user-adjustable parameters.
- Read the **task-specific safety instructions** before starting the task. See the section describing the task.

Target audience

This manual is intended for people who plan the installation, install, start up and service the drive, or create instructions for the end user of the drive concerning the installation and maintenance of the drive.

Read the manual before working on the drive. You are expected to know the fundamentals of electricity, wiring, electrical components and electrical schematic symbols.

The manual is written for readers worldwide. Both SI and imperial units are shown.

Categorization by frame size and option code

The instructions and technical data which concern only certain module or frame sizes are marked with a size identifier.

The module size can be identified from the basic code visible on the type designation label, for example, "ACS880-104LC-0850A-7", where 0850A is the module size. The option codes of the module are listed after a plus sign. Chapter Ordering information, section Frame R8i and multiples explains the type designation code in detail.

The frame size of the module can be, for example, R8i or 2×R8i, the latter representing an inverter unit consisting of two parallel-connected R8i inverter modules. The table under section Ratings lists the units and frame sizes.

Use of component designations

Some device names in the manual include the item designation in brackets, for example [Q20], to make it possible to identify the components in the circuit diagrams of the drive.

Related documents

Manual	Code
General manuals	
<i>ACS880 liquid-cooled multidrive cabinets and modules safety instructions</i>	3AXD50000048633
<i>ACS880 liquid-cooled multidrive cabinets and modules electrical planning instructions</i>	3AXD50000048634
<i>Drive modules cabinet design and construction instructions</i>	3AUA0000107668
<i>BCU-02/12/22 control units hardware manual</i>	3AUA0000113605
<i>CIO-01 I/O module for distributed I/O bus control user's manual</i>	3AXD50000126880
Supply module manuals	
<i>ACS880-204LC IGBT supply modules hardware manual</i>	3AXD50000284436
<i>ACS880 IGBT supply control program firmware manual</i>	3AUA0000131562
<i>ACS880-304LC+A019 diode supply modules hardware manual</i>	3AXD50000045157
<i>ACS880 diode supply control program firmware manual</i>	3AUA0000103295
Inverter module manuals and guides	
<i>ACS880-104LC inverter modules hardware manual</i>	3AXD50000045610
<i>ACS880 primary control program firmware manual</i>	3AUA0000085967
<i>ACS880 primary control program quick start-up guide</i>	3AUA0000098062
Brake module and DC/DC converter module manuals	
<i>ACS880-604LC 1-phase brake chopper modules hardware manual</i>	3AXD50000184378
<i>ACS880-1604LC DC/DC converter modules hardware manual</i>	3AXD50000371631
<i>ACS880 DC/DC converter control program firmware manual</i>	3AXD50000024671
Option manuals	
<i>ACS880-1007LC liquid cooling unit user's manual</i>	3AXD50000129607
<i>ACX-AP-x assistant control panels user's manual</i>	3AUA0000085685
<i>BAMU-12C auxiliary measurement unit hardware manual</i>	3AXD50000117840
<i>Drive composer start-up and maintenance PC tool user's manual</i>	3AUA0000094606
<i>Drive application programming (IEC 61131-3) manual</i>	3AUA0000127808
Manuals and quick guides for I/O extension modules, fieldbus adapters, safety functions modules, etc.	


See www.abb.com/drives/documents for all manuals on the Internet.

You can find all documentation related to the multidrive modules on the Internet at <https://sites-apps.abb.com/sites/lvacdrivesengineering/support/content>.

Terms and abbreviations

Term	Description
BCON	Type of control board
BCU	Type of control unit
BDPS	Internal power supply board in frame R8i modules
Brake chopper	Conducts the surplus energy from the intermediate circuit of the drive to the brake resistor when necessary. The chopper operates when the DC link voltage exceeds a certain maximum limit. The voltage rise is typically caused by deceleration (braking) of a high inertia motor.
CIO	I/O module for controlling cabinet fans
CMF	Common mode filtering
Cubicle	One section of a cabinet-installed drive. A cubicle is typically behind a door of its own.
DC link	DC circuit between rectifier and inverter
DC link capacitors	Energy storage which stabilizes the intermediate circuit DC voltage
DDCS	Distributed drives communication system protocol
DPMP	Optional mounting platform for door mounting of control panel
Drive	Frequency converter for controlling AC motors
EFB	Embedded fieldbus
EMC	Electromagnetic compatibility
EMI	Electromagnetic interference
FAIO	Optional analog I/O extension module
FBA	Fieldbus adapter
FCAN	Optional CANopen® adapter module
FCNA	Optional ControlNet™ adapter module
FDCO	DDCS communication module
FDNA	Optional DeviceNet™ adapter module
FDPI	Diagnostics and panel interface board
FECA	Optional EtherCAT adapter module
FEN-01	Optional TTL incremental encoder interface module
FEN-11	Optional TTL absolute encoder interface module
FEN-21	Optional resolver interface module
FEN-31	Optional HTL incremental encoder interface module
FENA-11	Optional Ethernet adapter module for EtherNet/IP™, Modbus TCP® and PROFINET IO® protocols
FENA-21	Optional Ethernet adapter module for EtherNet/IP™, Modbus TCP® and PROFINET IO® protocols, 2-port
FEPL	Optional Ethernet POWERLINK adapter module
FIO-01	Optional digital I/O extension module
FIO-11	Optional analog I/O extension module
Four-quadrant operation	Operation of a machine in both the forward and reverse directions in both motoring and generating modes. Also used as an attribute of a drive; a regenerative drive can operate the electric machine in all four modes, while a non-regenerative drive can only operate the machine in motoring mode.
FPBA	Optional PROFIBUS DP adapter module
Frame, frame size	Physical size of the drive or power module
FSCA	Optional Modbus RTU adapter module
FSO-12, FSO-21	Optional functional safety modules
Generic enclosure	See chapter <i>Ordering information</i> .
HTL	High-threshold logic
IGBT	Insulated gate bipolar transistor
Intermediate circuit	DC circuit between rectifier and inverter
INU	Inverter unit
Inverter	Converts direct current and voltage to alternating current and voltage.

Term	Description
Inverter module	Inverter bridge, related components and drive DC link capacitors enclosed in a metal frame or enclosure. Intended for cabinet installation.
Inverter unit	Inverter module(s) under control of one control board, and related components. One inverter unit typically controls one motor.
Multidrive	Drive for controlling several motors which are typically coupled to the same machinery. Includes one supply unit, and one or several inverter units.
NBRA	Series of optional brake chopper modules
NBRW	Series of optional, liquid-cooled brake chopper modules
Parameter	In the drive control program, user-adjustable operation instruction to the drive, or signal measured or calculated by the drive. In some (for example fieldbus) contexts, a value that can be accessed as an object, eg, variable, constant, or signal.
PLC	Programmable logic controller
RFI	Radio-frequency interference
SIL	Safety integrity level (1...3) (IEC 61508)
STO	Safe torque off (IEC/EN 61800-5-2)
THD	Total harmonic distortion
TTL	Transistor-transistor logic
UPS	Uninterruptible power supply
VX25	Enclosure system by Rittal (www.rittal.com)
ZMU	Type of memory unit, attached to the control unit






Operation principle and hardware description

Contents of this chapter

This chapter describes a typical drive system and the hardware of ACS880-104LC inverter modules.

Overview diagram of the drive system

The diagram below depicts a common DC bus drive system.



The supply unit connects to the AC supply network and converts the AC voltage into DC. The DC voltage is distributed through the DC bus to all inverter units. The inverter unit, consisting of one or more inverter modules, converts the DC back to AC that rotates the motor.

The inverter units can be used for controlling asynchronous AC induction motors, permanent magnet synchronous motors, AC induction servomotors and ABB synchronous reluctance (SynRM) motors

Cooling system

See chapter [Internal cooling circuit \(page 143\)](#).

Inverter module hardware

■ General

An inverter unit contains the components required to control one motor. These include one or more inverter modules connected in parallel, together with the necessary auxiliary equipment such as control electronics, fusing, cabling and switchgear.

ACS880-104LC modules can be used to construct inverter units with a power rating of 350 kW up to several megawatts. Up to approximately 500...800 kW (depending on supply voltage), inverter units consist of one module only; higher power ratings are achieved by connecting multiple modules in parallel.

All inverter modules have coated circuit boards as standard.

The dimension drawings of the inverter modules are presented in a separate chapter.

■ Frame R8i and multiples

Frame R8i modules are used to achieve output powers from approximately 350 kW upwards in single or parallel configurations.

The DC connection of the module is by busbars and located at the top. The motor connection is via a quick connector at the back of the module that couples when the module is inserted into the cubicle. Each parallel-connected module is cabled separately to the motor, or connected by busbars to adjacent modules to reduce the number of cables. It is also possible to build an AC bus from each module to a separate output cubicle.

Internal du/dt filtering is mandatory with all 690 volt units and all parallel-connected modules. 690 volt modules have internal du/dt filtering as standard.

Frame R8i (and multiples, if any) modules are controlled by a single BCU control unit installed separately from the module(s). The control unit is connected to each module by a fiber optic link. The control unit can be powered from the module (terminal block X53), from an external 24 V DC supply, or both for redundancy. The control unit contains the basic I/Os and slots for optional I/O modules. Other equipment is primarily installed on separate mounting plates.

DC connection and capacitor charging

The module must be equipped with external DC fuses.

A DC switch/disconnector can be installed if quick isolation of the module from the DC bus is required.

A capacitor charging circuit must be fitted if:


- the module is connected to the DC bus through a DC switch/disconnector, or
- the module is directly connected to the DC bus and the supply unit of the system does not have a charging capability.

The charging circuit design presented in this manual consists of a charging switch, resistors and a charging controller. When the module is connected to an energized DC bus, the charging switch is closed first. When the charging is finished, the main DC switch/disconnector can be closed and the charging switch opened. The module will not start if the charging switch is closed.

Common mode filtering is implemented by running the DC bus through ferrite cores at the input of the module.

Frame R8i hardware

Module layout



1	DC connection busbars, + (a) and - (b)
2	Lifting eyes, front (a) and back (b)
3	Coolant in (a) and out (b) connectors
4	Handle
5	Fiber optic connectors
6	Quick connector (AC connection) (the counterpart fastened to the cabinet behind the module)
7	Terminal block X50 (auxiliary power input for internal boards)
8	Terminal block X51 and X52 (Safe torque off in inverter modules only)
9	Terminal block X53 (24 V DC power output)
10	Auxiliary voltage selector (115 or 230 V)
11	Unpainted fastening hole. The grounding point (PE) between module frame and cabinet frame.

Coolant connectors

The coolant pipe inlet and outlet connectors are located at the bottom front of the module. The connectors are for 16/13 millimeter PA (polyamide) pipe.

Connectors X50...X59

R8i modules contain a power supply (BDPS) that provides 24 V DC for the circuit boards of the module. The 24 V DC voltage provided by the BDPS is also available on X53, and can be used to power the BCU control unit of a single R8i module.

Note:

With parallel-connected R8i modules, it is strongly recommended to use an external 24 V DC supply to power the BCU control unit.


The BDPS is powered internally from the DC link. An auxiliary voltage of 230 V AC or 115 V AC (selectable) can optionally be fed to terminal block X50 to power the BDPS even when the DC link is not live. The selection between 115 V and 230 V is made with selector plug X59. The setting can be changed by removing the two screws, turning the plug 180 degrees, and reinstalling the screws.

If the Safe torque off (STO) function is not used, the “24V” inputs on X52 must be connected to +24 V (on connector X53, for example) on each inverter module. On a new module, a jumper wire set installed at the factory makes this connection.


If the STO function is to be implemented, the jumper wire set must be removed – a mechanical interlocking device is factory-installed on connectors X51 and X52 to this effect.

For STO, X52 (STO IN) is wired to the STO OUT connector on the BCU control unit. Connector X51 on the module is wired to connector X52 on the next module (if present). For details, see chapter The Safe torque off function.

24 Operation principle and hardware description




Fiber optic connectors



Name	Description
BSFC	Charging controller connection. Must be connected by the installer.
BCU	Control unit connection. Must be connected by the installer.

Overview circuit diagram of a frame R8i inverter unit


The following figure shows a simplified connection example of an inverter unit based on a frame R8i inverter module.



Item	Explanation	Available through
A	Inverter cubicle	-
1	DC supply	-
2	DC switch/disconnector (optional)	ABB or third party
3	Charging switch (optional)	ABB or third party
4	Charging resistor (optional)	ABB or third party
5	DC fuses	ABB or third party
6	Common mode filters	ABB
7	Inverter module	ABB
8	Motor	ABB (not part of ACS880-104LC product offering) or third party

Overview circuit diagram of a frame 2×R8i inverter unit

The following figure shows a simplified connection example of an inverter based on two parallel-connected frame R8i inverter modules.



Item	Explanation	Available through
A	Inverter cubicle	-
1	DC supply	-
2	DC switch/disconnector (optional)	ABB or third party
3	Charging switch (optional)	ABB or third party
4	Charging resistors (optional)	ABB or third party
5	DC fuses	ABB or third party
6	Common mode filters	ABB
7	Inverter modules	ABB
8	Motor	ABB (not part of ACS880-104LC product offering) or third party


Cabinet layout and cooling

See chapter [Cabinet construction \(page 33\)](#).

Control interfaces

■ Overview of the control connections of the BCU control unit

The diagram shows the control connections and interfaces of the BCU control unit.



■ The ACx-AP-x control panel

The ACx-AP-x control panel is the user interface of the inverter unit, providing the essential controls such as Start/Stop/Direction/Reset/Reference, and the parameter settings for the control program.

The control panel can be mounted on the cabinet door using a DPMP-01 mounting platform (available separately).

One control panel can be used to control several inverter units through a panel link provided that each unit is equipped with panel holder or an FDPI-02 module.

Note:

A control panel is required for the commissioning of an ACS880 drive system, even if the Drive composer PC tool is used.

For details on the control panel, see *ACX-AP-x Assistant control panels User's manual* (3AUA0000085685 [English]).

Control by PC tools


There is a USB connector on the front of the panel that can be used to connect a PC to the drive. When a PC is connected to the control panel, the control panel keypad is disabled.

For more information see section Connecting a PC.


Type designation label

Each inverter module has a type designation label attached to it. The type designation stated on the label contains information on the specifications and configuration of the unit. The first digits express the basic construction of the unit, for example “ACS880-104LC-0850A-7”. Any optional selections are given thereafter, separated by plus signs.

Quote the complete type designation and serial number when contacting technical support on the subject of individual inverter modules. An example of the label is shown below.



No.	Description
1	Type designation
2	Frame size
3	Cooling method
4	Degree of protection
5	UL/CSA data
6	Ratings
7	Valid markings. See <i>Electrical planning instructions for ACS880 liquid-cooled multidrive cabinets and modules</i> (3AXD50000048634 [English]).
8	Serial number. The first digit of the serial number refers to the manufacturing plant. The next four digits refer to the unit's manufacturing year and week, respectively. The remaining digits complete the serial number so that there are no two units with the same number.



3

Moving and unpacking the module

Contents of this chapter

This chapter gives basic information on unpacking and moving the module.



WARNING!

For the safety instructions, see *Safety instructions for ACS880 liquid-cooled multidrive cabinets and modules* (3AXD50000048633 [English]).


Moving and unpacking the module

The modules are delivered on a wooden base, boxed in corrugated cardboard. The cardboard box is tied to the base with PET bands.

1. Cut off the bands.
2. Lift off the cardboard box.
3. Remove any filling material.
4. Cut open the plastic wrapping of the module.
5. Lift off the module.
6. Check that there are no signs of damage.

Dispose of or recycle the packaging according to the local regulations.

If you need to pack the modules, see the package information in the technical data.





Cabinet construction

Contents of this chapter

This chapter instructs in placing the modules and additional equipment into a cabinet.

For general instructions, see *Cabinet design and construction instructions for drive modules* (3AUA0000107668 [English]).

Limitation of liability

The installation must always be designed and made according to applicable local laws and regulations. ABB does not assume any liability whatsoever for any installation which breaches the local laws and/or other regulations. Furthermore, if the recommendations given by ABB are not followed, the drive may experience problems that the warranty does not cover.

General

See the technical data for module-specific cooling requirements and allowable mounting orientations.

Installation examples



WARNING!

The code labels attached to mechanical parts such as busbars, shrouds and sheet metal parts must be removed before installation as they may cause bad electrical connections, or, after peeling off and collecting dust in time, cause arcing or block the cooling air flow.

This section includes installation examples of inverter modules in Rittal VX25 series as well as generic enclosures. Each example includes a table that lists:

- installation stages of different equipment in the order in which the installation into the cabinet should be performed
- code of the step-by-step instructions
- equipment kit code
- kit ordering code.


You can find kit-specific assembly drawings, step-by-step instructions and kit information on the Internet (<https://sites-apps.abb.com/sites/vacdrivesengineeringsupport/content>).

The example includes also cabinet assembly drawings that show each stage listed in the table. More detailed steps of each stage are described in the kit-specific assembly drawings.

For general instructions, refer to *Cabinet design and construction instructions for ACS880/ACS880LC multidrive modules* (3AUA0000107668 [English]).


■ One R8i module in a 400 mm wide Rittal VX25 enclosure

Layout drawing



No.	Description
1	DC fuses (DC switch can alternatively be installed)
2	Common mode filters
3	Inverter module
4	Output busbars
5	Heat exchanger (between module and cooling fan)
6	Cooling fan
7	Inlet manifold with stop and drain valves
8	Outlet manifold with stop and drain valves
9	Cable entries

Pipe routing example




No.	Description
1	Coolant in
2	Inlet manifold with stop and drain valves
3	Heat exchanger
4	Inverter
5	Outlet manifold with stop and drain valves
6	Coolant out

Installation stages

No.	Installation stage	Instruction code	Kit code	Kit ordering code
1	Baying parts	3AXD50000336340	-	-
	DC bus support kit	3AXD50000333639	A-468-X-001-VX	3AXD50000333387
2	Side plates	3AXD50000327591	L-468-8-020-VX	3AXD50000360543
	Module mounting mechanics	3AXD50000330461	L-4-8-301-VX	3AXD50000360598
	Quick connector	-	A-468-8-100	3AUA0000119227
3A	AC output terminals (for cabling)	3AXD50000330874	L-468-8-131-VX	3AXD50000360550
	Cable entry	3AXD50000004817	L-468-8-441	3AXD50000004385
3B	Common AC bus support kit	3AXD50000370870	L-468-X-012-VX	3AXD50000371013
	AC output busbars (for connection to common AC bus)	3AXD50000352791	L-468-8-121-VX	3AXD50000371037
4	Cooling fan	-	-	3AXD50000043886 / 3AXD50000045414
	Heat exchanger	-	L-468-8-440	3AXD50000041265
	Coolant distribution manifolds	3AXD50000048217	L-468-8-441	3AXD50000044084
	PE busbar	-	-	-
5A	DC busbars (for configuration without DC switch)	3AXD50000332861	L-4-8-201-VX	3AXD50000360604
		3AXD50000332885	L-4-8-251-VX	3AXD50000361021
		3AXD50000041311	L-468-8-230	3AXD50000041264
5B	DC switch and busbars	3AXD50000342600	L-4-8-254-VX	3AXD50000361038
		3AXD50000343614	L-46-8-207-VX	3AXD50000360567
		3AXD50000205042	L-46-8-233	3AXD50000200368
6	Module installation	-	-	-
7	Swing-out frame	3AXD50000345106	L-4-X-051-VX	3AXD50000361045
	Shrouding	3AXD50000353354	L-4-8-022-VX	3AXD50000361083

Stage 1: Installation of common parts



Stage 2: Installation of side plates, module mounting mechanics and quick connector

1	2	3	4	5	6	7	8
A	B	C	D	E	F	G	H

AC5880-104LC-VX25-W400 A.01
AC5880-104LC-VX25-W400 (ASSEMBLY) L-13

Initial Approval


We reserve all rights in this document and in the information contained therein, reproduction, distribution, or use of any part of this document is strictly prohibited.

© ABB. ALL RIGHTS RESERVED. INFORMATION CONFIDENTIAL.


20-Feb-19 L. Lehtisalo

STAGE2: SIDE PLATE KIT, MODULE MOUNTING MECHANICS KIT AND QUICK CONNECTOR KIT INSTALLATION


See assembly drawings for details and required additional Rittal and standard parts.




SIDE PLATE KIT
KIT L-468-8-020-VX
Ordering code: 3AXD50000360543
See drawing: 3AXD50000327591



MODULE MOUNTING MECH KIT W400
KIT L-468-8-020-VX
Ordering code: 3AXD50000360538
See drawing: 3AXD50000330461






X8Y QUICK CONNECTORS FOR MODULE
KIT A-468-8-100
Ordering code: 3AUA0000119227




Based on	L. Lehtisalo	20-Feb-19	Title	ASSEMBLY DRAWING	Scale	Form
Customer	M. Koskinen	20-Feb-19	IXR81 IN RITTAL VX25 W400	ASSEMBLY DRAWING	1:25	A3
Drawn	M. Asikainen	20-Feb-19	ACS880-104LC	Responsible	A. LAP	
Project name	3AXD10000888521		Weight	kg 338.02		
Doc. No.	3AXD50000327591		Doc. No.	3AXD50000434961		
Doc. Number	3AXD50000330461		Doc. No.	3AXD50000434961		
			ABB			
			Total 10			






Stage 3A: Installation of output terminals (for cabling) and cable entries

1	2	3	4	5	6	7	8																																																								
<p>AC3880-104LC-VX25-W400 AC3880-104LC-VX25-W400 ASSEMBLY KIT</p> <p>Initial Approval</p>																																																															
<p>20-Feb-19</p>																																																															
<p>Original drawing made with 3D CAD. Set the correct scale factor when adding dimensions after DWG/DXF conversion.</p>																																																															
A	B	C	D	E	F	G	H																																																								
																																																															
<p>STAGE3A: R81 AC OUTPUT BUSBARS KIT AND LEAD-THROUGH KIT FOR BOTTOM PLATE INSTALLATION</p> <p>See assembly drawings for details and required additional Rittal and standard parts.</p>																																																															
																																																															
<p>R81 AC OUTPUT BUSBARS KIT KIT L-468-13-1-VX Ordering code: 3AXD50000360550 See drawing: 3AXD50000330874</p>																																																															
																																																															
<p>LEAD-THROUGH KIT FOR BOTTOM PLATE KIT A-468-8-441 Ordering code: 3AXD5000004355 1 kit/module (default) See drawing: 3AXD5000004617</p> <p>Note: one kit includes 4x60mm diam. lead-throughs</p>																																																															
<p>In this example two lead-through kits are shown.</p>																																																															
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td>Based on</td> <td>L-Leh15al3b</td> <td>20-Feb-19</td> <td>Title</td> <td>ASSEMBLY DRAWING</td> <td>Scale</td> <td>Form</td> </tr> <tr> <td>Customer</td> <td>M-VOSHTIEN</td> <td>20-Feb-19</td> <td>Project</td> <td>AC3880-104LC</td> <td>1:1,5</td> <td>A3</td> </tr> <tr> <td>Cart. Desc. No.</td> <td>3AXD10000868527</td> <td>20-Feb-19</td> <td>Rev. desc.</td> <td>AC3880-104LC</td> <td>Rev. desc.</td> <td>A-LAP7</td> </tr> <tr> <td>DWG Number</td> <td>3AXD10000868527</td> <td>Weight kg</td> <td>338,02</td> <td></td> <td></td> <td></td> </tr> <tr> <td colspan="5"></td> <td>Dec. No.</td> <td>3AXD5000043496 I</td> </tr> <tr> <td colspan="5"></td> <td>Sheet</td> <td>4</td> </tr> <tr> <td colspan="5"></td> <td>Leads</td> <td>EN</td> </tr> <tr> <td colspan="5"></td> <td>Total</td> <td>10</td> </tr> </table>								Based on	L-Leh15al3b	20-Feb-19	Title	ASSEMBLY DRAWING	Scale	Form	Customer	M-VOSHTIEN	20-Feb-19	Project	AC3880-104LC	1:1,5	A3	Cart. Desc. No.	3AXD10000868527	20-Feb-19	Rev. desc.	AC3880-104LC	Rev. desc.	A-LAP7	DWG Number	3AXD10000868527	Weight kg	338,02									Dec. No.	3AXD5000043496 I						Sheet	4						Leads	EN						Total	10
Based on	L-Leh15al3b	20-Feb-19	Title	ASSEMBLY DRAWING	Scale	Form																																																									
Customer	M-VOSHTIEN	20-Feb-19	Project	AC3880-104LC	1:1,5	A3																																																									
Cart. Desc. No.	3AXD10000868527	20-Feb-19	Rev. desc.	AC3880-104LC	Rev. desc.	A-LAP7																																																									
DWG Number	3AXD10000868527	Weight kg	338,02																																																												
					Dec. No.	3AXD5000043496 I																																																									
					Sheet	4																																																									
					Leads	EN																																																									
					Total	10																																																									





Stage 3B: Installation of AC busbars (for common AC bus)



Stage 4: Installation of cooling components and PE busbar







1	2	3	4	5	6	7	8	
ACS880-104LC-VX25-W400 ACS880-104LC-VX25-W400 (ASSEMBLY) - 1:13 Original drawing made with 3D CAD. Set the correct scale factor when adding dimensions after DWG/DXF conversion.								
A. Initial Approval 20-Feb-19 L.Lehliisalo								
We reserve all rights in this document and in the information contained therein. Reproduction, use or disclosure to third parties without express authority is strictly forbidden.								
<h2>STAGE4: R81 LC FAN KIT, ACS880LC HEAT EXCHANGER KIT AND COOLING COMPONENTS KIT INSTALLATION</h2> <p>See assembly drawings for details and required additional Rittal and standard parts.</p>								
 <p>R81 FAN KIT Ordering codes: 3AXD50000043886 (230V) 3AXD50000045414 (115V)</p>	 <p>ACS880LC HEAT EXCHANGER KIT KIT L-468-8-440 Ordering code: 3AXD50000041265</p>	 <p>COOLING COMPONENTS KIT I KIT L-468-8-441 KIT L-468-8-441 Ordering code: 3AXD50000044084 See drawing: 3AXD50000048217</p>						 <p>Suggested placement for cabinet PE bus bar assembly PE Busbar not included in kits.</p>
Based on: L.Lehliisalo Customer: M.VOSHTIEN Date: 20-FEB-19 Project name: ACS880-104LC Weight: kg 338,02								
Title: ASSEMBLY DRAWING Part: ACS880-104LC Part No.: 3AXD50000043496 I Weight: kg 338,02								
Dec. No.: 3AXD50000043496 I Dec. No.: 3AXD50000043496 I Dec. No.: 3AXD50000043496 I Dec. No.: 3AXD50000043496 I								
Form: A3 Scale: 1:1,95 Sheet: 6 Total: 10								

Stage 5A: Installation of DC busbars (units without DC switch)


1	2	3	4	5	6	7	8
ACS880-104LC-VX25-W400 A.01 We reserve all rights in this document and in the information contained therein, reproduction, distribution, disclosure or use of any part of this document is strictly prohibited. © ABB Oy. PROPRIETÄRYRÄTT OCH SÄKERTETSGENOMSKYDD.							
ACS880-104LC-VX25-W400 (ASSEMBLY) - 1.13 20-Feb-19 L. Lehtisalo							
Initial Approval							
<p style="text-align: center;"> STAGE5A: R81 DC CONN BUSBAR KIT W400, DC FUSE BUSBAR KIT W400 AND R81 CMMF BUSBARS KIT INSTALLATION See assembly drawings for details and required additional Rittal and standard parts. </p>							
							
<p> R81 DC CONN BUSBAR KIT W400 KIT L-4-8-201-VX Ordering code: 3AXD5000360604 See drawing: 3AXD5000332861 </p>							
							
<p> DC FUSE BUSBAR KIT W400 KIT L-4-8-251-VX Ordering code: 3AXD5000361021 See drawing: 3AXD5000332885 </p>							
							
<p> R81 CMMF BUSBAR KIT KIT L-468-8-230 Ordering code: 3AXD5000041264 See instruction: 3AXD5000041311 </p>							
							
<p> First angle projection. Original drawing made with 3D CAD. Set the correct scale factor when adding dimensions after DWG/DXF conversion. </p>							

Based on:	L. Lehtisalo	20-Feb-19	Title	ASSEMBLY DRAWING	Scale	Form
Customer:	M. Koskinen	20-Feb-19	1XR81 IN RITTAL VX25 W400	ASSEMBLY DRAWING	1:25	A3
Appr.:	M. Asikainen	20-Feb-19	ACS880-104LC	Rev. ind.	A. LAP	
Project name:	3AXD10000888521		Weight: kg	338.02		
DWG Number:	ABB					
Doc. No.:	3AXD50000434961					
Sheet:	7					
Total:	10					


Stage 5B: Installation of DC switch and busbars

1	2	3	4	5	6	7	8
<p>AC3880-10ALC-VX25-W400 AC3880-10ALC-VX25-W400 ASSEMBLY KIT L-13</p> <p>WE EXCEPT ALL LIABILITY IN THIS DOCUMENT FOR THE INFORMATION CONTAINED HEREIN. REPRODUCTION, USE OR DISCLOSURE TO third parties without express authority is strictly forbidden. © ABB AB, MOHLECHEN AND SECTEL INFORMATION CONFIDENTIAL</p> <p>20-Feb-19 L.Lehlisalo</p> <p>A. Initial Approval</p>							
<p>First angle projection. Original drawing made with 3D CAD. Set the correct scale factor when adding dimensions after DWG/DXF conversion.</p>							
A	<p>STAGE5B: DC SWITCH KIT W400, DC CONNECTION KIT W400 AND R81 CMMF BUSBARS KIT INSTALLATION</p> <p>See assembly drawings for details and required additional Rittal and standard parts.</p>						F
B	 <p>DC SWITCH KIT W400 KIT L-4-8-254-VX Ordering code: 3AXD50000361038 See drawing: 3AXD50000342600</p>						E
C	 <p>DC CONNECTION W400/W600 KIT L-46-8-207-VX Ordering code: 3AXD50000360567 See drawing: 3AXD50000343614</p>						D
D	 <p>R81 CMMF BUSBAR KIT KIT L-46-8-233 Ordering code: 3AXD50000200368 See drawing: 3AXD50000205042</p>						C
E	 <p>DC SWITCH KIT W400 KIT L-4-8-254-VX Ordering code: 3AXD50000361038 See drawing: 3AXD50000342600</p>						B
F	 <p>DC CONNECTION W400/W600 KIT L-46-8-207-VX Ordering code: 3AXD50000360567 See drawing: 3AXD50000343614</p>						A
							
<p>Based on: L.Lehlisalo 20-Feb-19 Title: ASSEMBLY DRAWING Customer: M.VOSHTIEN 20-Feb-19 Project name: ACS880-10ALC Cart. Desc. No. 3AXD10000868527 Weight: kg 338.02 DMS Number: 3AXD10000868527</p> <p>Prepared: L.Lehlisalo 20-Feb-19 Title: ASSEMBLY DRAWING Checked: M.VOSHTIEN 20-Feb-19 Project name: ACS880-10ALC Project name: ACS880-10ALC Dec. No. 3AXD50000434961</p> <p>Scale: 1:1, 1:5, 1:10, 1:20, 1:50, 1:100, 1:200, 1:500, 1:1000 Form: A3, A4, A5, A6, A7, A8, A9, A10, A11, A12, A13, A14, A15, A16, A17, A18, A19, A20, A21, A22, A23, A24, A25, A26, A27, A28, A29, A30, A31, A32, A33, A34, A35, A36, A37, A38, A39, A40, A41, A42, A43, A44, A45, A46, A47, A48, A49, A50, A51, A52, A53, A54, A55, A56, A57, A58, A59, A60, A61, A62, A63, A64, A65, A66, A67, A68, A69, A70, A71, A72, A73, A74, A75, A76, A77, A78, A79, A80, A81, A82, A83, A84, A85, A86, A87, A88, A89, A90, A91, A92, A93, A94, A95, A96, A97, A98, A99, A100</p>							

Stage 6: Installation of module




Stage 7: Installation of swing-out frame and shrouding




■ Two R8i modules in a 600 mm wide Rittal VX25 enclosure

Layout drawing



No.	Description
1	DC fuses (DC switch can alternatively be installed)
2	Common mode filters
3	Inverter module
4	Output busbars (located behind module)
5	Heat exchanger (between module and cooling fan)
6	Cooling fan
7	Inlet manifold with stop and drain valves
8	Outlet manifold with stop and drain valves
9	Cable entries

Pipe routing example




No.	Description
1	Coolant in
2	Inlet manifold with stop and drain valves
3	Heat exchanger
4	Inverter module
5	Outlet manifold with stop and drain valves
6	Coolant out




Installation stages

No.	Installation stage	Instruction code	Kit code	Kit ordering code
1	Baying parts	3AXD50000336340	-	-
	DC bus support kit	3AXD50000333639	A-468-X-001-VX	3AXD50000333387
2	Side plates	3AXD50000327591	L-468-8-020-VX	3AXD50000360543
	Module mounting mechanics	3AXD50000330201	L-6-8-302-VX	3AXD50000361090
	Quick connector	-	A-468-8-100	3AUA0000119227
3A	AC output terminals (for cabling)	3AXD50000330874	L-468-8-131-VX	3AXD50000360550
	Cable entry	3AXD50000004817	L-468-8-441	3AXD50000004385
3B	Common AC bus support kit	3AXD50000370870	L-468-X-012-VX	3AXD50000371013
	AC output busbars (for connection to common AC bus)	3AXD50000352791	L-468-8-121-VX	3AXD50000371037
4	Cooling fans	-	-	3AXD50000043886 / 3AXD50000045414
	Heat exchangers	-	L-468-8-440	3AXD50000041265
	Coolant distribution manifolds	3AXD50000048258	L-468-8-442	3AXD50000044182
	PE busbar	-	-	-
5A	DC busbars (for configuration without DC switch)	3AXD50000332229	L-6-8-202-VX	3AXD50000361106
		3AXD50000332106	L-6-8-252-VX	3AXD50000361229
		3AXD50000041311	L-468-8-230	3AXD50000041264
5B	DC switch and busbars	3AXD50000338740	L-6-8-255-VX	3AXD50000361243
		3AXD50000343614	L-46-8-207-VX	3AXD50000360567
		3AXD50000205042	L-46-8-233	3AXD50000200368
6	Module installation	-	-	-
7	Swing-out frame	3AXD50000345069	L-6-X-052-VX	3AXD50000361250
	Shrouding	3AXD50000353521	L-6-8-023-VX	3AXD50000361267

Stage 1: Installation of common parts



Stage 3A: Installation of output terminals (for cabling) and cable entry

1	2	3	4	5	6	7	8
ACS880-104LC-VX25-W600 A.01 No copyright or rights in this document and in the information contained therein, representation, or other intellectual and scientific information, is hereby included. © ABB Oy, 2019. ALL RIGHTS RESERVED.							
ACS880-104LC-VX25-W600 (ASSEMBLY) - 1.0 Initial Approval 20-Feb-19 L.Lehilaisalo							
<p style="text-align: center;"> STAGE3A: R81 AC OUTPUT BUSBARS KIT AND LEAD-THROUGH KIT FOR BOTTOM PLATE INSTALLATION See assembly drawings for details and required additional Rittal and standard parts. </p> <div style="display: flex; justify-content: space-around;"> <div style="width: 45%;">  <p style="font-size: 8px;"> R81 AC OUTPUT BUSBARS KIT KIT L-468-8-131-VX Ordering code: 3AXD50000360550 Note: 1 kit/module See drawing: 3AXD50000330874 </p> </div> <div style="width: 45%;">  <p style="font-size: 8px;"> LEAD-THROUGH KIT FOR BOTTOM PLATE KIT A-468-8-441 Ordering code: 3AXD5000004385 1 kit/module (default) See drawing: 3AXD5000004817 Note: one kit includes 4x60mm diam. lead-throughs </p> </div> </div> <div style="text-align: center; margin-top: 20px;">  <p style="font-size: 8px; margin-top: 10px;"> In this example four lead-through kits are shown. </p> </div>							
First angle projection. Original drawing made with 3D CAD. Set the correct scale factor when adding dimensions after DWG/DXF conversion.							

Based on	L.Lehilaisalo	20-Feb-19	Title	ASSEMBLY DRAWING	Doc. des.	ASSEMBLY DRAWING	Scale	Form
Customer	M.Koskinen	20-Feb-19	ZXR81 IN RITTAL	VX25 W600	Resp.dpl.	A. LAP	1:25	A3
Appr.	M.Asiikainen	20-Feb-19	ACS880-104LC		Doc. No.	3AXD50000435630		
Proj. name	3AXD10000869117				Sheet	4		
DWG Number	3AXD10000869117	Weight kg	476.73		Total	10		



Stage 4: Installation of cooling components and PE busbar


1	2	3	4	5	6	7	8
A	B	C	D	E	F	G	H

ACS880-104LC-VX25-W600 A.01
 ACS880-104LC-VX25-W600 (ASSEM) 1-10
 We reserve all rights in this document and in the information contained therein, reproduction, distribution, or public or private use is strictly prohibited.
 © ABB Oy. PROHIELEÄÄN JA SIVELÄN TIEDONKÄSITTELY.


20-Feb-19 L. Lehtisalo

Initial Approval


STAGE4: R81 LC FAN KIT, ACS880LC HEAT EXCHANGER KIT AND COOLING COMPONENTS KIT INSTALLATION
 See assembly drawings for details and required additional Rittal and standard parts.




R81 FAN KIT
 Ordering codes:
 3AXD5000043886 (230V)
 3AXD5000045414 (115V)
 Note:
 1 kit/module



ACS880LC HEAT EXCHANGER KIT
 KIT L-468-8-440
 Ordering code: 3AXD50000041265
 Note:
 1 kit/module




COOLING COMPONENTS KIT 2
 KIT L-468-8-442
 Ordering code: 3AXD50000044162
 See drawing: 3AXD50000048256
 Note:
 1 kit/module



Suggested placement for cabinet PE bus bar assembly
 PE busbar not included in kits.

Based on:	L. Lehtisalo	20-Feb-19	Title	ASSEMBLY DRAWING	Scale	Form
Customer:	M. Koskinen	20-Feb-19	ZXR81 IN RITTAL VX25 W600	ASSEMBLY DRAWING	1:25	A3
Project name:	M. Asikainen	20-Feb-19	ACS880-104LC	Rev. ind.	A. LAP	
Doc. No.	3AXD50000089117	Weight kg	476.73	Doc. No.	3AXD50000435630	Sheet
Doc. Number				Doc. des.		Total
				Resp. dept.		6
				Doc. No.		10

Stage 5A: Installation of DC busbars (units without DC switch)



Stage 5B: Installation of DC switch and busbars

1	2	3	4	5	6	7	8
A	B	C	D	E	F	G	H


ACS880-104LC-VX25-W600 A.01
 ACS880-104LC-VX25-W600 ASSEMBLY 1-10
 © ABB. ALL RIGHTS RESERVED. ALL INFORMATION CONTAINED HEREIN IS STRICTLY CONFIDENTIAL.

Initial Approval 20-Feb-19 L. Lehtilaisalo


We reserve all rights in this document and the information contained therein. Reproduction, storage in retrieval systems, or disclosure of any information is strictly prohibited.

STAGE5B: DC SWITCH KIT W600, DC CONNECTION KIT W600 AND R81 CMMF BUSBARS KIT INSTALLATION


See assembly drawings for details and required additional Ritral and standard parts.




DC SWITCH KIT W600
 KIT L-6-235-VX
 Ordering code: 3AXD50000381243
 See drawing: 3AXD50000338740



DC CONNECTION W600/W600
 KIT L-46-8-207-VX
 Ordering code: 3AXD50000360567
 Note!
 1 kit/module
 See drawing: 3AXD50000343614




R81 CMMF BUSBAR KIT
 KIT L-46-8-233
 Ordering code: 3AXD50000200368
 Note!
 1 kit/module
 See drawing: 3AXD50000205042




First angle projection. Original drawing made with 3D CAD. Set the correct scale factor when adding dimensions after DWG/DXF conversion.




Based on	L. Lehtilaisalo	20-Feb-19	Title	ASSEMBLY DRAWING	Scale	Form
Customer	M. Koskinen	20-Feb-19	2XR81 IN RITRAL VX25 W600	ASSEMBLY DRAWING	1:25	A3
Cur. Doc. No.	M. Asikainen	20-Feb-19	ACS880-104LC	Rev. ind.	A. LAP	Lang. EN
DWG Number	3AXD5000089117			Doc. No.	3AXD50000435630	Sheet 8
	Weight kg	476.73				Total 10



Stage 6: Installation of module




Stage 7: Installation of swing-out frame and shrouding

1	2	3	4	5	6	7	8
ACS880-104LC-VX25-W600 A.01 No rights reserved in this document and the information contained therein, reproduction, distribution, or use of any part of this document is strictly prohibited. © ABB. ALL RIGHTS RESERVED.							
Initial Approval 20-Feb-19 L. Lehtisalo							
<p>STAGE7: SWING FRAME KIT W600 AND SHROUD KIT W600 INSTALLATION</p> <p>See assembly drawings for details and required additional Rittal and standard parts.</p>							
 <p style="font-size: 8px;"> SWING FRAME KIT W600 KIT L-6-X-052-VX Ordering code: 3AXD50000361250 Drawing code: 3AXD50000345069 </p>				 <p style="font-size: 8px;"> SHROUD KIT W600 KIT L-6-X-023-VX Ordering code: 3AXD50000361267 See drawing: 3AXD5000033521 </p>			
							
First angle projection. Original drawing made with 3D CAD. Set the correct scale factor when adding dimensions after DWG/DXF conversion.							

Based on	L. Lehtisalo	20-Feb-19	Title	ASSEMBLY DRAWING	Scale	Form
Customer	M. Koskinen	20-Feb-19	ZXR81 IN RITTAL VX25 W600	ASSEMBLY DRAWING	1:25	A3
Appr.	M. Asikainen	20-Feb-19	ACS880-104LC	Rev.ind.	A. LAP	
Project name	3AXD10000869117		Doc. No.		3AXD50000435630	
DWG Number	476-73		Doc. No.		3AXD50000435630	
			Total		10	


■ Three R8i modules in a 800 mm wide Rittal VX25 enclosure

Layout drawing



No.	Description
1	DC fuses (DC switch can alternatively be installed)
2	Common mode filters
3	Inverter module
4	Output busbars (located behind the module)
5	Heat exchanger (between module and cooling fan)
6	Cooling fan
7	Inlet manifold with stop and drain valves
8	Outlet manifold with stop and drain valves
9	Cable entries

Pipe routing example



No.	Description
1	Coolant in
2	Inlet manifold with stop and drain valves
3	Heat exchanger
4	Inverter module
5	Outlet manifold with stop and drain valves
6	Coolant out


Installation stages

No.	Installation stage	Instruction code	Kit code	Kit ordering code
1	Baying parts	3AXD50000336340	-	-
	DC bus support kit	3AXD50000333639	A-468-X-001-VX	3AXD50000333387
2	Side plates	3AXD50000327591	L-468-8-020-VX	3AXD50000360543
	Module mounting mechanics	3AXD50000329502	L-8-8-303-VX	3AXD50000361274
	Quick connector	-	A-468-8-100	3AUA0000119227
3A	AC output terminals (for cabling)	3AXD50000330874	L-468-8-131-VX	3AXD50000360550
	Cable entry	3AXD50000004817	L-468-8-441	3AXD50000004385
3B	Common AC bus support kit	3AXD50000370870	L-468-X-012-VX	3AXD50000371013
	AC output busbars (for connection to common AC bus)	3AXD50000352791	L-468-8-121-VX	3AXD50000371037
4	Cooling fan	-	-	3AXD50000043886 / 3AXD50000045414
	Heat exchanger	-	L-468-8-440	3AXD50000041265
	Coolant distribution manifolds	3AXD50000048283	L-468-8-443	3AXD50000048136
	PE busbar	-	-	-
5A	DC busbars (for configuration without DC switch)	3AXD50000331567	L-8-8-203-VX	3AXD50000361281
		3AXD50000331765	L-8-8-253-VX	3AXD50000361298
		3AXD50000041311	L-468-8-230	3AXD50000041264
5B	DC switch and busbars	3AXD50000336999	L-8-8-256-VX	3AXD50000361304
		3AXD50000344185	L-8-8-208-VX	3AXD50000360574
		3AXD50000205226	L-8-8-234	3AXD50000200337
6	Module installation	-	-	-
7	Swing-out frame	3AXD50000345106	L-4-X-051-VX	3AXD50000361045
	Shrouding	3AXD50000353354	L-4-8-022-VX	3AXD50000361083




Stage 1: Installation of common parts

1	2	3	4	5	6	7	8																												
<p>ACS880-104LC-VX25-W800 ACS880-104LC-VX25-W800 ASSEMBLY - 1:13</p> <p style="font-size: small;">We reserve all rights in this document and in the information contained therein. Reproduction, use or disclosure to third parties without express authority is strictly forbidden. ©ABB AB, ABP/LEH/AND/SECT/REGISTRATION/CONFIDENTIAL</p>																																			
A	Initial Approval						8	9																											
<p>21-Feb-19</p> <p style="text-align: right;">L. Lehtisalo 50000117845</p>																																			
<p>Note! See Cabinet design and construction instructions for ACS880 multidrive modules (3AUA0000107668 [English])</p> <p>STAGE 1: Common assembly installations (Buying parts, Common DC).</p> <p>See assembly drawings for details</p>																																			
<p style="font-size: small;">FLAT-PLUS SUPPORT KIT FOR DC KIT A-468-X-001-VX Ordering code: 3AXD50000333639 See drawing: 3AXD50000333639</p> <p style="font-size: small;">Buying parts assembly See drawing: 3AXD50000336340</p>																																			
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="font-size: x-small;">Based on</td> <td style="font-size: x-small;">L. Lehtisalo</td> <td style="font-size: x-small;">21-Feb-19</td> <td style="font-size: x-small;">Title</td> <td style="font-size: x-small;">ASSEMBLY DRAWING</td> <td style="font-size: x-small;">Scale</td> <td style="font-size: x-small;">Form</td> </tr> <tr> <td style="font-size: x-small;">Customer</td> <td style="font-size: x-small;">M. VOSHTEN</td> <td style="font-size: x-small;">21-Feb-19</td> <td style="font-size: x-small;">Project</td> <td style="font-size: x-small;">MULTIPLAT Vx25 W800</td> <td style="font-size: x-small;">1:1,5</td> <td style="font-size: x-small;">A3</td> </tr> <tr> <td style="font-size: x-small;">Cart. Desc. No.</td> <td style="font-size: x-small;">3AXD10000869301</td> <td style="font-size: x-small;">21-Feb-19</td> <td style="font-size: x-small;">Project name</td> <td style="font-size: x-small;">ACS880-104LC</td> <td style="font-size: x-small;">1:1,5 (A3)</td> <td style="font-size: x-small;">Sheet</td> </tr> <tr> <td style="font-size: x-small;">DMS Number</td> <td style="font-size: x-small;">3718648936-05</td> <td style="font-size: x-small;">21-Feb-19</td> <td style="font-size: x-small;">Weight</td> <td style="font-size: x-small;">3AXD50000436415</td> <td style="font-size: x-small;">10</td> <td style="font-size: x-small;">Total</td> </tr> </table>								Based on	L. Lehtisalo	21-Feb-19	Title	ASSEMBLY DRAWING	Scale	Form	Customer	M. VOSHTEN	21-Feb-19	Project	MULTIPLAT Vx25 W800	1:1,5	A3	Cart. Desc. No.	3AXD10000869301	21-Feb-19	Project name	ACS880-104LC	1:1,5 (A3)	Sheet	DMS Number	3718648936-05	21-Feb-19	Weight	3AXD50000436415	10	Total
Based on	L. Lehtisalo	21-Feb-19	Title	ASSEMBLY DRAWING	Scale	Form																													
Customer	M. VOSHTEN	21-Feb-19	Project	MULTIPLAT Vx25 W800	1:1,5	A3																													
Cart. Desc. No.	3AXD10000869301	21-Feb-19	Project name	ACS880-104LC	1:1,5 (A3)	Sheet																													
DMS Number	3718648936-05	21-Feb-19	Weight	3AXD50000436415	10	Total																													
A	B	C	D	E	F	G	H																												

Stage 2: Installation of side plates, module mounting mechanics and quick connector



Stage 3A: Installation of output terminals (for cabling) and cable entry

1	2	3	4	5	6	7	8																																										
ACS880-104LC-VX25-W800 / L-01 ACS880-104LC-VX25-W800 ASSEMBLY KIT Initial Approval 21-Feb-19 L-Lehtisaalo 50000117845																																																	
We refer to the information on this document only in the information contained therein. Any reproduction, use or disclosure of this document without express authority is strictly forbidden. KÄYTTÖOHJE, HUOLTO- JA KORJAUSOHJE, RAKENNUKSELÄIN, KÄYTTÖOHJE																																																	
<p>STAGE3A: R81 AC OUTPUT BUSBARS KIT AND LEAD-THROUGH KIT FOR BOTTOM PLATE INSTALLATION See assembly drawings for details and required additional Rittal and standard parts.</p>																																																	
																																																	
<p>R81 AC OUTPUT BUSBARS KIT KIT L-468-8-131-VX Ordering code: 3AXD50000360550 Note: 1 kit/module See drawing: 3AXD50000330874</p>				<p>LEAD-THROUGH KIT FOR BOTTOM PLATE KIT A-468-8-441 Ordering code: 3AXD5000004385 1 kit/module (default) See drawing: 3AXD5000004817 Note: one kit includes 4x60mm diam. lead-throughs</p>																																													
																																																	
In this example five lead-through kits are shown.																																																	
<table border="1" style="width: 100%; border-collapse: collapse; font-size: 8px;"> <tr> <td>Based on</td> <td>L-Lehtisaalo</td> <td>21-Feb-19</td> <td>Title</td> <td>ASSEMBLY DRAWING</td> <td>Scale</td> <td>Form</td> </tr> <tr> <td>Customer</td> <td>M. VOSHTIEN</td> <td>21-Feb-19</td> <td>Part</td> <td>PLATE Vx25 W800</td> <td>1:1, 1:5</td> <td>A3</td> </tr> <tr> <td>Cart. Desc. No.</td> <td>3AXD10000869301</td> <td>21-Feb-19</td> <td>Base part</td> <td>ACS880-104LC</td> <td>1:1, 1:5</td> <td>A3</td> </tr> <tr> <td>DWG Number</td> <td>3AXD10000869301</td> <td>21-Feb-19</td> <td>Project name</td> <td>ACS880-104LC</td> <td>1:1, 1:5</td> <td>Sheet 4</td> </tr> <tr> <td></td> <td></td> <td></td> <td>Weight kg</td> <td>3718648936.05</td> <td></td> <td>Sheet 10</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>Total 10</td> </tr> </table>								Based on	L-Lehtisaalo	21-Feb-19	Title	ASSEMBLY DRAWING	Scale	Form	Customer	M. VOSHTIEN	21-Feb-19	Part	PLATE Vx25 W800	1:1, 1:5	A3	Cart. Desc. No.	3AXD10000869301	21-Feb-19	Base part	ACS880-104LC	1:1, 1:5	A3	DWG Number	3AXD10000869301	21-Feb-19	Project name	ACS880-104LC	1:1, 1:5	Sheet 4				Weight kg	3718648936.05		Sheet 10							Total 10
Based on	L-Lehtisaalo	21-Feb-19	Title	ASSEMBLY DRAWING	Scale	Form																																											
Customer	M. VOSHTIEN	21-Feb-19	Part	PLATE Vx25 W800	1:1, 1:5	A3																																											
Cart. Desc. No.	3AXD10000869301	21-Feb-19	Base part	ACS880-104LC	1:1, 1:5	A3																																											
DWG Number	3AXD10000869301	21-Feb-19	Project name	ACS880-104LC	1:1, 1:5	Sheet 4																																											
			Weight kg	3718648936.05		Sheet 10																																											
						Total 10																																											

Stage 3B: Installation of AC busbars (for common AC bus)


12345678

ABCDEF


AC5880-104LC-VX25-W800 A.01
 AC5880-104LC-VX25-W800 ASSEM01-13
 Initial Approval

50000117824
 21-Feb-19 L.Lehiisalo


STAGE3B: FLAT-PLS SUPPORT KIT FOR AC AND COMMON AC CONNECTION BUSBARS INSTALLATION
 See assembly drawings for details and required additional Rittal and standard parts.



FLAT-PLS SUPPORT KIT FOR AC
 KIT L-468-X-012-VX
 Ordering code: 3AXD50000371013
 See drawing: 3AXD50000370870




COMMON AC CONNECTION BUSBARS
 KIT L-468-8-121-VX
 Ordering code: 3AXD50000371037
 Note:
 1 kit/module
 See drawing: 3AXD50000352191



First angle projection. Original drawing made with 3D CAD. Set the correct scale factor when adding dimensions after DWG/DXF conversion.

Based on	L.Lehiisalo	21-Feb-19	Title	ASSEMBLY DRAWING	Scale	Form
Customer	M.Koskinen	21-Feb-19	3XR81 IN RITTAL VX25 W800	ASSEMBLY DRAWING	1:25	A3
Check	M.Koskinen	21-Feb-19	ACS880-104LC	Resp.appl.	A (AP)	
Appr.	M.Asiikainen	21-Feb-19	ACS880-104LC	Doc. No.	3AXD50000436415	
Project name				Logg.	FN	5
DWG Number	3AXD100008693901			Sheet		
Weight kg	3718628936-05			Total	10	



Stage 4: Installation of cooling components

1	2	3	4	5	6	7	8
ACS880-104LC-VX25-W800 ACS880-104LC-VX25-W800 (ASSEMBLY) - 13 We refer to all rights in this document that in the original version are reserved. Reproduction, use or disclosure to third parties without express authority is strictly forbidden. © ABB AB, MOPTILKEN, SWEDEN. INFORMATION CONFIDENTIAL.							
A. Initial Approval		21-Feb-19		L. Lehtisalo		50000117844	

STAGE4: R8I LC FAN KIT, ACS880LC HEAT EXCHANGER KIT AND COOLING COMPONENTS KIT INSTALLATION

See assembly drawings for details and required additional Rittal and standard parts.

First angle projection. Original drawing made with 3D CAD. Set the correct scale factor when adding dimensions after DWG/DXF conversion.

R8I FAN KIT
 Order code: 3AXD5000043886 (230V)
 3AXD5000043886
 3AXD5000045414 (115V)
 Note:
 | kit/module

ACS880LC HEAT EXCHANGER KIT
 KIT L-468-8-440
 Ordering code: 3AXD50000041265
 Note:
 | kit/module

COOLING COMPONENTS KIT 3
 KIT L-468-8-443
 Ordering code: 3AXD50000048136
 See drawing: 3AXD50000048283

Suggested placement for cabinet PE bus bar assembly
 PE busbar not included in kits.


Based on	L. Lehtisalo	21-Feb-19	Title	ASSEMBLY DRAWING	Scale	Form
Customer	M. VOSHTIKEN	21-Feb-19	Project	INITIAL VX25 W800	1:1, 1:5, 1:10, 1:20, 1:40, 1:80	AS
Cart. Desc. No.	M. VOSHTIKEN	21-Feb-19	Project name	ACS880-104LC	Box title	R. (RPT)
DWG Number	3AXD100000869301	Weight kg			Dec. No.	3AXD500000436415
					Dec. No.	
					Sheet	6
					Sheet	10
					Total	10


Stage 5A: Installation of DC busbars (units without DC switch)

1	2	3	4	5	6	7	8
ACS880-104LC-VX25-W800 A.01 We reserve all rights in this document and in the information contained therein, reproduction, distribution, modification, copying, or any other use is strictly prohibited. © ABB Oy. PROPRIETÄRYRÄTT OCH ALLTID ÅRBEJDSRÄTT FÖRBEHÅLLNA.							
A Initial Approval		L. Lehtisalo 21-Feb-19		L. Lehtisalo 50000117824			


STAGE5A: R81 DC CONN BUSBAR KIT W800, DC FUSE BUSBAR KIT W800 AND R81 CMMF BUSBARS KIT INSTALLATION

See assembly drawings for details and required additional Rittal and standard parts.






R81 DC CONN BUSBAR KIT W800
KIT L-8-8-203-VX
Ordering code: 3AXD50000361281
See drawing: 3AXD50000331567



DC FUSE BUSBAR KIT W600
KIT L-8-8-253-VX
Ordering code: 3AXD50000361298
See drawing: 3AXD50000331765




R81 CMMF BUSBAR KIT
KIT L-468-8-230
Ordering code: 3AXD50000041264
Note:
- 1 kit/module
See instruction: 3AXD50000041311

Based on	L. Lehtisalo	21-Feb-19	Title	ASSEMBLY DRAWING	Scale	Form
Customer	M. Koskinen	21-Feb-19	3XR81 IN RITTAL VX25 W800	ASSEMBLY DRAWING	1:25	A3
Appr.	M. Asikainen	21-Feb-19	ACS880-104LC	Rev. ind.	A. (AP)	Lang. EN
Proj. name	3AXD50000041311		Doc. No.	3AXD50000436415		
DWG Number	3AXD50000041311		Weight kg	3718628935-45		
			ABB			
			Doc. des.	ASSEMBLY DRAWING		
			Resp. dpt.	A. (AP)		
			Doc. No.	3AXD50000436415		
			Form	A3		
			Scale	1:25		
			Rev. ind.	A. (AP)		
			Lang.	EN		
			Sheet	7		
			Total	10		

Stage 5B: Installation of DC switch and busbars

1	2	3	4	5	6	7	8
<p>AC3880-10ALC-VX25-W800 AC3880-10ALC-VX25-W800 ASSEMBLY KIT</p>							
<p>1. 01 L. Lehtisalo</p>							
<p>Initial Approval</p>							
<p>21-Feb-19 L. Lehtisalo 50000117844</p>							
<p>Original drawing made with 3D CAD. Set the correct scale factor when adding dimensions after DWG/DXF conversion.</p>							
<p>STAGE5B: DC SWITCH KIT W800, DC CONNECTION KIT W800 AND R81 CMMF BUSBARS KIT INSTALLATION See assembly drawings for details and required additional Rittal and standard parts.</p>							
<p>DC SWITCH KIT W800 KIT L-8-256-VX Ordering code: 3AXD50000361304 See drawing: 3AXD50000336999</p>							
<p>DC CONNECTION W800 KIT L-8-8-208-VX Ordering code: 3AXD50000360574 Note! 1 kit/module See drawing: 3AXD50000344185</p>							
<p>R81 CMMF BUSBAR KIT KIT L-8-8-234 Ordering code: 3AXD50000200337 Note! 1 kit/module See drawing: 3axd50000203226</p>							
<p>Based on: L. Lehtisalo 21-Feb-19 Title: ASSEMBLY DRAWING Customer: M. VOSHTIEN 21-Feb-19 Part: RITL Vx25 W800 Project Name: M. VOSHTIEN 21-Feb-19 ACS880-10ALC DMS Number: 3AXD10000869301 Weight: kg 3718648935.45</p>							
<p>Prepared: L. Lehtisalo 21-Feb-19 Checked: M. VOSHTIEN 21-Feb-19 Project Name: M. VOSHTIEN 21-Feb-19 DMS Number: 3AXD10000869301 Weight: kg 3718648935.45</p>							
<p>Dec. No. 3AXD50000436415 Dec. No. 3AXD50000436415</p>							
<p>Scale: 1:1, 95 Form: A3 Sheet: 8 Total: 10</p>							

Stage 6: Installation of module





Stage 7: Installation of swing-out frame and shrouding

1	2	3	4	5	6	7	8
ACS880-104LC-VX25-W800 ACS880-104LC-VX25-W800 ASSEMBLY KIT Initial Approval							
We refer to the drawing in this document only in the information contained therein. Responsibility for the use of this drawing to build parts without approval is strictly forbidden. We refer to the drawing in this document only in the information contained therein. Responsibility for the use of this drawing to build parts without approval is strictly forbidden.							
A		21-Feb-19		L. Lehtisalo		5000011784	

STAGE7: SWING FRAME KIT W800 AND SHROUD KIT W800 INSTALLATION


See assembly drawings for details and required additional Ritral and standard parts.

SWING FRAME KIT W800
 KIT L-8-X-053-VX
 Ordering code: 3AXD50000301410
 Drawing code: 3AXD50000344864

First angle projection. Original drawing made with 3D CAD. Set the correct scale factor when adding dimensions after DWG/DXF conversion.


SHROUD KIT W800
 KIT L-8-024-VX
 Ordering code: 3AXD50000361427
 See drawing: 3AXD50000353125



Based on	L. Lehtisalo	21-Feb-19	Title	ASSEMBLY DRAWING	Scale	Form
Customer	M. VOSILINEN	21-FEB-19	Project	ACS880-104LC	1:1	A3
Cart. Desc. No.	3AXD10000869301	21-FEB-19	Project name	ACS880-104LC	Revised	RAP7
DWG Number	3AXD10000869301	21-FEB-19	Weight	kg	37.8648935	45
Doc. No.	3AXD50000436415	21-FEB-19	Dec. No.	3AXD50000436415	Sheet	10
					Sheet	10
					Total	10

■ One R8i module in a 400 mm wide generic enclosure

Parts to be installed	Instruction code	Kit code	Kit ordering code
Bottom plate	3AXD50000004817	A-468-8-441	3AXD50000004385
Cooling component kit	3AXD500000048217	L-468-8-441	3AXD50000044084
AC busbars	3AUA0000118667	A-468-8-100	3AUA0000119227
	3AXD500000043742	L-4-8-131	3AXD500000043691
Module mounting mechanics and cooling components	-	-	3AXD500000043886 / 3AXD500000045414
		L-468-8-440	3AXD500000041265
DC busbars	3AXD500000043729	L-4-8-251	3AXD500000043679
	3AXD500000041311	L-468-8-230	3AXD500000041264
Inverter module	-	-	-
Shrouding	-	-	-



KITS FOR ACS880-104LC 1xR81 IN GENERIC 2000x600x400 CABINET

Note! Only parts included in ABB kits are shown here!
See kit assembly drawings for details.

1 2 3 4 5 6 7 8
 3AXD5000048321
 ACS880-104LC-BITRAL-WOOD (ASSEMBLY)
 A Initial Approval
 18-Jan-17 M. Michelsson
 No reserve all rights in this document and in the information contained herein. Reproduction, in whole or in part, without the written permission of ABB is strictly forbidden.
 First angle projection. Original drawing made with 3D CAD. Set the correct scale factor when adding dimensions after DWG/DXF conversion.

Prepared	M. Michelsson	18-Jun-17	Title	ASSEMBLY DRAWING	Scale	Form
Checked	M. Vesterinen	18-Jun-17		ASSEMBLY DRAWING	1:1	1/15
Project name	M. Vesterinen	18-Jun-17		Doc. No.	3AXD5000048321	Sheet
Customer				Doc. No.	3AXD5000048321	Total
DNS Number	3AXD10000580288					

R81 FAN KIT
 Ordering code: 3AXD5000043866 (230V)
 ; 3AXD5000045414 (115V)

COOLING COMPONENTS KIT I
 KIT L-468-8-441
 Ordering code: 3AXD5000044084

LEAD-THROUGH KIT FOR BOTTOM PLATE
 KIT A-468-8-441
 Ordering code: 3AXD5000004385
 (KIT/MODULE GENERIC)

ACS880C HEAT EXCHANGER KIT
 KIT L-468-8-440
 Ordering code: 3AXD5000041265

R81 MODULE MOUNTING MECH W400
 KIT L-4-8-301
 Ordering code: 3AXD5000043678

R81 COMMON MODE BUSBAR KIT LC
 KIT L-468-8-230
 Ordering code: 3AXD5000041264

R81 AC OUTPUT BUSBAR KIT W400
 KIT L-4-8-131
 Ordering code: 3AXD5000043691

R81 DC FUSE BUSBAR KIT LC W400
 KIT L-4-8-251
 Ordering code: 3AXD5000043679


X8X QUICK CONNECTORS FOR MODULE
 KIT A-468-8-100
 Ordering code: 3AXD5000119227

■ **Two R8i modules in a 600 mm wide generic enclosure**

Parts to be installed	Instruction code	Kit code	Kit ordering code
Bottom plate	3AXD50000004817	A-468-8-441	3AXD50000004385
Cooling component kit	3AXD500000048258	L-468-8-442	3AXD500000044182
AC busbars	3AUA0000118667	A-468-8-100	3AUA0000119227
	3AXD500000041888	L-6-8-132	3AXD500000041733
Module mounting mechanics and cooling components	3AXD500000041836	L-6-8-302	3AXD500000041710
	-	-	3AXD500000043886 / 3AXD500000045414
	-	L-468-8-440	3AXD500000041265
DC busbars	3AXD500000041842	L-6-8-252	3AXD500000041731
	3AXD500000041311	L-468-8-230	3AXD500000041264
Inverter modules	-	-	-
Shrouding	-	-	-

■ **Three R8i modules in a 800 mm wide generic enclosure**

Parts to be installed	Instruction code	Kit code	Kit ordering code
Bottom plate	3AXD50000004817	A-468-8-441	3AXD50000004385
Cooling component kit	3AXD500000048283	L-468-8-443	3AXD500000048136
AC busbars	3AUA0000118667	A-468-8-100	3AUA0000119227
	3AXD500000041909	L-8-8-133	3AXD500000041734
Module mounting mechanics and cooling components	3AXD500000041461	L-8-8-303	3AXD500000041248
	-	-	3AXD500000043886 / 3AXD500000045414
	-	L-468-8-440	3AXD500000041265
DC busbars	3AXD500000041448	L-8-8-253	3AXD500000041263
	3AXD500000041311	L-468-8-230	3AXD500000041264
Inverter modules	-	-	-
Shrouding	-	-	-



5

Electrical installation

Contents of this chapter

This chapter describes the electrical installation of the modules.

The wiring diagrams in this chapter are simplified presentations. For details, see the example circuit diagrams included in the manual.

Note:

The instructions do not cover all possible cabinet constructions.

For more information on electrical installation, see *Electrical planning instructions for ACS880 liquid-cooled multidrive cabinets and modules* [3AXD50000048634 (English)].

Safety and liability



WARNING!

Only qualified electricians are allowed to do the work described in this chapter. Read the **complete safety instructions** before you install, commission, use or service the drive. The complete safety instructions are given in *Safety instructions for ACS880 liquid-cooled multidrive cabinets and modules* (3AXD50000048633 [English]).

Note:

The installation must always be designed and made according to applicable local laws and regulations. ABB does not assume any liability whatsoever for any installation which breaches the local laws and/or other regulations. Furthermore, if the recommendations given by ABB are not followed, the drive system may experience problems that the warranty does not cover.

Electrical safety precautions

These electrical safety precautions are for all personnel who do work on the drive, motor cable or motor.



WARNING!

Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur.

If you are not a qualified electrician, do not do installation or maintenance work.

Go through these steps before you begin any installation or maintenance work.

1. Keep the cabinet doors closed when the drive is powered. With the doors open, a risk of a potentially fatal electric shock, arc flash or high-energy arc blast exists.
2. Clearly identify the work location and equipment.
3. Disconnect all possible voltage sources. Lock out and tag out.
 - Open the main disconnecting device of the drive.
 - Open the charging switch if present.
 - Open the disconnecter of the supply transformer. (The main disconnecting device in the drive cabinet does not disconnect the voltage from the AC input power busbars of the drive cabinet.)
 - If the drive is equipped with a DC/DC converter unit (optional): Open the DC switch/disconnector ([Q11], option +F286) of the DC/DC converter. Open the disconnecting device of the energy storage connected to the DC/DC converter unit (outside the drive cabinet).
 - Open the auxiliary voltage switch-disconnector (if present), and all other possible disconnecting devices that isolate the drive from dangerous voltage sources.
 - In the liquid cooling unit (if present), open the motor protective circuit breaker(s) of the cooling pumps.
 - If you have a permanent magnet motor connected to the drive, disconnect the motor from the drive with a safety switch or by other means.
 - Make sure that re-connection is not possible. Lock out and tag out.
 - Disconnect any dangerous external voltages from the control circuits.
 - After you disconnect power from the drive, always wait 5 minutes to let the intermediate circuit capacitors discharge before you continue.
4. Protect any other energized parts in the work location against contact.
5. Take special precautions when close to bare conductors.
6. Measure that the installation is de-energized. If the measurement requires removal or disassembly of shrouding or other cabinet structures, obey the local laws and regulations applicable to live working (including – but not limited to – electric shock and arc protection).
 - Use a multimeter with an impedance greater than 1 Mohm.
 - Make sure that the voltage between the drive input power terminals (L1, L2, L3) and the grounding (PE) busbar is close to 0 V.
 - Make sure that the voltage between the drive DC busbars (+ and -) and the grounding (PE) busbar is close to 0 V.
 - If you have a permanent magnet motor connected to the drive, make sure that the voltage between the drive output terminals (T1/U, T2/V, T3/W) and the grounding (PE) busbar is close to 0 V.



7. Install temporary grounding as required by the local regulations.
8. Ask the person in control of the electrical installation work for a permit to work.

General notes

■ Printed circuit boards



WARNING!

Use a grounding wrist band when you handle printed circuit boards. Do not touch the boards unnecessarily. The boards contain components sensitive to electrostatic discharge.

■ Optical components



WARNING!

Obey these instructions. If you ignore them, damage to the equipment can occur.

- Handle the fiber optic cables with care.
- When you unplug the fiber optic cables, always hold the connector, not the cable itself.
- Do not touch the ends of the fibers with bare hands as the ends are extremely sensitive to dirt.
- Do not bend the fiber optic cables too tightly. The minimum allowed bend radius is 35 mm (1.4").

Checking the insulation of the drive system



WARNING!

Do not make any voltage withstand or insulation resistance tests on any part of the drive as testing can damage the drive. Every drive has been tested for insulation between the main circuit and the chassis at the factory. Also, there are voltage-limiting circuits inside the drive which cut down the testing voltage automatically.

Checking the insulation of the motor and motor cable



WARNING!


Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

If you are not a qualified electrician, do not do installation or maintenance work.

1. Stop the drive and do the steps in section *Electrical safety precautions (page 82)* before you start the work.
2. Check that the motor cable is disconnected from the drive output terminals.
3. Measure the insulation resistance between the phase conductors and then between each phase conductor and the Protective Earth conductor. Use a measuring voltage of 1000 V DC. The insulation resistance of an ABB motor must exceed 100 Mohm (reference value at 25 °C [77 °F]). For the insulation resistance of other motors, consult the manufacturer's instructions.


Note:

Moisture inside the motor casing reduces the insulation resistance. If moisture is suspected, dry the motor and repeat the measurement.




Power connections - Frame R8i

■ R8i inverter module



A	Inverter cubicle
1	DC supply
2	DC switch/disconnector
3	Charging circuit (fuses, resistors, charging controller)
4	DC fuses
5	Common mode filter
6	Inverter module
7	Motor

■ 2×R8i inverter unit



A	Inverter cubicle
1	DC supply
2	DC switch/disconnector
3	Charging circuit (fuses, resistors, charging controller)
4	DC fuses
5	Common mode filters
6	Inverter modules
7	Motor



■ Connection procedure



WARNING!

Read and follow the instructions given in *Safety instructions for ACS880 multidrive cabinets and modules* (3AUA0000102301 [English]). Ignoring the instructions can cause physical injury or death, or damage to the equipment.


1. Ground the inverter modules by the top edge of the front plate. The grounding point is marked on the module. Connect the front plate to the frame support bracket with screws. The bracket should have a galvanic connection to the PE busbar through the cabinet frame.

Note:

- If the cabinet frame is painted (such as with Rittal enclosures), it is important to make sure that a good galvanic connection to ground (PE busbar) is achieved. You can, for example, remove the paint from the connection points and use star washers.
- The connection to ground merely through the mounting screws and the cabinet chassis is not always good enough. To ensure the continuity of the protective bonding circuit, you can connect the modules to the cabinet PE busbar with a copper busbar or cable. The inductance and impedance of the PE conductor must be rated according to permissible touch voltage appearing under fault conditions (so that the fault point voltage will not rise excessively when a ground fault occurs).

See *Electrical planning instructions for ACS880 liquid-cooled multidrive cabinets and modules* [3AXD50000048634 (English)].

2. Run the output (motor) cable into the cubicle through a cable gland or grommet. 360° grounding of the cable shield is recommended to suppress interference. In case a grounding cable gland is available, remove the outer jacket of the cable where it passes through the cable gland.
3. Cut the output cable to suitable length and strip the ends of the individual conductors.
4. Twist the shield strands of the output cable together to form a separate conductor and wrap tape around it as shown.




5. Crimp suitable cable lugs to the conductors as well as the twisted shield. Connect the phase conductors to the output busbars. Connect the cable shield to a PE busbar.

6. Secure the cables inside and outside the cabinet mechanically.
7. Tighten the cable gland if present.

Grounding the motor cable shield at the motor end

For minimum radio-frequency interference, ground the cable shield 360 degrees at the cable entry of the motor terminal box.



Connecting the control cables - All frame sizes

For technical data and default I/O connections of the inverter control unit, refer to chapter Control unit.


1. In the cabinet, remove shrouding wherever necessary to allow access to the cable entries and any trunking inside the cubicle.
2. Run the control cables into the cubicle. If possible, arrange for a 360° grounding of the cable shield at the cable entry.

If the outer surface of the shield is non-conductive, turn the shield inside out as shown below and wrap copper foil around the cable to keep the shielding continuous. Do not cut the grounding wire (if present).

A	Stripped cable
B	Conductive surface of the shield exposed
C	Stripped part covered with copper foil
1	Cable shield
2	Copper foil
3	Shielded twisted pair
4	Grounding wire
5	Copper cable

3. Run the cables to the control unit of the inverter (or other connection point) using cable trunking wherever possible.
4. (Only when running the cable to the inverter module) The inverter control units have a clamp plate attached. Remove the outer sheathing of the cable at one of the clamps on the plate. Tighten the clamp onto the bare cable shield.
5. Cut the cables to suitable length.

6. Strip the cable ends and conductors. When connecting to the drive I/O, also remove the shield along with the outer sheathing, and use electrical tape or shrink tubing to contain the strands. Elsewhere, twist the outer shield strands into a bundle, crimp a lug onto it and connect it to the nearest chassis grounding point.



7. Connect the conductors to appropriate terminals.
8. Refit any shrouds removed earlier.



Installing optional modules

■ Installation of I/O extension and fieldbus adapter modules



WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

Note:

Pay attention to the free space required by the cabling or terminals coming to the optional modules.

1. Repeat the steps described in section [Electrical safety precautions \(page 82\)](#).
2. Ensure by measuring that the I/O terminals of the control unit (especially the relay output terminals) are safe.
3. Insert the module into a free option module slot on the control unit.
4. Fasten the module. For instructions, see the documentation of the optional module.
5. Connect the necessary wiring to the module following the instructions given in the documentation of the module.
6. Tighten the grounding screw to a torque of 0.8 N·m.

Note:

The screw tightens the connections and grounds the module. It is essential for fulfilling the EMC requirements and for proper operation of the module.

■ Installation of an FSO-xx safety functions module

Installation of an FSO-xx safety functions module onto BCU




WARNING!

Read the safety instructions given in *Safety instructions for ACS880 liquid-cooled multidrive cabinets and modules (3AXD50000048633 [English])*. If you ignore them, injury or death, or damage to the equipment can occur.

This procedure describes the installation of an FSO-xx safety functions module onto the BCU control unit. (The FSO-xx can alternatively be installed beside the control unit, which is the standard with factory-installed FSO-xx modules. For instructions, see the FSO-xx manual.)

1. Stop the inverter unit and do the steps in section [Electrical safety precautions \(page 82\)](#) before you start the work.
2. The FSO-xx comes with alternative bottom plates for mounting on different units. For mounting on the BCU, the mounting points should be located at the long edges of the module as shown. Replace the bottom plate of the FSO-xx if necessary.
3. Fasten the FSO-xx onto slot 3 of the BCU control unit [A41] with four screws.






4. Tighten the FSO-xx electronics grounding screw.

Note:

The screw tightens the connections and grounds the module. It is essential for fulfilling the EMC requirements and for proper operation of the module.

5. Connect the FSO-xx data cable between FSO-xx connector X110 and BCU-x2 connector X12.
6. To complete the installation, refer to the instructions in the User's manual delivered with the FSO-xx.




Installation of FSO-xx beside the control unit

To reserve the slots of the control unit for other modules, you can install the FSO-xx separate from the control unit using mounting kit 3AXD50000025495. The kit contains the parts for mounting the FSO-xx either onto a DIN rail nearby the control unit. The kit also contains longer cables for connecting the FSO-xx to the control unit.

Refer to instruction 3AXD50000025583 for installation details.


Mounting on DIN rail



Connecting a PC

A PC (with eg, the Drive composer PC tool) can be connected as follows:

1. Connect an ACx-AP-x control panel to the unit either
 - by inserting the control panel into the panel holder or platform (if present), or
 - by using an Ethernet (eg, Cat 5e) networking cable.
2. Remove the USB connector cover on the front of the control panel.
3. Connect an USB cable (Type A to Type Mini-B) between the USB connector on the control panel (3a) and a free USB port on the PC (3b).
4. The panel will display an indication whenever the connection is active.



5. See the documentation of the PC tool for setup instructions.

Panel bus (Control of several inverter units from one control panel)

One control panel (or PC) can be used to control several drives (or inverter units, supply units etc.) by constructing a panel bus. This is done by daisy-chaining the panel connections of the drives. Some drives have the necessary (twin) panel connectors in the control panel holder; those that do not require the installation of an FDPI-02 module (available separately). For further information, see the hardware description and *FDPI-02 diagnostics and panel interface user's manual* (3AUA0000113618 [English]).

The maximum allowed length of the cable chain is 100 m (328 ft).

1. Connect the panel to one drive using an Ethernet (for example Cat 5e) cable.
 - Use Menu - Settings - Edit texts - Drive to give a descriptive name to the drive
 - Use parameter *49.01** to assign the drive with a unique node ID number
 - Set other parameters in group *49** if necessary
 - Use parameter *49.06** to validate any changes.

*The parameter group is 149 with supply (line-side), brake or DC/DC converter units.

Repeat the above for each drive.

2. With the panel connected to one unit, link the units using Ethernet cables.
3. Switch on the bus termination on the drive that is farthest from the control panel in the chain.



- With drives that have the panel mounted on the front cover, move the terminating switch into the outer position.
- With an FDPI-02 module, move termination switch S2 into the TERMINATED position.

Make sure that bus termination is off on all other drives.





4. On the control panel, switch on the panel bus functionality (Options - Select drive - Panel bus). The drive to be controlled can now be selected from the list under Options - Select drive.

If a PC is connected to the control panel, the drives on the panel bus are automatically displayed in the Drive composer tool.

With twin connectors in the control panel holder:



With FDPI-02 modules:





Installation checklist of the drive

Contents of this chapter

This chapter contains a checklist of the mechanical and electrical installation of the drive.

Checklist

Examine the mechanical and electrical installation of the drive before start-up. Go through the checklist together with another person.



WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

If you are not a qualified electrician, do not do installation or maintenance work.



WARNING!

Stop the drive and do the steps in section *Electrical safety precautions (page 82)* before you start the work.

Make sure that ...	<input checked="" type="checkbox"/>
The ambient operating conditions meet the drive ambient conditions specification, and enclosure rating (IP code or UL enclosure type).	<input type="checkbox"/>
The supply voltage matches the nominal input voltage of the drive. See the type designation label.	<input type="checkbox"/>
The drive cabinet has been attached to floor, and if necessary due to vibration etc, also by its top to the wall or roof.	<input type="checkbox"/>
<u>If the drive is connected to a network other than a symetrically grounded TN-S system:</u> Check the compatibility. See the electrical installation instructions in the supply unit manual.	<input type="checkbox"/>
The enclosures of the equipment in the cabinet have proper galvanic connection to the cabinet protective earth (ground) busbar; The connection surfaces at the fastening points are bare (unpainted) and the connections are tight, or separate grounding conductors have been installed.	<input type="checkbox"/>

96 Installation checklist of the drive

Make sure that ...	<input checked="" type="checkbox"/>
The main circuit connections inside the drive cabinet correspond to the circuit diagrams.	<input type="checkbox"/>
The control unit has been connected. See the circuit diagrams.	<input type="checkbox"/>
Appropriate AC fuses and main disconnecter have been installed.	<input type="checkbox"/>
There is an adequately sized protective earth (ground) conductor between the drive and the switchboard, the conductor has been connected to appropriate terminal, and the terminal has been tightened to the proper torque. Proper grounding has also been measured according to the regulations.	<input type="checkbox"/>
The input power cable has been connected to the appropriate terminals, the phase order is right, and the terminals have been tightened to the proper torque.	<input type="checkbox"/>
There is an adequately sized protective earth (ground) conductor between the motor and the drive, and the conductor has been connected to appropriate terminal, and the terminal has been tightened to the proper torque. (Pull on the conductors to check.) Proper grounding has also been measured according to the regulations.	<input type="checkbox"/>
The motor cable has been connected to the appropriate terminals, the phase order is right, and the terminals have been tightened to the proper torque.	<input type="checkbox"/>
The motor cable has been routed away from other cables.	<input type="checkbox"/>
No power factor compensation capacitors have been connected to the motor cable.	<input type="checkbox"/>
The control cables have been connected to the appropriate terminals, and the terminals have been tightened to the proper torque.	<input type="checkbox"/>
<u>If a drive bypass connection will be used:</u> The direct-on-line contactor of the motor and the drive output contactor are either mechanically and/or electrically interlocked, ie, cannot be closed simultaneously. A thermal overload device must be used for protection when bypassing the drive. Refer to local codes and regulations.	<input type="checkbox"/>
There are no tools, foreign objects or dust from drilling inside the drive.	<input type="checkbox"/>
Cover(s) of the motor connection box are in place. Cabinet shrouds are in place and doors are closed.	<input type="checkbox"/>
The motor and the driven equipment are ready for start.	<input type="checkbox"/>
The coolant connections between cubicles (if any) and to the cooling circuit are tight.	<input type="checkbox"/>
<u>If the drive is equipped with a cooling unit:</u> Refer to the cooling unit documentation for specific tasks.	<input type="checkbox"/>

7

Start-up

Contents of this chapter

This chapter contains the start-up procedure of the inverter.

Note:

These instructions do not cover all possible cabinet constructions. Always refer to the delivery-specific circuit diagrams when proceeding with the start-up.



WARNING!


Only qualified electricians are allowed to do the work described in this chapter. Read the complete safety instructions and repeat the steps described in section Electrical safety precautions. The complete safety instructions are given in *Safety instructions for ACS880 multidrive cabinets and modules* [3AUA0000102301 (English)]. Ignoring the instructions can cause physical injury or death, or damage to the equipment.

Note:



The customer is fully responsible for implementing and testing the functional safety circuits according to the relevant legislation and acceptance testing regulations. The functional safety option manuals give examples on implementing the safety circuits in ACS880 multidrives. For information on the Safe torque off functions, see chapter The Safe torque off function.









Start-up procedure

Tasks	<input checked="" type="checkbox"/>
Safety	
 WARNING! Obey the safety instructions during the start-up procedure. See <i>Safety instructions for ACS880 multidrive cabinets and modules</i> (3AUA0000102301 [English]) and section Electrical safety precautions.	<input type="checkbox"/>
Checks/Settings with no voltage connected	
Check the mechanical and electrical installation. See Installation checklist.	<input type="checkbox"/>
Make sure that the insulation resistance of the assembly has been checked. See Checking the insulation of the assembly.	<input type="checkbox"/>
The supply unit of the drive system has been set up according to the instructions in its manuals.	<input type="checkbox"/>
The supply unit is off, and the drive system has been isolated from the supply network.	<input type="checkbox"/>
Check that any circuit breakers and protection switches in the cooling fan supply circuit are closed. Refer to the circuit diagrams.	<input type="checkbox"/>
Check the following data for each inverter unit and note down any deviations from delivery documents.	
• Motor, pulse encoder and cooling fan rating plate data correspond to the values in the motor list.	<input type="checkbox"/>
• Motor temperature method: Pt100, PTC, KTY84, other?	<input type="checkbox"/>
• Motor fan of separately ventilated motors. Check the current, the overcurrent protection setting and the functioning of the fan output control circuit.	<input type="checkbox"/>
• Direction of motor rotation.	<input type="checkbox"/>
• Maximum and minimum speeds, fixed speeds.	<input type="checkbox"/>
• Speed scaling factor, gear ratio, roll diameter, etc.	<input type="checkbox"/>
• Acceleration and deceleration times.	<input type="checkbox"/>
• Inertia compensation.	<input type="checkbox"/>
• Operating modes, stop mode, emergency stop mode, etc.	<input type="checkbox"/>
Starting and checking the cooling system	
Fill up and bleed the internal cooling circuit. Start the cooling unit up. See section Filling up and bleeding the internal cooling circuit.	<input type="checkbox"/>
Check the cooling system for leaks. Make sure that cooling circuit joints at the shipping split joining cubicles are tight and that all drain valves have been closed.	<input type="checkbox"/>
Make sure that the coolant can flow freely in all cubicles. Make sure that the drive system cools down.	<input type="checkbox"/>
Connecting voltage to the auxiliary circuits	
Disconnect any auxiliary voltage (230 or 115 V AC) cables that lead from the terminal blocks to the outside of the equipment and have not yet been checked. Also disconnect any uncompleted wiring.	<input type="checkbox"/>
Disconnect the communication link between the drive system and any overriding system.	<input type="checkbox"/>
Make sure the main contactor/breaker cannot be switched on inadvertently by remote control.	<input type="checkbox"/>



Tasks	<input checked="" type="checkbox"/>
Be ready to trip the main breaker of the supply transformer in case something abnormal occurs.	<input type="checkbox"/>
Ensure all cabinet doors are closed.	<input type="checkbox"/>
Close the main breaker of the supply transformer. This will energize the input terminals of the drive system.	<input type="checkbox"/>
Close the auxiliary voltage switch (if present).	<input type="checkbox"/>
Checks with auxiliary voltage connected	
Check that the cooling fans rotate freely in the right direction, and the air flows upwards. Note: Depending on the wiring of the drive system, it may be necessary to have the supply unit powered before the fans are started. If so, check the cooling fans after powering the supply unit.	<input type="checkbox"/>
Set the parameters for each inverter unit. Refer to the firmware manual and/or start-up guide of the control program. You can also use the start-up assistant if available in the particular control program. In addition to the parameter settings required by the application, make the following settings:	
• Set <i>31.23 Wiring or earth fault</i> to “No action”.	<input type="checkbox"/>
• Set <i>95.04 Control board supply</i> according to how the inverter control unit is powered.	<input type="checkbox"/>
• Edit <i>95.09 Fuse switch control</i> if necessary (ie. with R8i modules without a DC switch/disconnector and charging controller).	<input type="checkbox"/>
• With parallel-connected R8i modules, select the inverter unit type in parameter <i>95.31 Parallel type configuration</i> . You can filter the list using parameter <i>95.30</i> .	<input type="checkbox"/>
• Reboot the control unit either by cycling the power, or by parameter <i>96.08 Control board boot</i> .	<input type="checkbox"/>
Powering up the inverter unit	
Close the cabinet doors.	<input type="checkbox"/>
Make sure that it is safe to connect voltage to the drive system. Ensure that: <ul style="list-style-type: none"> nobody is working on the unit or circuits that have been wired from outside into the cabinets cover of the motor terminal box is on. 	<input type="checkbox"/>
Close the main disconnecting device of the drive system.  WARNING! When connecting voltage to the supply unit, the DC busbars will become live, as will all the inverters connected to the DC bus.  WARNING! <u>Inverter units with a DC switch-disconnector:</u> Some types of inverter module may be energized through a charging circuit even when the DC switch-disconnector is open or the DC fuses are removed. <u>Inverter units without a DC switch-disconnector:</u> If the inverter unit only has DC fuses without a switch fuse, all the inverter units with the DC fuses in place will be energized when the main breaker/contacter closes. To prevent this, remove the fuses from the inverter units which are to remain unenergized before connecting voltage. When the main breaker/contacter of the supply unit is closed (DC busbars are live), never remove or insert the DC fuses of an inverter unit.	<input type="checkbox"/>
<u>Inverter units equipped with DC switch-disconnector (or fuse disconnectors):</u> Close the DC switch/disconnector (or fuse disconnectors) of the inverter units that are to be powered up.	<input type="checkbox"/>



Tasks	<input checked="" type="checkbox"/>
 WARNING! Before closing the main contactor/air circuit breaker, make sure that sufficient inverter power is connected to the intermediate (DC) bus. As a rule of thumb, <ul style="list-style-type: none"> • the sum power of the inverters connected must be at least 30% of the sum power of all inverters • the sum power of the inverters connected must be at least 30% of the rated power of the brake unit ($P_{br.max}$) (if present). If the above-mentioned rules are not followed, the DC fuses of the connected inverter units may blow, or the brake chopper (if present) may be damaged.	<input type="checkbox"/>
Close the main contactor (or breaker) of the supply unit. The DC bus is now powered, along with all inverters that are connected to it.	<input type="checkbox"/>
Checks with voltage connected to the inverter unit	
Complete the pending ID (motor identification) run. Refer to the firmware manual and/or start-up guide of the control program.  WARNING! Make sure the motor can be started and rotated as required by the selected ID run mode (parameter 99.13 ID run requested).	<input type="checkbox"/>
Check the rotation direction of the motor.	<input type="checkbox"/>
Check the operation of the pulse encoder (if present). Refer to the user manual of the pulse encoder interface module.	<input type="checkbox"/>
Check the functioning of the emergency stop function from each operating location.	<input type="checkbox"/>
Validate the Safe torque off function. Refer to chapter The Safe torque off function, section Start-up including acceptance test.   WARNING! The safety functions cannot be considered safe until they are validated.	<input type="checkbox"/>
Validate any other safety functions (Emergency stop, Prevention of unexpected start-up, etc.) according to the appropriate procedures.   WARNING! The safety functions cannot be considered safe until they are validated.	<input type="checkbox"/>
Control from an overriding system	
Disconnect all voltages from the drive system.	<input type="checkbox"/>
Connect the communication link between the overriding system and the inverter unit.	<input type="checkbox"/>
Power up the drive system.	<input type="checkbox"/>
Check the start/stop functions.	<input type="checkbox"/>
Check the references received from the overriding system.	<input type="checkbox"/>
Check the warning/fault words.	<input type="checkbox"/>
Check the reaction of the inverter unit in case of a communication break.	<input type="checkbox"/>
Check the updating intervals of the communication.	<input type="checkbox"/>

Tasks	<input checked="" type="checkbox"/>
Check any other relevant points.	<input type="checkbox"/>





Maintenance

Contents of this chapter

This chapter instructs how to maintain the inverter module and how to interpret its fault conditions. The information is valid for ACS880-104LC inverter modules and the cabinet construction examples presented in this manual.

**WARNING!**

Only qualified electricians are allowed to do the work described in this chapter. Read the complete safety instructions before you install, commission, use or service the converter. The complete safety instructions are given in *Safety instructions for ACS880 liquid-cooled multidrive cabinets and modules (3AXD50000048633 [English])*.

Maintenance intervals

The table below shows the maintenance tasks which can be done by the end user. The complete maintenance schedule is available on the Internet (www.abb.com/drivesservices). For more information, consult your local ABB Service representative (www.abb.com/searchchannels).

Maintenance task/object	Years from start-up													...
	0	1	2	3	4	5	6	7	8	9	10	11	12	
Coolant														
Checking coolant antifreeze concentration		P	P	P	P	P	P	P	P	P	P	P	P	
Checking coolant quality			P		P		P		P		P		P	
Coolant draining and replacement							R						R	
Cooling fan														
Cooling fan (underneath each inverter module), 230 V										R				
Cooling fan (underneath each inverter module), 115 V							R						R	
Batteries														
Control unit battery							R						R	
Control panel battery										R				
Connections and environment														
Quality of supply voltage		P	P	P	P	P	P	P	P	P	P	P	P	P
Spare parts														
Spare parts		I	I	I	I	I	I	I	I	I	I	I	I	I
DC circuit capacitor reforming (spare modules and spare capacitors)		P	P	P	P	P	P	P	P	P	P	P	P	P
Inspections														
Checking tightness of cable and busbar terminals. Tightening if needed.		I	I	I	I	I	I	I	I	I	I	I	I	I
Checking ambient conditions (dustiness, corrosion, temperature)		I	I	I	I	I	I	I	I	I	I	I	I	I
Checking coolant pipe connections		I	I	I	I	I	I	I	I	I	I	I	I	I
3AXD10000578918 F														

Symbols

- I Inspection** (visual inspection and maintenance action if needed)
- P Performance** of on/off-site work (commissioning, tests, measurements or other work)
- R Replacement**

Maintenance and component replacement intervals are based on the assumption that the equipment is operated within the specified ratings and ambient conditions. ABB recommends annual drive inspections to ensure the highest reliability and optimum performance.

Note:

Long term operation near the specified maximum ratings or ambient conditions may require shorter maintenance intervals for certain components. Consult your local ABB Service representative for additional maintenance recommendations.

Maintenance timers and counters

The control program has maintenance timers and counters that can be configured to generate a warning when a pre-defined limit is reached. Each timer/counter can be set to monitor any parameter. This feature is especially useful as a service reminder. For more information, see the firmware manual.

Cooling system

For instructions on coolant replacement and checking the cooling system, see chapter Internal cooling circuit.

Cabinet

■ Cleaning the interior of the cabinet



WARNING!

Read the safety instructions given in *Safety instructions for ACS880 liquid-cooled multidrive cabinets and modules* (3AXD50000048633 [English]). If you ignore them, injury or death, or damage to the equipment can occur.



WARNING!

Use a vacuum cleaner with an antistatic hose and nozzle, and wear a grounding wristband. Otherwise an electrostatic charge might build up and damage the circuit boards.

1. Stop the drive and do the steps in section *Electrical safety precautions (page 82)* before you start the work.
2. Open the cabinet door.
3. Clean the interior of the cabinet. Use a vacuum cleaner and a soft brush.
4. Clean the air inlets of the fans and air outlets of the modules (top).
5. Clean the air inlet gratings (if any) on the door.
6. Close the door.

Power connections

■ Retightening the power connections



WARNING!

Read the safety instructions given in *Safety instructions for ACS880 liquid-cooled multidrive cabinets and modules* (3AXD50000048633 [English]). Ignoring the instructions can cause physical injury or death, or damage to the equipment.

1. Repeat the steps described in section *Electrical safety precautions*.
 2. Check the tightness of the cable connections. Use the tightening torques given in section *Tightening torques*. See also *Dimension drawings*.
-

Cooling fans

The life span of the cooling fan depends on the running time of the fan, ambient temperature and dust concentration. See the firmware manual for the actual signal which indicates the running time of the cooling fan. Reset the running time signal after fan replacement.

Replacement fans are available from ABB. Do not use other than ABB specified spare parts.


■ Frame R8i fan replacement



WARNING!

Wear protective gloves and long sleeves. Some parts have sharp edges.

1. Repeat the steps described in section [Electrical safety precautions \(page 82\)](#).
2. Remove any shrouding in front of the cooling fan.
3. Disconnect the fan wiring.
4. Undo the two retaining screws (a).
5. Pull the fan outwards to separate it from the heat exchanger housing.
6. Install new fan in reverse order. Align the guide pins (b) at the rear of the fan cowling with the slots (c) in the module bottom guide, then reinstall the retaining screws (a).



Inverter module

■ Replacing an inverter module

**WARNING!**

Obey the safety instructions given in *Safety instructions for ACS880 liquid-cooled multidrive cabinets and modules* (3AXD50000048633 [English]). If you ignore the safety instructions, injury or death, or damage to the equipment can occur.

If you are not a qualified electrician, do not do installation or maintenance work.

**WARNING!**

Make sure that the replacement module has exactly the same type code as the old module.

**WARNING!**


Beware of hot coolant. Do not work on the liquid cooling system until the pressure is lowered down by stopping the pumps and draining the coolant. High-pressure warm coolant (6 bar, max. 50 °C) is present in the internal cooling circuit when it is in operation.

**WARNING!**


Use the required personal protective equipment. Wear protective gloves and long sleeves. Some parts have sharp edges.

Removing the module


1. Repeat the steps described in section Electrical safety precautions.
2. Remove the shrouding in front of the module.
3. Undo the locking screws of the swing-out frame (if present) and open it.
4. Unplug the wiring from the module and move it aside. Use cable ties to keep the wiring out of the way.
5. Remove the L-shaped DC busbars at the top of the module. Make note of the orientation of the screws as well as the order of the washers.




6. Close the inlet valve (a) and outlet valve (located on the right-hand side of the cubicle) valves. Lead the drain hoses (b, on both sides of the cubicle) into a suitable container. Open the drain valves (c, on both sides of the cubicle). This will drain all modules in the cubicle.




7. After the module has drained, disconnect the piping from the module.



8. Remove the module retaining screws at the top and the bottom of the module.



9. Pull the module carefully out onto a table or other platform. Keep the module secured to a hoist or equivalent to prevent the module from falling. For information on using the lifting device, see *Converter module lifting device for drive cabinets hardware manual* (3AXD50000210268 [English]).



Reinstalling the module

1. Push the module carefully into its bay.
 2. Fasten the retaining screws at the top and the bottom of the module.
 3. Reinstall the DC busbars at the top of the module.
 4. Reconnect the coolant pipes to the module.
 5. Reconnect the control wiring to the module.
 6. Fill up the cooling system. For instructions, see section *Filling up and bleeding the internal cooling circuit*.
-

110 Maintenance

7. Close the swing-out frame (if present). Reinstall all shrouds removed earlier.



Control panel

For detailed information on the control panel, see *ACx-AP-x assistant control panels user's manual* (3AUA0000085685 [English]).

■ **Cleaning the control panel**

Use a soft damp cloth to clean the control panel. Avoid harsh cleaners which could scratch the display window.

■ **Replacing the control panel battery**

For instructions on how to replace the control panel battery, see the separate *ACx-AP-x assistant control panels user's manual* document (3AUA0000085685 [English]).

Control unit

■ Replacing the memory unit


After replacing a control unit, you can retain the existing parameter settings by transferring the memory unit from the defective control unit to the new control unit.



WARNING!

Do not remove or insert the memory unit when the control unit is powered.


1. Stop the drive and do the steps in section [Electrical safety precautions \(page 82\)](#) before you start the work.
2. Make sure that the control unit is not powered.
3. Undo the fastening screw and pull the memory unit out.
4. Install a memory unit in reverse order.



■ Replacing the BCU control unit battery

Replace the real-time clock battery if the BATT OK LED is not illuminated when the control unit is powered.

1. Stop the drive and do the steps in section [Electrical safety precautions \(page 82\)](#) before you start the work.
 2. Undo the fastening screw and remove the battery
 3. Replace the battery with a new BR2032 battery.
 4. Dispose of the old battery according to local disposal rules or applicable laws.
 5. Set the real-time clock.
-



Capacitors

The DC circuit of the power modules of the drive contain several electrolytic capacitors. Their lifespan depends on the operating time of the drive, loading and ambient temperature. Capacitor life can be prolonged by lowering the ambient temperature.

Capacitor failure is usually followed by damage to the unit and an input cable fuse failure, or a fault trip. Contact ABB if capacitor failure is suspected. Replacements are available from ABB. Do not use other than ABB specified spare parts. Contact an ABB service representative for spare parts and repair services.

■ Reforming the capacitors

The capacitors must be reformed if the drive has not been powered (either in storage or unused) for a year or more. The manufacturing date is on the type designation label. For information on reforming the capacitors, see *Converter module capacitor reforming instructions* (3BFE64059629 [English]) in the ABB Library (<https://library.abb.com/en>).

If the drive module has been stored for one to three years, turn on the mains power for 30 minutes without load, then continue as usual.

If the drive module has been stored for less than a year, continue as usual.

LED indications

Warnings and faults reported by the control program are displayed on the control panel or in the Drive composer PC tool. For further information, see the firmware manual of the inverter control program.

■ Control panel and panel platform/holder LEDs

The ACX-AP-x control panel has a status LED. The control panel mounting platform or holder has two status LEDs. For their indications, see the following table.

Location	LED	Indication
Control panel	Continuous green	The unit is functioning normally.
	Flickering green	Data is transferred between the PC and the unit through the USB connection of the control panel.
	Blinking green	There is an active warning in the unit.
	Continuous red	There is an active fault in the unit.
	Blinking red	There is a fault that requires the stopping and restarting of the drive/converter/inverter.
	Blinking blue (ACS-AP-W only)	The Bluetooth interface is enabled, in discoverable mode, and ready for pairing.
	Flickering blue (ACS-AP-W only)	Data is being transferred through the Bluetooth interface of the control panel.
Control panel mounting platform or holder (with the control panel removed)	Red	There is an active fault in the unit.
	Green	Power supply for the control unit is OK.

■ R8i module LEDs

Frame R8i modules have three LEDs. For their indications, see the following table.

Location	LED	Indication
R8i module	FAULT (continuous red)	There is an active fault in the module.
	ENABLE / STO (continuous green)	The module is ready for use.
	ENABLE / STO (continuous yellow)	XSTO connectors are de-energized.
	POWER OK (continuous green)	Supply voltage of the internal circuit boards is OK (> 21 V).

A large, bold, black number '9' is centered within a light blue square with rounded corners. The square is positioned in the upper right quadrant of the page.

Ordering information

Contents of this chapter

This chapter lists the types and ordering codes of the unit components.

You can find the kit-specific assembly drawings, step-by-step instructions and detailed kit information on the Internet. Go to

<https://sites-apps.abb.com/sites/lvacdrivesengineeringsupport/content>. If needed, contact your local ABB representative.

Note:

- This chapter only lists the installation accessories available from ABB. All other parts must be sourced from a third party (such as Rittal) by the system integrator. For a listing, refer to the kit-specific installation instructions available at <https://sites-apps.abb.com/sites/lvacdrivesengineeringsupport/content>. For access, contact your local ABB representative.
- Parts that are labeled suitable for generic enclosures are not designed for any specific enclosure system. These parts are intended as a basis for further engineering, and may require additional parts to be fully usable.

Installation accessories designed for generic enclosures are in fact designed for an inside width of 50 mm less than the nominal width of the enclosure. For example, a mechanical kit intended for 800 mm wide generic enclosure is designed for an inside width of 750 mm, and will not fit a 800 mm wide Rittal VX25 enclosure.

Kit code key

The kit codes shown in this chapter break down as follows.

The format of the kit code is x-w-s-yyy(-VX), for example, L-6-8-401 where:

- x = cooling method
 - A = air-cooled (some of these kits are also used with liquid-cooled drives)
 - L = liquid-cooled
 - w = cabinet width
 - 4 = 400 mm
 - 6 = 600 mm
 - 8 = 800 mm
 - s = module frame size / sizes
 - 1 = R1i
 - 2 = R2i
 - 3 = R3i
 - 4 = R4i
 - 5 = R5i
 - 6 = R6i/D6D
 - 7 = R7i/D7D/D7T
 - 8 = R8i/D8D/D8T
 - X = any, or not defined.
 - yyy = consecutive numbering
 - 001...099 = Kits related to cabinets, for example, adapter plates
 - 001...019 Common AC- and DC-related kits
 - 020...049 Cabinet mechanics kits
 - 050...059 Swing frame kits
 - 100...199 = Kits related to AC connection, for example, busbars
 - 100...129 Kits with connection to AC
 - 130...149 Kits with connection to module
 - 150...199 Other kits related to AC connection
 - 200...299 = Kits related to DC connection, for example, busbars
 - 200...229 Kits with connection to common DC
 - 230...249 Kits with connection to module
 - 250...299 Other kits related to DC connection
 - 300...399 = Kits related to module installation, for example, mechanical supports
 - 300...330 Module supporting kits, basic mechanical support
 - 350...379 Shroud kits
-

- 400...499 = Other kits

400...419	Fan kits
420...439	Air guides
440...459	Cooling circuit kits

- VX = Kit specifically designed for the Rittal VX25 enclosure system. Many kits without this designation are also used with the VX25 system.

Frame R8i and multiples

■ Inverter modules

Inverter units consisting of frame R8i inverter modules are to be ordered as separate modules. For inverter unit ratings, see the technical data.

Inverter unit		Modules used	
Type	Frame size	Qty	Ordering code (for options see below)
$U_N = 690\text{ V}$			
ACS880-104LC-0390A-7	R8i	1	ACS880-104LC-0390A-7+E205
ACS880-104LC-0430A-7	R8i	1	ACS880-104LC-0430A-7+E205
ACS880-104LC-0480A-7	R8i	1	ACS880-104LC-0480A-7+E205
ACS880-104LC-0530A-7	R8i	1	ACS880-104LC-0530A-7+E205
ACS880-104LC-0600A-7	R8i	1	ACS880-104LC-0600A-7+E205
ACS880-104LC-0670A-7	R8i	1	ACS880-104LC-0670A-7+E205
ACS880-104LC-0750A-7	R8i	1	ACS880-104LC-0750A-7+E205
ACS880-104LC-0850A-7	R8i	1	ACS880-104LC-0850A-7+E205
ACS880-104LC-1030A-7	2×R8i	2	ACS880-104LC-0530A-7+E205
ACS880-104LC-1170A-7	2×R8i	2	ACS880-104LC-0600A-7+E205
ACS880-104LC-1310A-7	2×R8i	2	ACS880-104LC-0670A-7+E205
ACS880-104LC-1470A-7	2×R8i	2	ACS880-104LC-0750A-7+E205
ACS880-104LC-1660A-7	2×R8i	2	ACS880-104LC-0850A-7+E205
ACS880-104LC-1940A-7	3×R8i	3	ACS880-104LC-0670A-7+E205
ACS880-104LC-2180A-7	3×R8i	3	ACS880-104LC-0750A-7+E205
ACS880-104LC-2470A-7	3×R8i	3	ACS880-104LC-0850A-7+E205
ACS880-104LC-2880A-7	4×R8i	4	ACS880-104LC-0750A-7+E205
ACS880-104LC-3260A-7	4×R8i	4	ACS880-104LC-0850A-7+E205

Ordering code format	Option codes
[Module type] +code [+code] ... For example, ACS880-104LC-0480A-7 +E205	+E205 : Internal du/dt filtering. Standard with 690 V modules.

Note: The following components are also required to construct a working inverter unit and must be ordered separately:

- An ACS-AP-x control panel is required for the commissioning of an ACS880 drive system, even if the Drive composer PC tool is used. See section ACS-AP-W control panel below.
- Inverter control unit (see section Inverter control unit below)
- Fiber optic cabling from control unit to each inverter module (see section Fiver optic cables below)
- Common mode filters - see section DC-side components
- Quick connector - see section AC-side components



The other parts listed in this chapter for this frame size

- may be required by the application (such as a DC switch/disconnector), or
 - make the installation or use of the module easier.
-

■ Control panel

The control panel is not included with the module but must be ordered separately. One control panel is required for the commissioning of an ACS880 drive system, even if the Drive composer PC tool is used.

The control panel can be flush mounted on the cabinet door with the help of a door mounting kit. For more information on the control panel, see *ACX-AP-x assistant control panels user's manual* (3AUA0000085685 [English]).

Type	Description	Ordering code	Illustration
ACS-AP-W	Control panel with Bluetooth	3AXD50000025965	
DPMP-01	Door mounting kit (IP55)	3AUA0000108878	

The door mounting kit contains:

- front cover
- flat cable (between DDPI-01 board and the panel)
- DDPI-01 board, cover and M4×8 combi screw for the cover
- EMC shield
- control panel mounting platform
- grounding wire
- Ethernet cable (3 m).
- *DPMP-01 mounting platform for ACS-AP control panel installation guide* [3AUA0000100140 (English)].

■ Control electronics

Inverter control unit

One BCU-0x control unit is required per inverter unit. The type of the control unit depends on the number of inverter modules as shown below. The control unit delivered with a memory unit containing the ACS880 primary control program, optionally with application programmability, For availability of other control programs, contact your local ABB representative.

Frame size	Control unit type	Application programmability	Ordering code
R8i, 2×R8i	BCU-02	No	3AXD50000003417
		*Yes	3AXD50000011540
3×R8i...6×R8i	BCU-12	No	3AXD50000006340
		*Yes	3AXD50000011541

*Application programmability using function block based on the IEC 61131-3 standard. For more information, see Programming manual: Drive application programming (IEC 61131-3) (3AUA0000127808 [English]).

Note:

Fiber optic communication with another control unit (such as that of the supply unit) requires an RDCO-0x DDCS communication module. For more information, see *RDCO-0x DDCS communication option modules* (3AFE64492209 [English]).

Fiber optic cables

Each frame R8i module is connected to the inverter control unit with a pair of fiber optic cables.

The following kits, each consisting of a pair of plastic fiber optic cables, are available from ABB:


Length	Kit type designation	Ordering code
2 m	NLWC-02	58988821
3 m	NLWC-03	58948233
5 m	NLWC-05	58948250
7 m	NLWC-07	58948268
10 m	NLWC-10	58948276

■ **Mechanical installation accessories**

These kits include parts that are used for installing the module in the enclosure.




Side plate kit




These parts attach to the left-hand and right-hand sides of the VX25 enclosure frame and act as a mounting base for the module guides.

Used with...	Qty	Ordering code	Kit code	Illustration
400/600/800 mm VX25 enclosure	1	3AXD50000360543	L-468-8-020-VX	 <p data-bbox="1117 1377 1452 1411">Instruction code: 3AXD50000327591</p>

Module top/bottom guides




This kit contains the frames that support the module at the top and the bottom.

Used with...	Qty	Ordering code	Kit code	Illustration
400 mm VX25 enclosure	1	3AXD50000360598	L-4-8-301-VX	 <p data-bbox="965 875 1297 902">Instruction code: 3AXD50000330461</p>
600 mm VX25 enclosure	1	3AXD50000361090	L-6-8-302-VX	 <p data-bbox="965 1373 1297 1400">Instruction code: 3AXD50000330201</p>
800 mm VX25 enclosure	1	3AXD50000361274	L-8-8-303-VX	 <p data-bbox="965 1904 1297 1930">Instruction code: 3AXD50000329502</p>

Used with...	Qty	Ordering code	Kit code	Illustration
400 mm generic enclosure	1	3AXD50000043678	L-4-8-301	 <p data-bbox="1117 658 1452 680">Instruction code: 3AXD50000043726</p>
600 mm generic enclosure	1	3AXD50000041710	L-6-8-302	 <p data-bbox="1117 1196 1452 1218">Instruction code: 3AXD50000041836</p>
800 mm generic enclosure	1	3AXD50000041248	L-8-8-303	 <p data-bbox="1117 1621 1452 1644">Instruction code: 3AXD50000041461</p>



Swing-out frame


The swing-out frame is a hinged compartment that can be used as a mounting base for eg. control electronics and auxiliary voltage circuit components.

Used with...	Qty	Ordering code	Kit code	Illustration
400 mm VX25 enclosure	1	3AXD50000361045	L-4-X-051-VX	 <p>Instruction code: 3AXD50000345106</p>
600 mm VX25 enclosure	1	3AXD50000361250	L6-X-052-VX	 <p>Illustration code: 3AXD50000345069</p>
800 mm VX25 enclosure	1	3AXD50000361410	L-8-X-053-VX	 <p>Instruction code: 3AXD50000344864</p>

Shrouding


This kit contains the shrouds, as well as the necessary brackets and screws, to cover the top and bottom parts of the cubicle.

Frame size	Qty	Ordering code	Kit code	Illustration
400 mm VX25 enclosure	1	3AXD50000361083	L-4-8-022-VX	 <p data-bbox="1118 1014 1455 1039">Instruction code: 3AXD50000353354</p>
600 mm VX25 enclosure	1	3AXD50000361267	L-6-8-023-VX	 <p data-bbox="1118 1646 1455 1671">Instruction code: 3AXD50000353521</p>

Frame size	Qty	Ordering code	Kit code	Illustration
800 mm VX25 enclosure	1	3AXD50000361427	L-8-8-024-VX	 <p>Instruction code: 3AXD50000353125</p>

Lifting device

The lifting device is designed for maneuvering a frame R8i module when installing it into (or extracting it from) the Rittal VX25 enclosure.

Used with...	Qty	Ordering code	Kit code	Illustration
R8i	1	3AXD50000439997	-	 <p>Instruction code: 3AXD50000439409, 3AXD50000210268</p>

■ DC-side components

Frame R8i modules are connected to the DC bus through fuses. The design presented in this manual has flush-end fuse blocks bolted to the DC busbars.

A DC switch/disconnector can be installed if quick isolation of the module from the DC bus is required. One of the auxiliary contacts of the switch is used for monitoring the open/closed state of the switch. A capacitor charging circuit is to be installed with the DC switch/disconnector.

Note:

A separate capacitor charging circuit must be designed and installed by the customer if the inverter unit is directly connected to the DC bus and the supply unit of the system does not have a charging capability.


The common mode filters are mounted onto the busbars that connect to the DC input of the inverter module.

DC bus installation parts (for Rittal VX25 enclosures)

The brackets in this kit act as a mounting base for the busbar supports of the Rittal Flat-PLS DC bus and ensure its correct placement and alignment inside the cabinet line-up.



Note:





The designs presented in this manual for Rittal VX25 enclosures employ the Rittal Flat-PLS busbar system. Make sure that the current carrying capability of the busbars is not exceeded at any point of the drive system.

Used with ...	Qty	Ordering code	Kit code	Illustration
400/600/800 mm VX25 enclosure	1 kit per cubicle	3AXD50000333387	A-468-X-001-VX	 <p data-bbox="1219 1055 1410 1106">Instruction code: 3AXD50000333639</p>





DC connection parts 1 of 2 (for Rittal VX25 enclosures)



These parts connect the Flat-PLS busbars to the DC fuses.

Used with...	Qty	Ordering code	Kit code	Illustration
400 mm VX25 enclosure without DC switch	1	3AXD50000360604	L-4-8-201-VX	 <p data-bbox="965 958 1297 981">Instruction code: 3AXD50000332861</p>
	1	3AXD50000361021	L-4-8-251-VX	 <p data-bbox="965 1377 1297 1400">Instruction code: 3AXD50000332885</p>

Used with...	Qty	Ordering code	Kit code	Illustration
400 mm VX25 enclosure with DC switch	1	3AXD50000361038	L-4-8-254-VX	 <p data-bbox="1118 712 1453 734">Instruction code: 3AXD50000342600</p>
	1	3AXD50000360567	L-46-8-207-VX	 <p data-bbox="1118 1294 1453 1317">Instruction code: 3AXD50000343614</p>
600 mm VX25 enclosure without DC switch	1	3AXD50000361106	L-6-8-202-VX	 <p data-bbox="1118 1646 1453 1668">Instruction code: 3AXD50000332229</p>
	1	3AXD50000361229	L-6-8-252-VX	 <p data-bbox="1118 2016 1453 2038">Instruction code: 3AXD50000332106</p>




130 Ordering information

Used with...	Qty	Ordering code	Kit code	Illustration
600 mm VX25 enclosure with DC switch	1	3AXD50000361243	L-6-8-255-VX	 <p>Instruction code: 3AXD50000338740</p>
	2	3AXD50000360567	L-46-8-207-VX	 <p>Instruction code: 3AXD50000343614</p>
800 mm VX25 enclosure without DC switch	1	3AXD50000361281	L-8-8-203-VX	 <p>Instruction code: 3AXD50000331567</p>
	1	3AXD50000361298	L-8-8-253-VX	 <p>Instruction code: 3AXD50000331765</p>

Used with...	Qty	Ordering code	Kit code	Illustration
800 mm VX25 enclosure with DC switch	1	3AXD50000361304	L-8-8-256-VX	 <p data-bbox="1121 600 1444 622">Instruction code: 3AXD50000336999</p>
	1	3AXD50000360574	L-8-8-208-VX	 <p data-bbox="1121 1014 1444 1037">Instruction code: 3AXD50000344185</p>

DC connection parts 1 of 2 (for generic enclosures)

These parts provide the DC connection between the DC input (busbars or otherwise) and the DC fuses.

Used with...	Qty	Ordering code	Kit code	Illustration
400 mm generic enclosure	1	3AXD50000043679	L-4-8-251	 <p>Instruction code: 3AXD50000043729</p>
600 mm generic enclosure	1	3AXD50000041731	L-6-8-252	 <p>Instruction code: 3AXD50000041842</p>
800 mm generic enclosure	1	3AXD50000041263	L-8-8-253	 <p>Instruction code: 3AXD50000041448</p>

DC switch/disconnector kits (for Rittal VX25 enclosures)

Used with...	Switch type Handle type	Qty	Ordering code	Instruction code
Frame R8i with DC switch/disconnector	OT1600E11 OHB150J12P	1	3AXD50000227037	3AXD50000330720
Frame 2×R8i with DC switch/disconnector	OT1600E22 OHB274J12	1	3AXD50000227044	
Frame 3×R8i with DC switch/disconnector	OT2500E22 OHB274J12	1	3AXD50000227051	

The kit contains the following components:

- DC switch (type indicated in table)
- Operating handle (type indicated in table)
- OXP12X395 operating shaft
- OA1G10 and OA3G01 auxiliary contacts
- OTZT4A and PDAL2/24DC interlocks
- OHZX10 alignment ring.

DC charging kits (for units with DC switch/disconnector)

Used with...	Switch type	Qty	Ordering code	Instruction code
Frames R8i and 2×R8i with DC switch/disconnector	OS160GD04F	1	3AXD50000226801	3AXD50000450978
Frame 3×R8i with DC switch/disconnector	OS200DZ22F	1	3AXD50000227020	

The kit contains the following components:

- Charging switch (type indicated in table) with terminal shrouds
 - OHB65J6 operating handle
 - OXP6X290 operating shaft
 - 2 pcs of OA3G01 auxiliary contacts
 - BSFC-12C charging controller
 - 170M2676 fuses
 - OHZX10 alignment ring.
-

Note: Charging resistors are not included in the kit and must be ordered separately.

Charging resistors (for units with DC switch/disconnector)



Used with...	Qty	Ordering code	Type
Frame R8i with DC switch/disconnector	4	10028531	ZRF 30/165 S 33R
Frame 2×R8i with DC switch/disconnector	6		
Frame 3×R8i with DC switch/disconnector	8		


DC fuses (IEC)

Unit type ACS880- 104LC-	Qty	Ordering code	Fuse		
			Type (Bussmann)	Data	Size
0390A-7	2	63919128	170M6546	800 A, 1250 V	3
0430A-7	2	63919128	170M6546	800 A, 1250 V	3
0480A-7	2	63919381	170M6547	900 A, 1100 V	3
0530A-7	2	63916749	170M6548	1000 A, 1100 V	3
0600A-7	2	68736021	170M6549	1100 A, 1000 V	3
0670A-7	2	63919462	170M6500	1250 A, 1100 V	3*
0750A-7	2	3AUA0000086673	170M6501	1400 A, 1100 V	3*
0850A-7	2	3AUA0000086673	170M6501	1400 A, 1100 V	3*
1030A-7	4	63916749	170M6548	1000 A, 1100 V	3
1170A-7	4	68736021	170M6549	1100 A, 1000 V	3
1310A-7	4	63919462	170M6500	1250 A, 1100 V	3*
1470A-7	4	3AUA0000086673	170M6501	1400 A, 1100 V	3*
1660A-7	4	3AUA0000086673	170M6501	1400 A, 1100 V	3*
1940A-7	6	63919462	170M6500	1250 A, 1100 V	3*
2180A-7	6	3AUA0000086673	170M6501	1400 A, 1100 V	3*
2470A-7	6	3AUA0000086673	170M6501	1400 A, 1100 V	3*
2880A-7	8	3AUA0000086673	170M6501	1400 A, 1100 V	3*
3260A-7	8	3AUA0000086673	170M6501	1400 A, 1100 V	3*

DC connection parts 2 of 2 (for Rittal VX25 or generic enclosures)

These parts connect the DC fuses to the inverter module.

Used with	Qty	Ordering code	Kit code	Illustration
All VX25 and generic enclosures (without DC switch)	1 per module	3AXD50000041264	L-468-8-230	 <p data-bbox="1118 875 1453 898">Instruction code: 3AXD50000041311</p> <p data-bbox="1254 927 1318 949">Note:</p> <p data-bbox="1134 965 1437 987">Filters to be ordered separately</p>
400 mm and 600 mm VX25 enclosures (with DC switch)	1 per module	3AXD50000200368	L-46-8-233	 <p data-bbox="1118 1473 1453 1496">Instruction code: 3AXD50000205042</p> <p data-bbox="1254 1525 1318 1547">Note:</p> <p data-bbox="1134 1563 1437 1585">Filters to be ordered separately</p>

Used with	Qty	Ordering code	Kit code	Illustration
800 mm VX25 enclosures (with DC switch)	3	3AXD50000200337	L-8-8-234	 <p>Instruction code: 3AXD50000205226</p> <p>Note: Filters to be ordered separately</p>


Common mode filters

Common mode filtering reduces bearing currents and is required for electromagnetic compatibility (EMC). The filtering is implemented by installing two toroidal cores onto the DC busbars.

Used with	Qty	Ordering code	Kit code	Illustration
All enclosure types	2 per mod- ule	3AUA0000032859	-	 <p>Instruction code: 3AXD50000005734</p>


■ AC-side components

Quick connector




Used with	Qty	Ordering codes	Kit code	Illustration
All enclosure types	1 per module	3AUA0000119227	A-468-8-100	 <p>Instruction code: 3AUA0000118667</p>

Output busbars

This kit contains busbars that attach to the quick connector, and the terminals for the motor cables. Note that the kits for multiple modules have no built-in interconnections, so each module in the same cubicle must be separately (and identically) cabled to the motor.


Used with	Qty	Ordering code	Kit code	Illustration
400/600/800 mm VX25 enclosure	1 per module	3AXD50000360550	L-468-8-131-VX	 <p>Instruction code: 3AXD50000330874</p>

138 Ordering information

Used with	Qty	Ordering code	Kit code	Illustration
400 mm generic enclosure	1	3AXD50000043691	L-4-8-131	 <p data-bbox="965 929 1292 952">Instruction code: 3AXD50000043742</p>
600 mm generic enclosure	1	3AXD50000041733	L-6-8-132	 <p data-bbox="965 1456 1292 1478">Instruction code: 3AXD50000041888</p>
800 mm generic enclosure	1	3AXD50000041734	L-8-8-133	 <p data-bbox="965 1937 1292 1960">Instruction code: 3AXD50000041909</p>



Cable entry kit

Cable entry kit, to be installed on the bottom plate of the enclosure, contains four 60 mm diameter inlets for cables with grommets, wire meshing for 360° grounding, and a strain relief bracket.


Used with ...	Qty	Ordering code	Kit code	Illustration
All enclosure types	1 (minimum) kit for a module	3AXD5000004385	A-468-8-441	 <p>Instruction code: 3AXD5000004817</p>

■ Cooling system parts

Coolant distribution manifold kits

Enclosure	Qty	Ordering code	Kit code	Illustration
400 mm VX25 and generic enclosure (1 module)	1	3AXD50000044084	L-468-8-441	 <p>Instruction code: 3AXD50000048217</p>
600 mm VX25 and generic enclosure (2 modules)	1	3AXD50000044182	L-468-8-442	 <p>Instruction code: 3AXD50000048258</p>


140 Ordering information

Enclosure	Qty	Ordering code	Kit code	Illustration
800 mm VX25 and generic enclosure (3 modules)	1	3AXD50000048136	L-468-8-443	 <p>Instruction code: 3AXD50000048283</p>


The manifold kits contain:



Inlet and outlet manifolds



Inlet and outlet valves



Drain valves



Nipples for connecting the valves to manifolds



Connectors for PA piping



Plugs for unused piping connectors



Chokes for flow limitation – not used with the ACS880-104LC.

You must order the following parts separately as they are not included in the manifold kits:

- Connectors to attach to inlet, outlet and drain valves
- Connectors to attach to main pipes
- Pipes between main pipe and inlet/outlet valves
- Main pipes
- Drain pipes

Note:

The inlet and outlet valves have an R3/4" internal thread. The drain valves have an R3/8" internal thread.


Piping

The PA (polyamide) pipe can be used for all piping inside the cubicle between the manifolds.


Component		Ordering code
PA pipe	Data	
PA pipe	50 m, PA12P40, 16/13 mm	3AXD50000047488

Note:

The piping between the manifolds and main pipes (1), and drain pipes (2) are not part of the offering.




Heat exchanger

Used with ...	Qty	Ordering code	Kit code	Illustration
All enclosure types	1 per module	3AXD50000041265	L-468-8-440	

Cooling fan

The fan blows air through the heat exchanger, circulating the air inside the cabinet. The kit contains the fan installed into its cowling which mounts to the module bottom guide.

The fan is selected according to the auxiliary voltage.

Auxiliary voltage	Qty	Ordering code	Illustration
230 V AC (50/60 Hz)	1 / module	3AXD50000043886	
115 V AC (50/60 Hz)	1 / module	3AXD50000045414	

Miscellaneous

■ CIO-01 I/O module

CIO-01 I/O module for distributed I/O bus control is not included in the module delivery but must be ordered separately. The distributed I/O bus controls and supervises each cabinet fan separately. It indicates malfunctioning fans by warning or fault messages.

For more information, see *CIO-01 I/O module for distributed I/O bus control* (3AXD50000126880 [English]).

Type	Data	Qty	Ordering code
CIO-01	CIO-01 I/O module for distributed I/O bus control	1	3AXD50000041983

10

Internal cooling circuit

Contents of this chapter

The cooling system of a liquid-cooled drive consists of two circuits: the internal cooling circuit and the external cooling circuit. The internal cooling circuit covers the heat-generating electrical components of the drive and transfers the heat to the cooling unit. In the cooling unit, the heat is transferred to the external cooling circuit which is usually part of a larger external cooling system. This chapter deals with the internal cooling circuit.

Applicability

The information in this chapter is applicable to cabinet-built ACS880 liquid-cooled drives. Except where otherwise indicated, the information is also applicable to drives built out of ACS880 liquid-cooled multidrive modules.


Internal cooling system

Note: This section describes cabinet-built, liquid-cooled ACS880 drives. The information in this section can be used as guidelines for building a drive system out of ACS880 liquid-cooled modules.

Each cubicle has an inlet and an outlet manifold, fitted with a stop valve and a drain valve. The stop valves can be closed to isolate all modules in the cubicle from the main cooling circuit.

The following diagram shows the coolant pipe connections in a drive system consisting of a supply unit and an inverter unit.

144 Internal cooling circuit



The coolant used with ACS880 liquid-cooled drive systems is Antifrogen® L 25% or 50% water mixture. See [Coolant specification \(page 148\)](#).

Connection to a cooling unit

■ Connection to an ACS880-1007LC cooling unit

Refer to *ACS880-1007LC cooling unit user's manual* (3AXD50000129607 [English]).

■ Connection to a custom cooling unit

General requirements

Equip the system with an expansion tank to damp pressure rise due to volume changes when the temperature varies. Equip the system with a pump that provides a nominal flow and pressure. Keep the pressure within the limits specified in *Technical data (page 148)*. Install a pressure regulator to make sure that the maximum permissible operating pressure is not exceeded.

Install a bleed valve at the highest point of the cooling circuit, and a drain valve at the lowest point.

The materials that can be used are listed in *Cooling circuit materials (page 150)*.

Coolant temperature control

The temperature of the coolant in the internal cooling circuit must be kept within the limits specified in *Technical data (page 148)*. Note that the minimum temperature is dependent on ambient temperature and relative humidity.

Filling up and bleeding the internal cooling circuit

Both the drive and coolant must be at room temperature before filling up the cooling circuit.



WARNING!

Make sure that the maximum permissible operating pressure is not exceeded. When necessary regulate the pressure to appropriate level by draining excess coolant out of the system.



WARNING!

Bleeding of the cooling circuit is very important and has to be done with great care. Air bubbles in the cooling circuit may reduce or completely block coolant flow and lead to overheating. Let the air out of the cooling system while filling in coolant and, eg. after any power module replacements.

■ Drive line-ups with an ACS880-1007LC cooling unit

Follow the filling up and bleeding instructions in *ACS880-1007LC cooling unit user's manual* (3AXD50000129607 [English]).

■ Drive line-ups with a custom cooling unit

Note:

- In filling up the system, the drain valves in the line-up are used only to vent the air from the circuit so that it can be displaced by the coolant. The actual bleeding of the circuit must be done via an external bleed valve installed at the highest point of the cooling circuit. The most practical location for the valve is usually near or at the cooling unit.
- Observe the instructions given by the manufacturer of the cooling unit. Pay special attention to filling up and bleeding the pumps properly as they may be damaged if operated when dry.
- Draining coolant into the sewer system is not allowed.

1. Open the bleed valve at the cooling unit.
2. Open the inlet valve and the outlet-side drain valve of one cubicle. Keep the outlet valve and the inlet-side drain valve closed.
3. Attach a hose to the outlet-side drain valve and lead it into a suitable container.
4. Fill the circuit with coolant. For coolant specification, see [Coolant specification \(page 148\)](#).

Note: To minimize foaming, do not exceed the filling flow rate of 5 l/min (1.3 US gallon/min).

5. As the piping and modules in the cubicle fills up, coolant starts to flow from the hose. Let some coolant flow out, then close the drain valve.
 6. Close the inlet valve.
 7. Repeat steps 2 to 6 for all cubicles in the line-up.
 8. Open the inlet and outlet valves in all cubicles. Let any air remaining in the system out through the bleed valve at the cooling unit.
 9. Close the bleed valve at the cooling unit.
 10. Continue to fill in coolant until a base pressure of 100...150 kPa is achieved.
 11. Open the bleed valve of the pump to let out any air.
 12. Re-check the pressure and add coolant if necessary.
-

13. Start the coolant pump. Let any air remaining in the system out through the bleed valve at the cooling unit.
 14. After one to two minutes, stop the pump or block the coolant flow with a valve.
 15. Re-check the pressure and add coolant if necessary.
 16. Repeat steps 13 to 15 a few times until all air is let out of the cooling circuit. Listen for a humming sound and/or feel the piping for vibration to find out if there is still air left in the circuit.
-

Draining the internal cooling circuit

The modules in each cubicle can be drained through the drain valves without draining the whole internal cooling circuit.



WARNING!

Hot, pressurized coolant can be present in the cooling circuit. Do not work on the cooling circuit before the pressure is released by stopping the pumps and draining coolant.

1. Attach hoses to each drain valve in the cubicle to be drained. Lead the hoses into a suitable container. Make sure the ends of the hoses are not immersed in coolant at any point so that air can displace the coolant in the system.
2. Open the drain valves. Wait until all coolant has drained.

Note: Draining coolant into the sewer system is not allowed.

3. If required, dry the piping with compressed oil-free air of less than 6 bar.
4. If the drive is to be stored in temperatures below 0 °C (32 °F),
 - dry the cooling circuit with air,
 - fill the cooling circuit with coolant specified under *Coolant specification (page 148)*.
 - drain the cooling circuit again.

Maintenance intervals

As a general rule, the quality of the coolant should be checked at intervals of two years. This can be done by distributors of Antifrogen® L (see www.clariant.com) if a 250 milliliter sample is provided.

Technical data

■ Coolant specification

Coolant type

Antifrogen® L (by Clariant International Ltd, www.clariant.com) 25% or 50% water mixture, available from Clariant distributors and ABB Service representatives.

Antifrogen® L 25% mixture is usable in storage temperatures down to -16 °C (3.2 °F).

Antifrogen® L 50% mixture is usable in storage temperatures down to -40 °C (-40 °F).

Note that operation below 0 °C (32 °F) is not allowed regardless of the freezing point of the coolant.



WARNING!

The warranty does not cover damage occurring from use of improper coolant.


■ Temperature limits

Ambient temperature: See the technical data of the drive/unit.

Freeze protection: The freezing point of the coolant is determined by the concentration of heat transfer fluid in the mixture.

The higher the concentration of heat transfer fluid, the higher the viscosity of the coolant. This results in a higher pressure loss in the system. See *Pressure limits (page 150)*.


The nominal current ratings of drive system modules apply to an Antifrogen® L / water solution of 25/75% (volume). With the Antifrogen® L concentration between 25% and 50%, the drive output current must be derated by 1/3 percentage point per 1 p.p. increase in Antifrogen® L concentration. The drawing below shows the derating factor (*k*) in relation to Antifrogen® L concentration.



Incoming coolant temperature:

- 0...40 °C (32...104 °F): no drive output current derating required
- 40...45 °C (104...113 °F): drive output current must be derated by 2 percentage points per 1 °C (1.8 °F) temperature increase, as shown by curve (a).
- 45...50 °C (113...122 °F):
 - If components with a maximum operating temperature of 55 °C (131 °F) are installed in the same space as the drive modules, drive output current must be derated by 6 percentage points per 1 °C (1.8 °F) temperature increase, as shown by curve (c).
 - If there are no components with a maximum operating temperature of 55 °C (131 °F) installed in the same space as the drive modules, drive output current must be derated by 2 percentage points per 1 °C (1.8 °F) temperature increase, as shown by curve (b).

The drawing below shows the derating factor (*k*) in relation to coolant temperature.



Condensation is not allowed. The minimum coolant temperature to avoid condensation (at an atmospheric pressure of 1 bar) is shown below as a function of relative humidity (RH) and ambient temperature (T_{air}).

T_{air} (°C)	Min. $T_{coolant}$ (°C)				
	RH = 95%	RH = 80%	RH = 65%	RH = 50%	RH = 40%
5	4.3	1.9	-0.9	-4.5	-7.4

T_{air} (°C)	Min. T_{coolant} (°C)				
	RH = 95%	RH = 80%	RH = 65%	RH = 50%	RH = 40%
10	9.2	6.7	3.7	-0.1	-3.0
15	14.2	11.5	8.4	4.6	1.5
20	19.2	16.5	13.2	9.4	6.0
25	24.1	21.4	17.9	13.8	10.5
30	29.1	26.2	22.7	18.4	15.0
35	34.1	31.1	27.4	23.0	19.4
40	39.0	35.9	32.2	27.6	23.8
45	44.0	40.8	36.8	32.1	28.2
50	49.0	45.6	41.6	36.7	32.8
55	53.9	50.4	46.3	42.2	37.1
	= Not allowed as standard but the coolant temperature must be 0 °C (32 °F) or above.				
Example:	At an air temperature of 45 °C and relative humidity of 65% the coolant temperature may not be below +36.8 °C				

Maximum temperature rise: Depends on heat losses and mass flow. Typically 10 °C (18 °F) with nominal losses and flow.

■ Pressure limits

Base pressure: 100 ... 150 kPa (recommended); 200 kPa (maximum). “Base pressure” denotes the pressure of the system compared with the atmospheric pressure when the cooling circuit is filled with coolant.

Air counterpressure in the expansion tank: 40 kPa

Design pressure (PS): 600 kPa

Nominal pressure difference (between main in/out lines): 120 kPa with 25/75% (volume) coolant solution, 150 kPa with 50/50% (volume) coolant solution. This has to be taken into account when dimensioning the liquid cooling circuit.

Maximum pressure difference (between main in/out lines): 200 kPa

■ Coolant flow rate limits

The maximum coolant flow rate for all drive equipment is 1.3 × nominal. See the technical data chapter for nominal values.

■ Cooling circuit materials

Materials used in the internal cooling circuit are listed below. These are also the only materials that can be used in the external cooling circuit.

- stainless steel AISI 316L (UNS 31603)
- heavy gauge aluminum
- plastic materials such as PA, PEX and PTFE

Note: PVC hoses are not suitable for use with antifreeze.


- rubber gasketing NBR (nitrile rubber).



WARNING!

If connecting external piping to the internal cooling circuit, use only materials that are specified above. Copper, brass or bronze must not be used under any circumstances. Even minor dissolution of copper can cause copper precipitation on aluminum and subsequent galvanic corrosion. The liquid cooling system must not contain any zinc (eg. galvanized pipes).

If the plant incorporates normal iron pipes or cast iron accessories (eg. motor housings), a cooling unit with a heat exchanger (such as the ACS880-1007LC) must be used to separate the systems.





11

Technical data

Contents of this chapter

This chapter contains the technical specifications of the inverter modules and associated components.

Ratings

Inverter unit type ACS880-104LC-	Frame size	Input ratings		Output ratings						
		I_1	I_{max}	No-overload use			Light-overload use		Heavy-duty use	
				I_2	P_N	S_N	I_{Ld}	P_{Ld}	I_{Hd}	P_{Hd}
		A	A	A	kW	kVA	A	kW	A	kW
$U_N = 690 \text{ V}$										
0390A-7	R8i	439	590	390	355	466	374	355	292	250
0430A-7	R8i	484	650	430	400	514	413	355	322	250
0480A-7	R8i	540	720	480	450	574	461	400	359	315
0530A-7	R8i	596	800	530	500	633	509	450	396	355
0600A-7	R8i	675	900	600	560	717	576	560	449	400
0670A-7	R8i	754	1010	670	630	801	643	630	501	450
0750A-7	R8i	844	1130	750	710	896	720	710	561	500
0850A-7	R8i	956	1280	850	800	1016	816	800	636	560
1030A-7	2×R8i	1159	1550	1030	1000	1231	989	900	770	710
1170A-7	2×R8i	1316	1760	1170	1100	1398	1123	1100	875	800
1310A-7	2×R8i	1474	1970	1310	1200	1566	1258	1200	980	900
1470A-7	2×R8i	1654	2210	1470	1400	1757	1411	1200	1100	1000
1660A-7	2×R8i	1868	2490	1660	1600	1984	1594	1400	1242	1200
1940A-7	3×R8i	2183	2910	1940	1800	2319	1862	1800	1451	1400
2180A-7	3×R8i	2453	3270	2180	2000	2605	2093	2000	1631	1400
2470A-7	3×R8i	2779	3710	2470	2300	2952	2371	2300	1848	1800
2880A-7	4×R8i	3240	4320	2880	2700	3442	2765	2700	2154	2000
3260A-7	4×R8i	3668	4890	3260	3000	3896	3130	3000	2438	2300

■ Definitions

U_N	Nominal AC supply voltage of drive system
I_1	Nominal rms input current
I_2	Nominal output current (available continuously with no over-loading)
P_N	Typical motor power in no-overload use The horsepower ratings are typical NEMA motor sizes at 460 V (ACS880-104LC-xxxxA-5) and 575 V (ACS880-104LC-xxxxA-7) respectively.
S_N	Apparent power in no-overload use
I_{Ld}	Continuous rms output current allowing 10% overload for 1 minute every 5 minutes
P_{Ld}	Typical motor power in light-overload use

I_{max}	Maximum output current. Available for 10 seconds at start; otherwise as long as allowed by drive temperature.
I_{Hd}	Continuous rms output current allowing 50% overload for 1 minute every 5 minutes
P_{Hd}	Typical motor power in heavy-duty use


Note:

- The ratings apply at an ambient temperature of 40 °C (104 °F).
- The ratings apply at an ambient temperature of 45 °C (113 °F) and a coolant temperature of 40 °C (104 °F).
- To achieve the rated motor power given in the table, the rated current of the drive must be higher than or equal to the rated motor current.
- The DriveSize dimensioning tool available from ABB is recommended for selecting the drive, motor and gear combination.

Derating


■ Supply voltage derating

If the DC supply voltage of the inverter module (U_1) is below 810 V (which corresponds to a drive supply voltage of 600 V AC when a diode supply unit is used), the rated output current must be derated by multiplying by $U_1/810$ (represented by k in the diagram).



■ Ambient temperature derating

In the temperature range +45...55 °C (+113...131 °F), the rated output current is derated by 0.5 percentage points for every added 1 °C (1.8 °F). The output current can be calculated by multiplying the current given in the rating table by the derating factor (k):



■ Coolant temperature derating

See section [Temperature limits \(page 148\)](#).

■ **Antifreeze content derating**

See section *Temperature limits (page 148)*.

■ **Altitude derating**

At altitudes from 1000 to 4000 m (3281 to 13123 ft) above sea level, the output current derating is 1 percentage point for every added 100 m (328 ft). For example, the derating factor for 1500 m (4921 ft) is 0.95.

For a more accurate derating, use the DriveSize PC tool.

■ **Switching frequency derating**

In the switching frequency range of 3.0 to 7.5 kHz, the output current is derated by 8 percentage points per each kHz. For example, the derating factor for 5 kHz is 0.84.

■ **Output frequency derating**

Below the output frequency of 12 Hz, the output current is derated by 3.5 percentage points per each Hz. For example, the derating factor for 9 Hz is 0.895.

Above the output frequency of 150 Hz, the output current is derated by 1 percentage point per each 10 Hz. For example, the derating factor for 175 Hz is 0.975.

Cooling characteristics

Inverter unit type ACS880-104LC-	Power loss		Coolant volume		Coolant flow rate	Pressure loss
	into coolant	into air surrounding cabinet	modules + heat exchangers	cabinet piping		
	W	W	l (US qt)	l (US qt)	l/min (US gal/min)	kPa
$U_N = 690 \text{ V}$						
0390A-7	5000	100	1.9 (2.0)	2.4 (2.5)	16 (4.2)	120
0430A-7	5500	100	1.9 (2.0)	2.4 (2.5)	16 (4.2)	120
0480A-7	6200	200	1.9 (2.0)	2.4 (2.5)	16 (4.2)	120
0530A-7	7000	200	1.9 (2.0)	2.4 (2.5)	16 (4.2)	120
0600A-7	8000	200	1.9 (2.0)	2.4 (2.5)	16 (4.2)	120
0670A-7	9200	200	1.9 (2.0)	2.4 (2.5)	16 (4.2)	120
0750A-7	10500	300	1.9 (2.0)	2.4 (2.5)	16 (4.2)	120
0850A-7	12400	300	1.9 (2.0)	2.4 (2.5)	16 (4.2)	120
1030A-7	13600	300	3.8 (4.0)	4.0 (4.2)	32 (8.5)	120
1170A-7	15600	400	3.8 (4.0)	4.0 (4.2)	32 (8.5)	120
1310A-7	17900	500	3.8 (4.0)	4.0 (4.2)	32 (8.5)	120
1470A-7	20600	500	3.8 (4.0)	4.0 (4.2)	32 (8.5)	120
1660A-7	24200	600	3.8 (4.0)	4.0 (4.2)	32 (8.5)	120
1940A-7	26500	700	5.7 (6.0)	5.7 (6.0)	48 (12.5)	120
2180A-7	30600	800	5.7 (6.0)	5.7 (6.0)	48 (12.5)	120
2470A-7	36000	900	5.7 (6.0)	5.7 (6.0)	48 (12.5)	120
2880A-7	40400	1000	7.6 (8.0)	8.0 (8.5)	64 (17)	120
3260A-7	47500	1200	7.6 (8.0)	8.0 (8.5)	64 (17)	120

Modules used, noise, DC capacitance

Inverter unit type ACS880-104LC-	Inverter modules used		Noise level*	DC capacitance
	Qty	Type ACS880-104LC-	dB(A)	μF
$U_N = 690 \text{ V}$				
0390A-7	1	0390A-7	63	6000
0430A-7	1	0430A-7	63	6000
0480A-7	1	0480A-7	63	6000
0530A-7	1	0530A-7	63	6000
0600A-7	1	0600A-7	63	9000
0670A-7	1	0670A-7	63	9000
0750A-7	1	0750A-7	63	9000
0850A-7	1	0850A-7	63	9000
1030A-7	2	0530A-7	66	12000
1170A-7	2	0600A-7	66	18000
1310A-7	2	0670A-7	66	18000
1470A-7	2	0750A-7	66	18000
1660A-7	2	0850A-7	66	18000
1940A-7	3	0670A-7	68	27000
2180A-7	3	0750A-7	68	27000
2470A-7	3	0850A-7	68	27000
2880A-7	4	0750A-7	69	36000
3260A-7	4	0850A-7	69	36000

*Measured in a typical ABB (ACS880-107LC) cabinet installation.

Dimensions and weights

The weights of the ACS880-104LC modules are shown below. For the dimensions, see chapter Dimension drawings.

Module type	Weight	
	kg	lbs
ACS880-104LC-0390A-7 ... -0530A-7	59	130
ACS880-104LC-0600A-7 ... -0850A-7	63	139

Free space requirements

- Left and right sides, front and back: None
- Below: Space needed by heat exchanger and cooling fan.
- Above: The cooling air flow through the module should not be restricted.

For an example, see layout drawings.

Allowable mounting orientations

Frame R8i module:

- Upright
 - On left-hand side (viewed from the front)
-

Typical power cable sizes

The tables below give current carrying capacity (I_{Lmax}) for aluminum and copper PVC/XLPE insulated cables. A correction factor $K = 0.70$ is used. Time const is the temperature time constant of the cable.

The cable sizing is based on max. 9 cables laid on the cable trays side by side, three ladder type trays one on top of the other, ambient temperature 30 °C (EN 60204-1 and IEC 60364-5-52).

Aluminum cable		PVC insulation Conductor temperature 70°		XLPE insulation Conductor temperature 90°	
Size	∅ [mm]	I_{Lmax} [A]	Time const. [s]	I_{Lmax} [A]	Time const. [s]
3 × 35 + 10 Cu	26	67	736	84	669
3 × 50 + 15 Cu	29	82	959	102	874
3 × 70 + 21 Cu	32	105	1182	131	1079
3 × 95 + 29 Cu	38	128	1492	159	1376
3 × 120 + 41 Cu	41	148	1776	184	1637
3 × 150 + 41 Cu	44	171	2042	213	1881
3 × 185 + 57 Cu	49	196	2422	243	2237
3 × 240 + 72 Cu	54	231	2967	286	2740
3 × 300 + 88 Cu	58	267	3478	330	3229
2 × (3 × 70 + 21 Cu)	2 × 32	210	1182	262	1079
2 × (3 × 95 + 29 Cu)	2 × 38	256	1492	318	1376
2 × (3 × 120 + 41 Cu)	2 × 41	297	1776	368	1637
2 × (3 × 150 + 41 Cu)	2 × 44	343	2042	425	1881
2 × (3 × 185 + 57 Cu)	2 × 49	392	2422	486	2237
2 × (3 × 240 + 72 Cu)	2 × 54	462	2967	572	2740
2 × (3 × 300 + 88 Cu)	2 × 58	533	3478	659	3229
3 × (3 × 150 + 41 Cu)	3 × 44	514	2042	638	1881
3 × (3 × 185 + 57 Cu)	3 × 49	588	2422	728	2237
3 × (3 × 240 + 72 Cu)	3 × 54	693	2967	859	2740
3 × (3 × 300 + 88 Cu)	3 × 58	800	3478	989	3229
4 × (3 × 185 + 57 Cu)	4 × 49	784	2422	971	2237
4 × (3 × 240 + 72 Cu)	4 × 54	924	2967	1145	2740
4 × (3 × 300 + 88 Cu)	4 × 58	1067	3478	1319	3229
5 × (3 × 185 + 57 Cu)	5 × 49	980	2422	1214	2237
5 × (3 × 240 + 72 Cu)	5 × 54	1155	2967	1431	2740
5 × (3 × 300 + 88 Cu)	5 × 58	1333	3478	1648	3229
6 × (3 × 240 + 72 Cu)	6 × 54	1386	2967	1718	2740
6 × (3 × 300 + 88 Cu)	6 × 58	1600	3478	1978	3229
7 × (3 × 240 + 72 Cu)	7 × 54	1617	2967	2004	2740
7 × (3 × 300 + 88 Cu)	7 × 58	1867	3478	2308	3229
8 × (3 × 240 + 72 Cu)	8 × 54	1848	2967	2290	2740
8 × (3 × 300 + 88 Cu)	8 × 58	2133	3478	2637	3229
9 × (3 × 240 + 72 Cu)	9 × 54	2079	2967	2577	2740
9 × (3 × 300 + 88 Cu)	9 × 58	2400	3478	2967	3229
10 × (3 × 240 + 72 Cu)	10 × 54	2310	2967	2867	2740
10 × (3 × 300 + 88 Cu)	10 × 58	2667	3478	3297	3229

Copper cable		PVC insulation Conductor temperature 70°		XLPE insulation Conductor temperature 90°	
Size	∅ [mm]	I_{Lmax} [A]	Time const. [s]	I_{Lmax} [A]	Time const. [s]
3 × 1.5 + 1.5	13	13	85	16	67
3 × 2.5 + 2.5	14	18	121	23	88
(3 × 4 + 4)	16	24	175	30	133
3 × 6 + 6	18	30	251	38	186
3 × 10 + 10	21	42	359	53	268
3 × 16 + 16	23	56	514	70	391
3 × 25 + 16	24	71	791	89	598
3 × 35 + 16	26	88	1000	110	760
3 × 50 + 25	29	107	1308	134	990
3 × 70 + 35	32	137	1613	171	1230
3 × 95 + 50	38	167	2046	209	1551
3 × 120 + 70	41	193	2441	241	1859
3 × 150 + 70	44	223	2820	279	2139
3 × 185 + 95	50	255	3329	319	2525
3 × 240 + 120	55	301	4073	376	3099
3 × 300 + 150	58	348	4779	435	3636
2 × (3 × 70 + 35)	2 × 32	274	1613	342	1230
2 × (3 × 95 + 50)	2 × 38	334	2046	418	1551
2 × (3 × 120 + 70)	2 × 41	386	2441	482	1859
2 × (3 × 150 + 70)	2 × 44	446	2820	558	2139
2 × (3 × 185 + 95)	2 × 50	510	3329	638	2525
2 × (3 × 240 + 120)	2 × 55	602	4073	752	3099
2 × (3 × 300 + 150)	2 × 58	696	4779	869	3636
3 × (3 × 120 + 70)	3 × 41	579	2441	723	1859
3 × (3 × 150 + 70)	3 × 44	669	2820	837	2139
3 × (3 × 185 + 95)	3 × 50	765	3329	957	2525
3 × (3 × 240 + 120)	3 × 55	903	4073	1128	3099
3 × (3 × 300 + 150)	3 × 58	1044	4779	1304	3636
4 × (3 × 150 + 70)	4 × 44	892	2820	1116	2139
4 × (3 × 185 + 95)	4 × 50	1020	3329	1276	2525
4 × (3 × 240 + 120)	4 × 55	1204	4073	1504	3099
4 × (3 × 300 + 150)	4 × 58	1391	4779	1304	3636
5 × (3 × 185 + 95)	5 × 50	1275	3329	1595	2525
5 × (3 × 240 + 120)	5 × 55	1505	4073	1880	3099
5 × (3 × 300 + 150)	5 × 58	1739	4779	2173	3636
6 × (3 × 185 + 95)	6 × 50	1530	3329	1914	2525
6 × (3 × 240 + 120)	6 × 55	1806	4073	2256	3099
6 × (3 × 300 + 150)	6 × 58	2087	4779	2608	3636
7 × (3 × 240 + 120)	7 × 55	2107	4073	2632	3099
7 × (3 × 300 + 150)	7 × 58	2435	4779	3043	3636
8 × (3 × 240 + 120)	8 × 55	2408	4073	3008	3099
8 × (3 × 300 + 150)	8 × 58	2783	4779	3477	3636

Input power (DC) connection

Voltage (U_1)	ACS880-104LC-xxxx-7: 709...976 V DC. This is indicated in the type designation label as typical input voltage levels (742/849/976 V DC).
Drive AC supply network type	TN (grounded) and IT (ungrounded) systems up to 690 V AC, corner-grounded systems up to 600 V AC
Input terminals	M12, maximum intrusion into module 20 mm (0.8"). Torque: 70 N·m (52 lbf·ft). See also chapter Dimension drawings.

Motor (AC) connection

Motor types	Asynchronous AC induction motors, permanent magnet synchronous motors and AC induction servomotors, ABB synchronous reluctance (SynRM) motors
Voltage (U_2)	0 to AC supply voltage of drive, 3-phase symmetrical, U_{max} at field weakening point
Frequency	0...500 Hz <ul style="list-style-type: none">• For higher operational output frequencies, please contact your local ABB representative.• Operation outside the range of 12...150 Hz requires derating. See section Derating (page 155).
Current	See section Ratings (page 154) .
Switching frequency	3 kHz (typical)
Maximum motor cable length	500 m (1640 ft)

Note:

Longer cables cause a motor voltage decrease which limits the available motor power. The decrease depends on the motor cable length and characteristics. Contact ABB for more information.

Output terminals	<u>Frame R8i</u> Quick connector. See also chapter Dimensions. Busbars to quick connector: M12. Torque: 70 N·m (52 lbf·ft) Busbars to support insulators: M8. Torque: 9 N·m (6.5 lbf·ft) Cables to busbars: M12. Torque: 70 N·m (52 lbf·ft) See also section One R8i module in a 400 mm wide Rittal VX25 enclosure (page 35)
-------------------------	---

Control connections

See chapter Control unit.

Coolant connections

16 mm, for polyamide (PA) pipe.

Efficiency

Approximately 98% at nominal power level

Degree of protection

IP00

Optical components

The specifications of the optic cable are as follows:

- Storage temperature: -55 ... +85 °C
- Installation temperature: -20 ... +70 °C
- Maximum short-term tensile force: 50 N
- Minimum short-term bend radius: 25 mm
- Minimum long-term bend radius: 35 mm
- Maximum long-term tensile load: 1 N
- Flexing: Max. 1000 cycles

ABB drive products in general utilize 5 and 10 MBd (megabaud) optical components from Avago Technologies' Versatile Link range. Note that the optical component type is not directly related to the actual communication speed.

Note:

The optical components (transmitter and receiver) on a fiber optic link must be of the same type.

Plastic optical fiber (POF) cables can be used with both 5 MBd and 10 MBd optical components. 10 MBd components also enable the use of Hard Clad Silica (HCS®) cables, which allow longer connection distances thanks to their lower attenuation. HCS® cables cannot be used with 5 MBd optical components.

The maximum lengths of fiber optic links for POF and HCS® cables are 20 and 200 meters respectively.

Ambient conditions

The unit is to be used in a heated indoor controlled environment.			
	Operation installed for stationary use	Storage in protective package	Transportation in protective package
Altitude above sea level	0...4000 m (13123 ft)* Output derated above 1000 m (3281 ft). See section Altitude derating. *Neutral-grounded TN and TT network systems, non-corner-grounded IT network systems. Corner-grounded TN, TT and IT network systems up to 600 V.	-	-
Air temperature	0 ... +45 °C (+32 ... +113 °F), no condensation allowed. Output derated in the range +45 ... +55 °C (+113 ... +131 °F).	-40 ... +70 °C (-40 ... +158 °F)	-40 ... +70 °C (-40 ... +158 °F)

Relative humidity	Maximum 95%, no condensation allowed	Maximum 95%, no condensation allowed	Maximum 95%, no condensation allowed
	No condensation allowed. Maximum allowed relative humidity is 60% in the presence of corrosive gases.		
Contamination	IEC/EN 60721-3-3:2002: Classification of environmental conditions - Part 3-3: Classification of groups of environmental parameters and their severities - Stationary use of weather protected locations	IEC 60721-3-1	IEC 60721-3-2
Chemical gases	Class 3C2	Class 1C2	Class 2C2
Solid particles	Class 3S1	Class 1S3 (packing must support this, otherwise 1S2)	Class 2S2
	No conductive dust allowed.		
Vibration	IEC 61800-5-1 IEC 60068-2-6:2007, EN 60068-2-6:2008 Environmental testing Part 2: Tests -Test Fc: Vibration (sinusoidal) 10 ... 57 Hz, max. 0.075 mm amplitude 57 ... 150 Hz 1 g Tested in a typical cabinet assembly according to: Max. 1 mm (0.04 in.) (peak value, 5 ... 13.2 Hz), max. 0.7 g (13.2 ... 100 Hz) sinusoidal	IEC/EN 60721-3-1:1997	IEC/EN 60721-3-1:1997
Shock IEC 60068-2-27:2008, EN 60068-2-27:2009 Environmental testing - Part 2-27: Tests - Test Ea and guidance: Shock	Not allowed	With packing max. 100 m/s ² (330 ft./s ²) 11 ms	With packing max. 100 m/s ² (330 ft./s ²) 11 ms

Materials

Module housing	<ul style="list-style-type: none"> • Zinc coated steel sheet • Front plate covered with Lexan 8B35 polycarbonate film, color PMS 1C Cool Gray and PMS Process Black (frame R8i)
Liquid cooling system	See Cooling circuit materials (page 150)
Fire safety of materials (IEC 60332-1)	Insulating materials and non-metallic items: mostly self-extinctive
Package	<ul style="list-style-type: none"> • Plywood base, corrugated cardboard, PET straps. • Product wrapping: polyethylene sheet or VCI protection bag
Disposal	<p>The main parts of the drive can be recycled to preserve natural resources and energy. Product parts and materials should be dismantled and separated. Generally all metals, such as steel, aluminum, copper and its alloys, and precious metals can be recycled as material. Plastics, rubber, cardboard and other packaging material can be used in energy recovery. Printed circuit boards and large electrolytic capacitors need selective treatment according to IEC 62635 guidelines. To aid recycling, plastic parts are marked with an appropriate identification code. Contact your local ABB distributor for further information on environmental aspects and recycling instructions for professional recyclers. End of life treatment must follow international and local regulations.</p>

Standards

See *Electrical planning instructions for ACS880 multidrive cabinets and modules* (3AUA0000102324 [English]).

Markings

See *Electrical planning instructions for ACS880 multidrive cabinets and modules* (3AUA0000102324 [English]).

Auxiliary power consumption

■ Control equipment

Device	U_N	f Hz	I_{cont} A	I_{start} A	P_{cont} W	S_{cont} VA
BCU control unit	24 V DC ($\pm 10\%$)	-	2.0	-	48	-
BSFC-12C charging controller	24 V DC ($\pm 10\%$)	-	0.15	-	-	-
CIO-01 I/O module	24 V DC (+20%/-15%)	-	0.1	-	-	-
PDAL2 switch/disconnector interlock coil	24 V DC (+10%/-30%)	-	-	-	-	9
R8i module: internal electronics	230 V AC (+15%/-20%)	50	0.45	-	105	-
	115 V AC (+15%/-20%)	60	0.9	-	105	-

■ Cooling fans

Frame size	U_N V AC	f Hz	I_{cont} A	Type
R8i	200...240	50/60	1.4	R3G225-RE07-03
	100...130	50/60	2.4	R3G225-RE19-22

■ Definitions

f	Supply frequency
I_{cont}	Continuous current consumption
I_{start}	Calculated load current at start
P_{cont}	Continuous input power
U_N	Voltage requirement

Fuse data

■ Flush-end fuse blocks used with 690 V units

Rating	Class	Example	Power loss at I_n	Clearing I^2t		Size	U_n
A rms			W	A ² s	V		V
800	aR	Bussmann 170M6546	125	995000	1000	3	1250 (IEC) 1300 (UL)
900	aR	Bussmann 170M6547	130	1500000	1000	3	1100 (IEC)
1000	aR	Bussmann 170M6548	135	2150000	1000	3	1100 (IEC)
1100	aR	Bussmann 170M6549	140	2800000	1000	3	1100 (IEC)
1250	aR	Bussmann 170M6500	145	3950000	1000	3*	1100 (IEC)
1400	aR	Bussmann 170M6501	150	6000000	1000	3*	1100 (IEC)

Tightening torques

For Rittal components, use the torques given in the Rittal assembly documentation.

Unless a tightening torque is specified in the text, the following torques can be used.

■ Electrical connections

Size	Torque	Note
M3	0.5 N·m (4.4 lbf·in)	Strength class 4.6...8.8
M4	1 N·m (9 lbf·in)	Strength class 4.6...8.8
M5	4 N·m (35 lbf·in)	Strength class 8.8
M6	9 N·m (6.6 lbf·ft)	Strength class 8.8
M8	22 N·m (16 lbf·ft)	Strength class 8.8
M10	42 N·m (31 lbf·ft)	Strength class 8.8
M12	70 N·m (52 lbf·ft)	Strength class 8.8
M16	120 N·m (90 lbf·ft)	Strength class 8.8

■ Mechanical connections

Size	Max. torque	Note
M5	6 N·m (53 lbf·in)	Strength class 8.8
M6	10 N·m (7.4 lbf·ft)	Strength class 8.8
M8	24 N·m (17.7 lbf·ft)	Strength class 8.8

■ Insulation supports

Size	Max. torque	Note
M6	5 N·m (44 lbf·in)	Strength class 8.8
M8	9 N·m (6.6 lbf·ft)	Strength class 8.8
M10	18 N·m (13.3 lbf·ft)	Strength class 8.8
M12	31 N·m (23 lbf·ft)	Strength class 8.8

■ Cable lugs

Size	Max. torque	Note
M8	15 N·m (11 lbf·ft)	Strength class 8.8
M10	32 N·m (23.5 lbf·ft)	Strength class 8.8
M12	50 N·m (37 lbf·ft)	Strength class 8.8


Disclaimers

■ Generic disclaimer

The manufacturer shall have no obligation with respect to any product which (i) has been improperly repaired or altered; (ii) has been subjected to misuse, negligence or accident; (iii) has been used in a manner contrary to the manufacturer's instructions; or (iv) has failed as a result of ordinary wear and tear.

■ Cybersecurity disclaimer

This product is designed to be connected to and to communicate information and data via a network interface. It is Customer's sole responsibility to provide and continuously ensure a secure connection between the product and Customer network or any other network (as the case may be). Customer shall establish and maintain any appropriate measures (such as but not limited to the installation of firewalls, application of authentication measures, encryption of data, installation of anti-virus programs, etc) to protect the product, the network, its system and the interface against any kind of security breaches, unauthorized access, interference, intrusion, leakage and/or theft of data or information. ABB and its affiliates are not liable for damages and/or losses related to such security breaches, any unauthorized access, interference, intrusion, leakage and/or theft of data or information.



12

Control units of the drive

Contents of this chapter

This chapter


- describes the connections of the control unit(s) used in the drive,
- contains the specifications of the inputs and outputs of the control unit(s).

General


The BCU-x2 control unit is used with frame size R8i and multiples. The BCU-x2 consists of a BCON-12 control board (and a BIOC-01 I/O connector board and power supply board) built in a metal housing. The control unit is connected to the inverter module(s) by fiber optic cables.

In this manual, the name “BCU-x2” represents the control unit types BCU-02, BCU-12 and BCU-22. These have a different number of power module connections (2, 7 and 12 respectively) but are otherwise similar.

BCU-x2 control unit layout and connections



	Description
I/O	I/O terminals (see following diagram)
SLOT 1	I/O extension, encoder interface or fieldbus adapter module connection. (This is the sole location for an FDPI-02 diagnostics and panel interface.)
SLOT 2	I/O extension, encoder interface or fieldbus adapter module connection
SLOT 3	I/O extension, encoder interface, fieldbus adapter or FSO-xx safety functions module connection
SLOT 4	RDCO-0x DDCS communication option module connection
X205	Memory unit connection
BATTERY	Holder for real-time clock battery (BR2032)
A11	Mode selector for analog input A11 (I = current, U = voltage)
A12	Mode selector for analog input A12 (I = current, U = voltage)
D2D TERM	Termination switch for drive-to-drive link (D2D)
DICOM=DIOGND	Ground selection. Determines whether DICOM is separated from DIOGND (ie. the common reference for the digital inputs floats). See the ground isolation diagram.
7-segment display	
Multicharacter indications are displayed as repeated sequences of characters	
	("U" is indicated briefly before "o".) Control program running
	Control program startup in progress
	(Flashing) Firmware cannot be started. Memory unit missing or corrupted
	Firmware download from PC to control unit in progress
	At power-up, the display may show short indications of eg. "1", "2", "b" or "U". These are normal indications immediately after power-up. If the display ends up showing any other value than those described, it indicates a hardware failure.




	Description
XAI	Analog inputs
XAO	Analog outputs
XDI	Digital inputs, Digital input interlock (DIIL)
XDIO	Digital input/outputs
XD2D	Drive-to-drive link
XD24	+24 V output (for digital inputs)
XETH	Ethernet port – Not in use
XPOW	External power input
XRO1	Relay output RO1
XRO2	Relay output RO2
XRO3	Relay output RO3
XSTO	Safe torque off connection (input signals)
XSTO OUT	Safe torque off connection (to inverter modules)
X12	(On the opposite side) Connection for FSO-xx safety functions module (optional)
X13	Control panel / PC connection
X485	Not in use
V1T/V1R, V2T/V2R	Fiber optic connection to modules 1 and 2 (VxT = transmitter, VxR = receiver)
V3T/V3R ... V7T/V7R	Fiber optic connection to modules 3...7 (BCU-12/22 only) (VxT = transmitter, VxR = receiver)
V8T/V8R ... V12T/V12R	Fiber optic connection to modules 8...12 (BCU-22 only) (VxT = transmitter, VxR = receiver)
SD CARD	Data logger memory card for inverter module communication
BATT OK	Real-time clock battery voltage is higher than 2.8 V. If the LED is off when the control unit is powered, replace the battery.
FAULT	The control program has generated a fault. See the firmware manual of the supply/inverter unit.
PWR OK	Internal voltage supply is OK
WRITE	Writing to memory card in progress. Do not remove the memory card.

Default I/O diagram of the inverter control unit (A41)

The diagram below shows the default I/O connections on the inverter control unit (A41), and describes the use of the connections in the inverter unit.

The wire size accepted by all screw terminals (for both stranded and solid wire) is 0.5 ... 2.5 mm² (24...12 AWG). The torque is 0.5 N·m (5 lbf·in).



Notes:


- 1) See section *The XD2D connector (page 176)*.
- 2) See chapter *The Safe torque off function (page 181)*.
- 3) 0 = Acceleration/deceleration ramps defined by parameters 23.12/23.13 in use. 1 = Acceleration/deceleration ramps defined by parameters 23.14/23.15 in use.
- 4) Constant speed 1 is defined by parameter 22.26.
- 5) See section *DIIL input (page 176)*.
- 6) Total load capacity of these outputs is 4.8 W (200 mA at 24 V) minus the power taken by DIO1 and DIO2.
- 7) Determines whether DICOM is separated from DIOGND (ie. common reference for digital inputs floats; in practice, selects whether the digital inputs are used in current sinking or sourcing mode). See also *BCU-x2 ground isolation diagram (page 180)*.
DICOM=DIOGND ON: DICOM connected to DIOGND. OFF: DICOM and DIOGND separate.
- 8) Current [0(4)...20 mA, $R_{in} = 100 \text{ ohm}$] or voltage [0(2)...10 V, $R_{in} > 200 \text{ kohm}$] input selected by switch AI1. Change of setting requires reboot of control unit.
- 9) Current [0(4)...20 mA, $R_{in} = 100 \text{ ohm}$] or voltage [0(2)...10 V, $R_{in} > 200 \text{ kohm}$] input selected by switch AI2. Change of setting requires reboot of control unit.

External power supply for the control unit (XPOW)

The control unit is powered from a 24 V DC, 2 A supply through terminal block XPOW. With a type BCU control unit, a second supply can be connected to the same terminal block for redundancy.

DI6 as a PTC sensor input


A PTC sensor can be connected to this input for motor temperature measurement as follows. The sensor can alternatively be connected to FEN-xx encoder interface module. At the sensor end of the cable, leave the shields unconnected or ground them indirectly via a high-frequency capacitor with a few nanofarads, for example 3.3 nF / 630 V AC. The shield can also be grounded directly at both ends if they are in the same ground line with no significant voltage drop between the end points. See the firmware manual of the inverter unit for parameter settings.

**WARNING!**

As the inputs pictured above are not insulated according to IEC 60664, the connection of the motor temperature sensor requires double or reinforced insulation between motor live parts and the sensor. If the assembly does not fulfill the requirement, the I/O board terminals must be protected against contact and must not be connected to other equipment or the temperature sensor must be isolated from the I/O terminals.

AI1 or AI2 as a Pt100, Pt1000, PTC or KTY84 sensor input

Three Pt100/Pt1000 sensors or one KTY84 sensor for motor temperature measurement can be connected between an analog input and output as shown below. (Alternatively, you can connect the KTY to an FIO-11 or FAIO-01 analog I/O extension module or FEN-xx encoder interface module.) At the sensor end of the cable, leave the shields unconnected or ground them indirectly via a high-frequency capacitor with a few nanofarads, for example 3.3 nF / 630 V. The shield can also be grounded directly at both ends if they are in the same ground line with no significant voltage drop between the end points.



1) Set the input type to voltage with the appropriate switch or jumper on the inverter control unit. Make the corresponding setting in the inverter unit control program in parameter group **12 Standard AI**.

2) Select the excitation mode in parameter group **13 Standard AO** of inverter unit control program.



WARNING!

As the inputs pictured above are not insulated according to IEC/EN 60664, the connection of the motor temperature sensor requires double or reinforced insulation between motor live parts and the sensor. If the assembly does not fulfill the requirement, the I/O board terminals must be protected against contact and must not be connected to other equipment or the temperature sensor must be isolated from the I/O terminals.

DIIL input

The DIIL input is used for the connection of safety circuits. The input is parametrized to stop the unit when the input signal is lost.

Note:

This input is NOT SIL or PI certified.

The XD2D connector

The XD2D connector provides an RS-485 connection that can be used for

- basic master/follower communication with one master drive and multiple followers,
- fieldbus control through the embedded fieldbus interface (EFB), or

- drive-to-drive (D2D) communication implemented by application programming.


See the firmware manual of the drive for the related parameter settings.

Enable bus termination on the units at the ends of the drive-to-drive link. Disable bus termination on the intermediate units.

Use shielded twisted-pair cable with a twisted pair for data and a wire or another pair for signal ground (nominal impedance 100 to 165 ohm, for example Belden 9842) for the wiring. For best immunity, ABB recommends high quality cable. Keep the cable as short as possible. Avoid unnecessary loops and parallel runs near power cables such as motor cables.

The following diagram shows the wiring between control units.

BCU-x2



Safe torque off (XSTO, XSTO OUT)

See chapter [The Safe torque off function \(page 181\)](#).

Note:

The XSTO input only acts as a true Safe torque off input on the inverter control unit. De-energizing the IN1 and/or IN2 terminals of other units (supply, DC/DC converter, or brake unit) will stop the unit but not constitute a true safety function.


FSO-xx safety functions module connection (X12)

See the user manual of the FSO-xx module. Note that the FSO-xx safety functions module is not in use in supply (or DC/DC converter or brake) units.

SDHC memory card slot


The BCU-x2 has an on-board data logger that collects real-time data from the power modules to help fault tracing and analysis. The data is stored onto the SDHC memory card inserted into the SD CARD slot and can be analyzed by ABB service personnel.

Connector data

<p>Power supply (XPOW)</p>	<p>Connector pitch 5 mm, wire size 2.5 mm² 24 V (±10%) DC, 2 A External power input. Two supplies can be connected for redundancy.</p>
<p>Relay outputs RO1...RO3 (XRO1...XRO3)</p>	<p>Connector pitch 5 mm, wire size 2.5 mm² 250 V AC / 30 V DC, 2 A Protected by varistors</p>
<p>+24 V output (XD24:2 and XD24:4)</p>	<p>Connector pitch 5 mm, wire size 2.5 mm² Total load capacity of these outputs is 4.8 W (200 mA / 24 V) minus the power taken by DIO1 and DIO2.</p>
<p>Digital inputs DI1...DI6 (XDI:1...XDI:6)</p>	<p>Connector pitch 5 mm, wire size 2.5 mm² 24 V logic levels: "0" < 5 V, "1" > 15 V R_{in}: 2.0 kohm Input type: NPN/PNP (DI1...DI5), NPN (DI6) Hardware filtering: 0.04 ms, digital filtering up to 8 ms DI6 (XDI:6) can alternatively be used as an input for a PTC sensor. "0" > 4 kohm, "1" < 1.5 kohm. I_{max}: 15 mA (DI1...DI5), 5 mA (DI6)</p>
<p>Start interlock input DIIL (XDI:7)</p>	<p>Connector pitch 5 mm, wire size 2.5 mm² 24 V logic levels: "0" < 5 V, "1" > 15 V R_{in}: 2.0 kohm Input type: NPN/PNP Hardware filtering: 0.04 ms, digital filtering up to 8 ms</p>
<p>Digital inputs/outputs DIO1 and DIO2 (XDIO:1 and XDIO:2) Input/output mode selection by parameters. DIO1 can be configured as a frequency input (0...16 kHz with hardware filtering of 4 microseconds) for 24 V level square wave signal (sinusoidal or other wave form cannot be used). DIO2 can be configured as a 24 V level square wave frequency output. See the firmware manual of the supply/inverter unit, parameter group 111/11.</p>	<p>Connector pitch 5 mm, wire size 2.5 mm² <u>As inputs:</u> 24 V logic levels: "0" < 5 V, "1" > 15 V. R_{in}: 2.0 kohm. Filtering: 1 ms. <u>As outputs:</u> Total output current from +24VD is limited to 200 mA</p> 
<p>Reference voltage for analog inputs +VREF and -VREF (XAI:1 and XAI:2)</p>	<p>Connector pitch 5 mm, wire size 2.5 mm² 10 V ±1% and -10 V ±1%, R_{load} 1...10 kohm Maximum output current: 10 mA</p>

Analog inputs AI1 and AI2 (XAI:4 ... XAI:7). Current/voltage input mode selection by switches	Connector pitch 5 mm, wire size 2.5 mm ² Current input: -20...20 mA, $R_{in} = 100 \text{ ohm}$ Voltage input: -10...10 V, $R_{in} > 200 \text{ kohm}$ Differential inputs, common mode range $\pm 30 \text{ V}$ Sampling interval per channel: 0.25 ms Hardware filtering: 0.25 ms, adjustable digital filtering up to 8 ms Resolution: 11 bit + sign bit Inaccuracy: 1% of full scale range
Analog outputs AO1 and AO2 (XAO)	Connector pitch 5 mm, wire size 2.5 mm ² 0...20 mA, $R_{load} < 500 \text{ ohm}$ Frequency range: 0...500 Hz Resolution: 11 bit + sign bit Inaccuracy: 2% of full scale range
XD2D connector	Connector pitch 5 mm, wire size 2.5 mm ² Physical layer: RS-485 Termination by switch
RS-485 connection (X485)	Connector pitch 5 mm, wire size 2.5 mm ² Physical layer: RS-485
Safe torque off connection (XSTO)	Connector pitch 5 mm, wire size 2.5 mm ² Input voltage range: -3...30 V DC Logic levels: "0" < 5 V, "1" > 17 V. Note: For the unit to start, both connections must be "1". This applies to all control units (including drive, inverter, supply, brake, DC/DC converter etc. control units), but true Safe torque off functionality is only achieved through the XSTO connector of the drive/inverter control unit. Current consumption: 66 mA (continuous) per STO channel per R8i module EMC (immunity) according to IEC 61326-3-1 See also chapter The Safe torque off function (page 181) .
Safe torque off output (XSTO OUT)	Connector pitch 5 mm, wire size 2.5 mm ² To STO connector of inverter module.
Control panel connection (X13)	Connector: RJ-45 Cable length < 3 m
Ethernet connection (XETH)	Connector: RJ-45 This connection is not supported by the firmware.
SDHC memory card slot (SD CARD)	Memory card type: SDHC Maximum memory size: 4 GB
The terminals of the control unit fulfill the Protective Extra Low Voltage (PELV) requirements. The PELV requirements of a relay output are not fulfilled if a voltage higher than 48 V is connected to the relay output.	

■ BCU-x2 ground isolation diagram



*Ground selector (DICOM=DIOGND) settings

<p>DICOM=DIOGND: ON</p> <p>All digital inputs share a common ground (DICOM connected to DIOGND). This is the default setting.</p>
<p>DICOM=DIOGND: OFF</p> <p>Ground of digital inputs DI1...DI5 and DIIL (DICOM) is isolated from DIO signal ground (DIOGND). Isolation voltage 50 V.</p>

13

The Safe torque off function

Contents of this chapter

This chapter describes the Safe torque off (STO) function of the inverter and gives instructions for its use.

Description

The Safe torque off function can be used, for example, to as the final actuator device of safety circuits that stop the inverter in case of danger (such as an emergency stop circuit). Another typical application is a prevention of unexpected start-up function that enables short-time maintenance operations like cleaning or work on non-electrical parts of the machinery without switching off the power supply to the inverter.

When activated, the Safe torque off function disables the control voltage of the power semiconductors of the inverter output stage (A, see the diagrams below), thus preventing the inverter from generating the torque required to rotate the motor. If the motor is running when Safe torque off is activated, it coasts to a stop.

The Safe torque off function has a redundant architecture, that is, both channels must be used in the safety function implementation. The safety data given in this manual is calculated for redundant use, and does not apply if both channels are not used.

The Safe torque off function complies with these standards:

Standard	Name
IEC 60204-1:2016 EN 60204-1:2006 + A1:2009 + AC:2010	<i>Safety of machinery – Electrical equipment of machines – Part 1: General requirements</i>
IEC 61000-6-7:2014	<i>Electromagnetic compatibility (EMC) – Part 6-7: Generic standards – Immunity requirements for equipment intended to perform functions in a safety-related system (functional safety) in industrial locations</i>

Standard	Name
IEC 61326-3-1:2017	<i>Electrical equipment for measurement, control and laboratory use – EMC requirements – Part 3-1: Immunity requirements for safety-related systems and for equipment intended to perform safety-related functions (functional safety) – General industrial applications</i>
IEC 61508-1:2010	<i>Functional safety of electrical/electronic/programmable electronic safety-related systems – Part 1: General requirements</i>
IEC 61508-2:2010	<i>Functional safety of electrical/electronic/programmable electronic safety-related systems – Part 2: Requirements for electrical/electronic/programmable electronic safety-related systems</i>
IEC 61511-1:2016	<i>Functional safety – Safety instrumented systems for the process industry sector</i>
IEC 61800-5-2:2016 EN 61800-5-2:2007	<i>Adjustable speed electrical power drive systems – Part 5-2: Safety requirements – Functional</i>
IEC 62061:2005 + A1:2012 + A2:2015 EN 62061:2005 + AC:2010 + A1:2013 + A2:2015	<i>Safety of machinery – Functional safety of safety-related electrical, electronic and programmable electronic control systems</i>
EN ISO 13849-1:2015	<i>Safety of machinery – Safety-related parts of control systems – Part 1: General principles for design</i>
EN ISO 13849-2:2012	<i>Safety of machinery – Safety-related parts of control systems – Part 2: Validation</i>

The function also corresponds to Prevention of unexpected start-up as specified by EN ISO 14118:2018 (ISO 14118:2017), and Uncontrolled stop (stop category 0) as specified in EN/IEC 60204-1.

■ **Compliance with the European Machinery Directive**

See *Electrical planning instructions for ACS880 liquid-cooled multidrive cabinets and modules* (3AXD50000048634 [English]).

Wiring

For the electrical specifications of the STO connection, see the technical data of the control unit.

■ Activation switch

In the wiring diagrams, the activation switch has the designation [K]. This represents a component such as a manually operated switch, an emergency stop push button switch, or the contacts of a safety relay or safety PLC.

- In case a manually operated activation switch is used, the switch must be of a type that can be locked out to the open position.
- The contacts of the switch or relay must open/close within 200 ms of each other.
- An FSO-xx safety functions module or and FPTC-0x thermistor protection module can also be used. For more information, see the module documentation.

■ Cable types and lengths

- Double-shielded twisted-pair cable is recommended.
- Maximum cable lengths:
 - 300 m (1000 ft) between activation switch [K] and inverter control unit
 - 60 m (200 ft) between multiple drives or inverter units
 - 60 m (200 ft) between external power supply and first control unit
 - 30 m (100 ft) between BCU control unit and last inverter module in the chain.

Note:

A short-circuit in the wiring between the switch and an STO terminal causes a dangerous fault. Therefore, it is recommended to use a safety relay (including wiring diagnostics) or a wiring method (shield grounding, channel separation) which reduces or eliminates the risk caused by the short-circuit.

Note:

The voltage at the STO input terminals of the control unit (or frame R8i inverter module) must be at least 17 V DC to be interpreted as "1".


The pulse tolerance of the input channels is 1 ms.

■ Grounding of protective shields

- Ground the shield in the cabling between the activation switch and the control unit at the control unit only.
 - Ground the shield in the cabling between two control units at one control unit only.
 - Do not ground the shield in the cabling between BCU and R8i module, or between R8i modules.
-


■ Dual-channel connection with internal power supply

Frame R8i and multiples



1	Inverter control unit
2	Inverter module(s)
3	To remaining inverter modules
K	Activation switch

■ Single-channel connection of activation switch




Note:

- Both STO inputs (IN1, IN2) must be connected to the activation switch. Otherwise, no SIL/PL classification is given.
- Pay special attention to avoiding any potential failure modes for the wiring. For example, use shielded cable. For measures for fault exclusion of wiring, see eg. EN ISO 13849-2:2012, table D.4.


1	Inverter unit
2	Control unit
K	Activation switch

■ Multiple drives

Internal power supply



External power supply



Operation principle

1. The Safe torque off activates (the activation switch is opened, or safety relay contacts open).
2. The STO inputs of the inverter control unit de-energize.
3. The control unit cuts off the control voltage from the output IGBTs.
4. The control program generates an indication as defined by parameter 31.22 (refer to the firmware manual of the inverter).

The parameter selects which indications are given when one or both STO signals are switched off or lost. The indications also depend on whether the inverter is running or stopped when this occurs.

Note:

This parameter does not affect the operation of the STO function itself. The STO function will operate regardless of the setting of this parameter: a running drive will stop upon removal of one or both STO signals, and will not start until both STO signals are restored and all faults reset.

Note:

The loss of only one STO signal always generates a fault as it is interpreted as a malfunction of STO hardware or wiring.

5. The motor coasts to a stop (if running). The inverter cannot restart while the activation switch or safety relay contacts are open. After the contacts close, a reset may be needed (depending on the setting of parameter 31.22). A new start command is required to start the inverter.
-

Start-up including acceptance test

To ensure the safe operation of a safety function, validation is required. The final assembler of the machine must validate the function by performing an acceptance test. The acceptance test must be performed

- at initial start-up of the safety function
- after any changes related to the safety function (circuit boards, wiring, components, settings, etc.)
- after any maintenance work related to the safety function.

■ Competence

The acceptance test of the safety function must be carried out by a competent person with adequate expertise and knowledge of the safety function as well as functional safety, as required by IEC 61508-1 clause 6. The test procedures and report must be documented and signed by this person.

■ Acceptance test reports

Signed acceptance test reports must be stored in the logbook of the machine. The report shall include documentation of start-up activities and test results, references to failure reports and resolution of failures. Any new acceptance tests performed due to changes or maintenance shall be logged into the logbook.

■ Acceptance test procedure


After wiring the Safe torque off function, validate its operation as follows.

Note:

If an FSO-xx safety functions module or an FPTC-0x module is installed, refer to its documentation.

Note:

All inverter modules of the inverter unit must be powered and connected to the STO circuit during the acceptance test.

Action	<input checked="" type="checkbox"/>
 WARNING! Follow the safety instructions. If you ignore them, injury or death, or damage to the equipment can occur.	<input type="checkbox"/>
Ensure that the inverter can be run and stopped freely during start-up.	<input type="checkbox"/>
Stop the inverter (if running), switch the input power off and isolate the inverter from the power line using a disconnecter.	<input type="checkbox"/>
Check the STO circuit connections against the wiring diagram.	<input type="checkbox"/>
Close the disconnecter and switch the power on.	<input type="checkbox"/>

190 The Safe torque off function

Action	<input checked="" type="checkbox"/>
<p>Test the operation of the STO function when the motor is stopped.</p> <ul style="list-style-type: none"> • Give a stop command for the inverter (if running) and wait until the motor shaft is at a standstill. <p>Ensure that the inverter operates as follows:</p> <ul style="list-style-type: none"> • Open the STO circuit. The inverter generates an indication if one is defined for the 'stopped' state in parameter 31.22 (see the firmware manual). • Give a start command to verify that the STO function blocks the inverter's operation. The inverter generates a warning. The motor should not start. • Close the STO circuit. • Reset any active faults. Restart the inverter and check that the motor runs normally. 	<input type="checkbox"/>
<p>Test the operation of the STO function when the motor is running.</p> <ul style="list-style-type: none"> • Start the inverter and ensure the motor is running. • Open the STO circuit. The motor should stop. The inverter generates an indication if one is defined for the 'running' state in parameter 31.22 (see the firmware manual). • Reset any active faults and try to start the inverter. • Ensure that the motor stays at a standstill and the inverter operates as described above in testing the operation when the motor is stopped. • Close the STO circuit. • Reset any active faults. Restart the inverter and check that the motor runs normally. 	<input type="checkbox"/>
<p>Test the operation of the failure detection of the inverter. The motor can be stopped or running.</p> <ul style="list-style-type: none"> • Open the 1st channel of the STO circuit (wire coming to IN1). If the motor was running, it should coast to a stop. The inverter generates a <i>FA81 Safe Torque Off 1 loss</i> fault indication (see the firmware manual). • Give a start command to verify that the STO function blocks the inverter's operation. The motor should not start. • Close the STO circuit. • Reset any active faults. Restart the inverter and check that the motor runs normally. • Open the 2nd channel of the STO circuit (wire coming to IN2). If the motor was running, it should coast to a stop. The inverter generates a <i>FA82 Safe Torque Off 2 loss</i> fault indication (see the firmware manual). • Give a start command to verify that the STO function blocks the inverter's operation. The motor should not start. • Close the STO circuit. • Reset any active faults. Restart the inverter and check that the motor runs normally. 	<input type="checkbox"/>
<p>Document and sign the acceptance test report which verifies that the safety function is safe and accepted for operation.</p>	<input type="checkbox"/>

Use

1. Open the activation switch, or activate the safety functionality that is wired to the STO connection.
2. The STO inputs on the inverter control unit de-energize, and the control unit cuts off the control voltage from the output IGBTs.
3. The control program generates an indication as defined by parameter 31.22 (refer to the firmware manual of the inverter).
4. The motor coasts to a stop (if running). The inverter will not restart while the activation switch or safety relay contacts are open.
5. Deactivate the STO by closing the activation switch, or resetting the safety functionality that is wired to the STO connection.
6. Reset any faults before restarting.



WARNING!

The Safe torque off function does not disconnect the voltage of the main and auxiliary circuits from the inverter. Therefore maintenance work on electrical parts of the inverter or the motor can only be carried out after isolating the inverter from the supply and all other voltage sources.



WARNING!

The Safe torque off functionality is only achieved through the XSTO connector of the inverter control unit (A41). True Safe torque off functionality is not achieved through the XSTO connectors of other control units (such as the supply control unit or the brake control unit).

The Safe torque off function is supported by any ACS880 inverter or drive control program. It is not supported by supply, DC/DC converter or brake firmware.



WARNING!

(With permanent magnet or synchronous reluctance [SynRM] motors only)

In case of a multiple IGBT power semiconductor failure, the inverter can produce an alignment torque which maximally rotates the motor shaft by $180/p$ degrees (with permanent magnet motors) or $180/2p$ degrees (with synchronous reluctance [SynRM] motors) regardless of the activation of the Safe torque off function. p denotes the number of pole pairs.

Notes:

- If a running inverter is stopped by using the Safe torque off function, the inverter will cut off the motor supply voltage and the motor will coast to a stop. If this causes danger or is not otherwise acceptable, stop the inverter and machinery using the appropriate stop mode before activating the Safe torque off function.
 - The Safe torque off function overrides all other functions of the inverter.
 - The Safe torque off function is ineffective against deliberate sabotage or misuse.
 - The Safe torque off function has been designed to reduce the recognized hazardous conditions. In spite of this, it is not always possible to eliminate all potential hazards. The assembler of the machine must inform the final user about the residual risks.
-

Maintenance

After the operation of the circuit is validated at start-up, the STO function shall be maintained by periodic proof testing. In high demand mode of operation, the maximum proof test interval is 20 years. In low demand mode of operation, the maximum proof test interval is 5 or 2 years; see section [Safety data \(page 194\)](#). It is assumed that all dangerous failures of the STO circuit are detected by the proof test. To perform the proof test, do the [Acceptance test procedure \(page 189\)](#).

Note:

See also the Recommendation of Use CNB/M/11.050 (published by the European co-ordination of Notified Bodies) concerning dual-channel safety-related systems with electromechanical outputs:

- When the safety integrity requirement for the safety function is SIL 3 or PL e (cat. 3 or 4), the proof test for the function must be performed at least every month.
- When the safety integrity requirement for the safety function is SIL 2 (HFT = 1) or PL d (cat. 3), the proof test for the function must be performed at least every 12 months.

The STO function of the drive does not contain any electromechanical components.

In addition to proof testing, it is a good practice to check the operation of the function when other maintenance procedures are carried out on the machinery.

Include the Safe torque off operation test described above in the routine maintenance program of the machinery that the inverter runs.

If any wiring or component change is needed after start up, or the parameters are restored, follow the test given in section [Acceptance test procedure \(page 189\)](#).

Use only spare parts approved by ABB.

Record all maintenance and proof test activities in the machine logbook.

■ Competence

The maintenance and proof test activities of the safety function must be carried out by a competent person with adequate expertise and knowledge of the safety function as well as functional safety, as required by IEC 61508-1 clause 6.

Fault tracing

The indications given during the normal operation of the Safe torque off function are selected by inverter control program parameter 31.22.

The diagnostics of the Safe torque off function cross-compare the status of the two STO channels. In case the channels are not in the same state, a fault reaction function is performed and the inverter trips on an “STO hardware failure” fault. An attempt to use the STO in a non-redundant manner, for example activating only one channel, will trigger the same reaction.

See the firmware manual of the inverter control program for the indications generated by the inverter, and for details on directing fault and warning indications to an output on the control unit for external diagnostics.

Any failures of the Safe torque off function must be reported to ABB.

Safety data

The safety data for the Safe torque off function is given below.

Note:

The safety data is calculated for redundant use, and does not apply if both STO channels are not used.

Frame size	SIL/ SILCL	PL	SFF (%)	PFH ($T_1 = 20$ a) (1/h)	PFD _{avg} ($T_1 = 2$ a)	PFD _{avg} ($T_1 = 5$ a)	MTTF _D (a)	DC (%)	Cat.	SC	HFT	CCF	T _M (a)
R8i	3	e	>99	5.0E-11	4.5E-07	1.1E-06	23970	≥90	3	3	1	80	20
2×R8i	3	e	>99	6.2E-11	5.5E-07	1.3E-06	16330	≥90	3	3	1	80	20
3×R8i	3	e	>99	7.3E-11	6.5E-07	1.6E-06	12390	≥90	3	3	1	80	20
4×R8i	3	e	>99	8.4E-11	7.6E-07	1.9E-06	9980	≥90	3	3	1	80	20

3AXD10000078136 F

- The following temperature profile is used in safety value calculations:
 - 670 on/off cycles per year with $\Delta T = 71.66$ °C
 - 1340 on/off cycles per year with $\Delta T = 61.66$ °C
 - 30 on/off cycles per year with $\Delta T = 10.0$ °C
 - 32 °C board temperature at 2.0% of time
 - 60 °C board temperature at 1.5% of time
 - 85 °C board temperature at 2.3% of time.
- The STO is a type B safety component as defined in IEC 61508-2.
- Relevant failure modes:
 - The STO trips spuriously (safe failure)
 - The STO does not activate when requested
 - A fault exclusion on the failure mode “short circuit on printed circuit board” has been made (EN 13849-2, table D.5). The analysis is based on an assumption that one failure occurs at one time. No accumulated failures have been analyzed.
- STO response times:
 - STO reaction time (shortest detectable break): 1 ms
 - STO response time: 2 ms (typical), 25 ms (maximum)
 - Fault detection time: Channels in different states for longer than 200 ms
 - Fault reaction time: Fault detection time + 10 ms
- Indication delays:
 - STO fault indication (parameter 31.22) delay: < 500 ms
 - STO warning indication (parameter 31.22) delay: < 1000 ms

■ Abbreviations

Abbr.	Reference	Description
Cat.	EN ISO 13849-1	Classification of the safety-related parts of a control system in respect of their resistance to faults and their subsequent behavior in the fault condition, and which is achieved by the structural arrangement of the parts, fault detection and/or by their reliability. The categories are: B, 1, 2, 3 and 4.
CCF	EN ISO 13849-1	Common cause failure (%)

Abbr.	Reference	Description
DC	EN ISO 13849-1	Diagnostic coverage
HFT	IEC 61508	Hardware fault tolerance
MTTF _D	EN ISO 13849-1	Mean time to dangerous failure: (Total number of life units) / (Number of dangerous, undetected failures) during a particular measurement interval under stated conditions
PFD _{avg}	IEC 61508	Average probability of dangerous failure on demand, that is, mean unavailability of a safety-related system to perform the specified safety function when a demand occurs
PFH	IEC 61508	Average frequency of dangerous failures per hour, that is, average frequency of a dangerous failure of a safety related system to perform the specified safety function over a given period of time
PL	EN ISO 13849-1	Performance level. Levels a...e correspond to SIL
SC	IEC 61508	Systematic capability
SFF	IEC 61508	Safe failure fraction (%)
SIL	IEC 61508	Safety integrity level (1...3)
SILCL	IEC/EN 62061	Maximum SIL (level 1...3) that can be claimed for a safety function or subsystem
STO	IEC/EN 61800-5-2	Safe torque off
T ₁	IEC 61508-6	Proof test interval. T ₁ is a parameter used to define the probabilistic failure rate (PFH or PFD) for the safety function or subsystem. Performing a proof test at a maximum interval of T ₁ is required to keep the SIL capability valid. The same interval must be followed to keep the PL capability (EN ISO 13849) valid. See also section Maintenance.
T _M	EN ISO 13849-1	Mission time: the period of time covering the intended use of the safety function/device. After the mission time elapses, the safety device must be replaced. Note that any T _M values given cannot be regarded as a guarantee or warranty.

■ TÜV certificate

The TÜV certificate is available on the Internet at www.abb.com/drives/documents.


14

Dimension drawings

Contents of this chapter

This chapter contains dimension drawings of the ACS880-104LC inverter modules as well as auxiliary components. Dimensional drawings of most installation accessories are available from ABB on request.

Frame R8i inverter module



First angle projection. Original drawing made with 3D CAD. Set the correct scale factor when adding dimensions after DWG/DXF conversion.


3AYD5000048361	3AYD5000048361	3AYD5000048361	3AYD5000048361
AC380V-1813-1C-14W-1AS5EW	AC380V-1813-1C-14W-1AS5EW	AC380V-1813-1C-14W-1AS5EW	AC380V-1813-1C-14W-1AS5EW
Approved	Approved	Approved	Approved
Updated	Updated	Updated	Updated
05-Jun-19	05-Jun-19	05-Jun-19	05-Jun-19
M. Koskinen	M. Koskinen	M. Koskinen	M. Koskinen
30000117912	30000117912	30000117912	30000117912

Doc. No.	3AYD5000048361	Form	A3
Scale	2:25	Scale	2:25
Doc. desc.	DIMENSION DRAWING	Doc. desc.	DIMENSION DRAWING
Rev. ind.	B (LRF)	Rev. ind.	B (LRF)
Lang.	EN	Lang.	EN
Doc. No.	3AYD5000048361	Doc. No.	3AYD5000048361
Sheet	1	Sheet	1
Total	1	Total	1

Based on	M. Koskinen	16-Jan-17	Little DIMENSION DRAWING
Customer	V. Saastik, J. Tahiti	05-Jun-19	AC380V-1813-1C-14W-1AS5EW
Appr.	J. Karppa	05-Jun-19	AC380V-1813-1C-14W-1AS5EW
Project name			
DWG Number	3AYD50000568346	Weight	63 kg




■ Quick connector




Control electronics


■ BCU control unit



■ DPMP-01 door mounting kit



DC fuse blocks (Bussmann)




1000...1250 V fuses (as used with 690 V units)

Size	A mm (inch)	B mm (inch)	D mm (inch)	E mm (inch)	F	G mm (inch)	H mm (inch)
3	81 (3.19)	83 (3.27)	92 (3.62)	76 (2.99)	M12	10 (0.39)	30 (1.18)
3*	81 (3.19)	91 (3.58)	92 (3.62)	76 (2.99)	M12	10 (0.39)	30 (1.18)


Switchgear and charging components

■ OT_ DC switch/disconnectors

OT1600E11, OT1600E22




OT2500E22




■ OS_ charging switches

OS160GD04F



OS200DZ22F




OS200			
D22	mm (inch)	D22	mm (inch)
A	149 (5.87)	K	8.4 (0.33)
B	199 (7.83)	L	8.6 (0.34)
C	36.5 (1.44)	M	165 (6.50)
D	144.5 (5.69)	N	80 (3.15)
E	135.5 (5.33)	A1	191 (7.52)
F	43.5 (1.71)	A2	95.5 (3.76)
G	20 (0.79)	B1	210 (8.27)
H	219 (8.62)	B2	105 (4.13)
I	40.8 (1.57)	C1	227 (8.94)
J	10 (0.39)	C2	113.5 (4.47)

■ OHB_ switch handles

Note: The drawings are not to scale.


OHB65J6



L = 65 mm

B = 6 × 6 mm


OHB150J12P



L = 300 mm

Shaft: 12 × 12 mm

OHB274J12




L = 274 mm

Shaft: 12 × 12 mm


The drilling pattern is the same as OHB65J6.

■ Auxiliary contacts


OA1G10




OA3G01




■ ZRF 30/165 S charging resistor



■ BSFC-12C charging controller





15

Example circuit diagrams


Contents of this chapter

This chapter contains connection diagram examples for the whole inverter unit.

Note:

By default, the Safe torque off (STO) function is not in use, and has been bridged at the factory as shown in the diagrams. For information on implementing the function, see chapter [The Safe torque off function](#).

022a



INVERTER UNIT

NOTE*: Optional BUFFER MODULE allows control cards to be on during short power interruptions.

Item Des.	Item Des.	Item Des.	Item Des.	Item Des.	Item Des.	Item Des.	Item Des.
EFSZ	EFSZ	EFSZ	EFSZ	EFSZ	EFSZ	EFSZ	EFSZ
3AXD1000583044	3AXD1000583044	3AXD1000583044	3AXD1000583044	3AXD1000583044	3AXD1000583044	3AXD1000583044	3AXD1000583044
SPW Doc. No. -11	SPW Doc. No. -11	SPW Doc. No. -11	SPW Doc. No. -11	SPW Doc. No. -11	SPW Doc. No. -11	SPW Doc. No. -11	SPW Doc. No. -11
EPAN Doc. No. -11	EPAN Doc. No. -11	EPAN Doc. No. -11	EPAN Doc. No. -11	EPAN Doc. No. -11	EPAN Doc. No. -11	EPAN Doc. No. -11	EPAN Doc. No. -11
ABB Ref. No.	ABB Ref. No.	ABB Ref. No.	ABB Ref. No.	ABB Ref. No.	ABB Ref. No.	ABB Ref. No.	ABB Ref. No.
Resep. Dept.	Resep. Dept.	Resep. Dept.	Resep. Dept.	Resep. Dept.	Resep. Dept.	Resep. Dept.	Resep. Dept.
Rev.	Rev.	Rev.	Rev.	Rev.	Rev.	Rev.	Rev.
022a	022a	022a	022a	022a	022a	022a	022a
026a	026a	026a	026a	026a	026a	026a	026a



ABB

Revision C

Project: ACS880-104LC

App: Mika Asikainen


Prep: Joni Tuomi

Title: 24V Distribution ACS880-104LC-0850A-7 INVERTER MODULE

28.1.2019

25.1.2019


026a




INVERTER UNIT

Customer No.	25.1.2019	Prep. Joni Tuomi	25.1.2019	Title Cabinet fans	ACS880-104LC-0850A-7	Circuit diagram	EFS2	Item Des.	= 11
Customer Ref. No.	26.1.2019	App. Mika Askanen	26.1.2019	ACS880-104LC-0850A-7	INVERTER MODULE	SAP Doc. No.	3AXD10000580044	+11.1	
Customer	Example Circuit Diagrams	Project ACS880-104LC	R81	Revision C		EPAN Doc. No.	-11	Rev.	C Sheet
						ABB Ref. No.		026a	040a
						Resp. Dept.		Cont.	


040a



040b



040c



INVERTER UNIT


NOTE*: CH1: Charging DC voltage information for supply unit (optional)

Item No.	EFSZ	Item Des.	
SW Doc. No.	3AXD10000583044	= 11	
FRAN Doc. No.	-11	+11.1	
ABB Ref. No.			
Resep. Dept.			
Rev.	C	Sheet	040c
Cont.			061a

Prep.	Joni Tuomi	Title	INU Control Board
App.	Mika Asikainen		ACS880-104LC-0850A-7
Project	ACS880-104LC		INVERTER MODULE
	RBI		
	Revision C		

Frame 2xR8i with DC switch/disconnector

001a




INVERTER CUBICLE

<p>Cust. Doc. No. Cust. Ref. No. Customer</p>	<p>Prep. Joni Tuomi App. Mika Asikainen Project ACS880-104LC 2xR8i Revision B</p>	<p>Title Main line connections ACS880-104LC 2xR8i INVERTER MODULE</p>	<p>Item Desc. EFSZ = 11 +11.1</p>	<p>Circuit diagram SWP Doc. No. 3AXD1000603282 EPLAN Doc. No. +11.1 ABB Ref. No. Resp. Dept.</p>	<p>Rev. B Sheet 001a</p>
---	---	---	---	--	------------------------------



002a



INVERTER CUBICLE

#Charging Kit ABB Accessory -A11.1	CHARGING CONTROL BOARD BSFC-12C	Item Desc EFS2	Item Desc =11
		SAP Doc. No. 3A0J0000603282	Item Desc +11.1
		EPAN Doc. No.	Rev. +11.1
		ABB Ref. No.	Rev. 002a
		Resp. Dept.	Cont. 005a

26.4.2019	26.4.2019	ABB
Pres: Joni Tuomi	App: Mika Asikainen	
Project ACS880-104LC 2xR8I Revision B	Project ACS880-104LC 2xR8I Revision B	


Customer	Example Circuit Diagrams
----------	--------------------------

Circuit diagram	EFS2
SAP Doc. No.	3A0J0000603282
EPAN Doc. No.	
ABB Ref. No.	
Resp. Dept.	

Title	Charging circuit ACS880-104LC 2xR8I INVERTER MODULE
-------	---

Customer	Example Circuit Diagrams
----------	--------------------------


005a



INVERTER CUBICLE

Cust. Doc. No.		26.4.2019		Title		Module connections		Item Des.	
Cust. Ref. No.		26.4.2019		ACS800-104LC 2xR8		ACS800-104LC 2xR8		= 11	
Customer		Project		Revision B		INVERTER MODULE		+11.1	
Prep.		App.		Rev.		Rev.		Rev.	
Joni Tuomi		Mika Asikainen		ACS800-104LC		2xR8		005a	
Revision B		Revision B		Revision B		Revision B		020a	
2		3		4		5		6	
7		8		9		10		11	
12		13		14		15		16	
17		18		19		20		21	
22		23		24		25		26	
27		28		29		30		31	
32		33		34		35		36	
37		38		39		40		41	
42		43		44		45		46	
47		48		49		50		51	
52		53		54		55		56	
57		58		59		60		61	
62		63		64		65		66	
67		68		69		70		71	
72		73		74		75		76	
77		78		79		80		81	
82		83		84		85		86	
87		88		89		90		91	
92		93		94		95		96	
97		98		99		100		101	
102		103		104		105		106	
107		108		109		110		111	
112		113		114		115		116	
117		118		119		120		121	
122		123		124		125		126	
127		128		129		130		131	
132		133		134		135		136	
137		138		139		140		141	
142		143		144		145		146	
147		148		149		150		151	
152		153		154		155		156	
157		158		159		160		161	
162		163		164		165		166	
167		168		169		170		171	
172		173		174		175		176	
177		178		179		180		181	
182		183		184		185		186	
187		188		189		190		191	
192		193		194		195		196	
197		198		199		200		201	
202		203		204		205		206	
207		208		209		210		211	
212		213		214		215		216	
217		218		219		220		221	
222		223		224		225		226	
227		228		229		230		231	
232		233		234		235		236	
237		238		239		240		241	
242		243		244		245		246	
247		248		249		250		251	
252		253		254		255		256	
257		258		259		260		261	
262		263		264		265		266	
267		268		269		270		271	
272		273		274		275		276	
277		278		279		280		281	
282		283		284		285		286	
287		288		289		290		291	
292		293		294		295		296	
297		298		299		300		301	
302		303		304		305		306	
307		308		309		310		311	
312		313		314		315		316	
317		318		319		320		321	
322		323		324		325		326	
327		328		329		330		331	
332		333		334		335		336	
337		338		339		340		341	
342		343		344		345		346	
347		348		349		350		351	
352		353		354		355		356	
357		358		359		360		361	
362		363		364		365		366	
367		368		369		370		371	
372		373		374		375		376	
377		378		379		380		381	
382		383		384		385		386	
387		388		389		390		391	
392		393		394		395		396	
397		398		399		400		401	
402		403		404		405		406	
407		408		409		410		411	
412		413		414		415		416	
417		418		419		420		421	
422		423		424		425		426	
427		428		429		430		431	
432		433		434		435		436	
437		438		439		440		441	
442		443		444		445		446	
447		448		449		450		451	
452		453		454		455		456	
457		458		459		460		461	
462		463		464		465		466	
467		468		469		470		471	
472		473		474		475		476	
477		478		479		480		481	
482		483		484		485		486	
487		488		489		490		491	
492		493		494		495		496	
497		498		499		500		501	
502		503		504		505		506	
507		508		509		510		511	
512		513		514		515		516	
517		518		519		520		521	
522		523		524		525		526	
527		528		529		530		531	
532		533		534		535		536	
537		538		539		540		541	
542		543		544		545		546	
547		548		549		550		551	
552		553		554		555		556	
557		558		559		560		561	
562		563		564		565		566	
567		568		569		570		571	
572		573		574		575		576	
577		578		579		580		581	
582		583		584		585		586	
587		588		589		590		591	
592		593		594		595		596	
597		598		599		600		601	
602		603		604		605		606	
607		608		609		610		611	
612		613		614		615		616	
617		618		619		620		621	
622		623		624		625		626	
627		628		629		630		631	
632		633		634		635		636	
637		638		639		640		641	
642		643		644		645		646	
647		648		649		650		651	
652		653		654		655		656	
657		658		659		660		661	
662		663		664		665		666	
667		668		669		670		671	
672		673		674		675		676	
677		678		679		680		681	
682		683		684		685		686	
687		688		689		690		691	
692		693		694		695		696	
697		698		699		700		701	
702		703		704		705		706	
707		708		709		710		711	
712		713		714		715		716	
717		718		719		720		721	
722		723		724		725		726	
727		728		729		730		731	
732		733		734		735		736	
737		738		739		740		741	
742		743		744		745		746	
747		748		749		750		751	
752		753		754		755		756	
757		758		759		760		761	
762		763		764		765		766	
767		768		769		770		771	
772		773		774		775		776	
777		778		779		780		781	
782		783		784		785		786	
787		788		789					


022a




NOTE*: Optional BUFFER MODULE allows control cards to be on during short power interruptions.

INVERTER CUBICLE


026a



040a



040c




INVERTER CUBICLE


Part. Doc. No.	Customer	Example Circuit Diagrams
App.	Mika Tuomi	26.4.2019
Project	Mika Asikainen	26.4.2019
Revision B	ACS800-104LC 2xR8	
Rev.	Revision B	
Sheet	040c	8
Cont.	061a	

Frame 4xR8i without DC switch/disconnector


001a




005b




020a



022a




026a




1	2	3	4	5	6	7	8
Cust. Doc. No.		18.1.2019		The Cabinet fans		EFS2	
Cust. Ref. No.		25.1.2019		ACS880-104LC 4xR8I		= 11	
Customer		Example Circuit Diagrams		INVERTER MODULE		+11.1	
Prep.		Joni Tuomi		18.1.2019		Item Desc.	
App.		Mika Asikainen		25.1.2019		SAP Doc. No. 3AXD1000583045	
Project		ACS880-104LC		4xR8I		EPAN Doc. No. -11	
Revision		Revision C				ABB Ref. No.	
						Resp. Dept.	
						Rev.	
						C Sheet	
						026a	
						040a	

040a




040b



FIRST INVERTER CUBICLE

Cust. Doc. No.	18.1.2019	Prep.	Joni Tuomi	18.1.2019	The INU Control Board	Circuit diagram	EFS2	Item Des.	= 11
Cust. Ref. No.	25.1.2019	App.	Mika Asikainen	25.1.2019	ACS880-104LC 4xR8I	SAP Doc. No.	3AXD10000583045		+11.1
Customer	Example Circuit Diagrams	Project	ACS880-104LC 4xR8I		INVERTER MODULE	EPAN Doc. No.	- 11	Rev.	C
		Revision	Revision C			ABB Ref. No.		Cont.	040b
						Resp. Dept.			040c

040c




FIRST INVERTER CUBICLE

NOTE*: CH1: Charging DC voltage information for supply unit (optional)

<p>Qust. Doc. No.</p> <p>Cust. Ref. No.</p> <p>Customer</p>	<p>18.1.2019</p> <p>ACS800-104LC 4R8I</p> <p>Example Circuit Diagrams</p>	<p>Prep. Joni Tuomi</p> <p>App. Mika Asikainen</p> <p>Project ACS800-104LC 4R8I</p> <p>Revision C</p>	<p>File</p> <p>INU Control Board ACS800-104LC 4R8I INVERTER MODULE</p> <p>ABB</p>	<p>Circuit diagram</p> <p>SAP Doc. No. 3AX910000583M45</p> <p>EPAN Doc. No. -11</p> <p>ABB Ref. No.</p> <p>Resp. Dept.</p>	<p>Item Des.</p> <p>= 11</p> <p>+11.1</p> <p>Rev.</p> <p>C Sheet</p> <p>040C</p> <p>061B</p>
---	---	---	--	--	--

061a



SECOND INVERTER CUBICLE

FIRST INVERTER CUBICLE

Customer	Example Circuit Diagrams	Prep.	Joni Tuomi	18.1.2019	This Safety circuit	ACS880-104LC-4R8I	INVERTER MODULE	Item Des.	EFS2	Rev.	+11.1
Customer Ref. No.		App.	Mika Asikainen	25.1.2019	ACS880-104LC-4R8I			SAP Doc. No.	3AXD0000583045	Rev.	+11.1
		Project	ACS880-104LC-4R8I					EPAN Doc. No.	-11	Rev.	+11.1
		Revision	Revision C					ABB Ref. No.		Cont.	
								Resp. Dept.			



Further information

Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to www.abb.com/searchchannels.

Product training

For information on ABB product training, navigate to new.abb.com/service/training.

Providing feedback on ABB manuals

Your comments on our manuals are welcome. Navigate to new.abb.com/drives/manuals-feedback-form.

Document library on the Internet

You can find manuals and other product documents in PDF format on the Internet at www.abb.com/drives/documents.



www.abb.com/drives



3AXD50000045610B