

Type TB82PH Advantage Series™ 2-wire pH/ORP/pION transmitter



The Company

ABB Incorporated is an established world force in the design and manufacture of instrumentation for industrial process control, flow measurement, gas and liquid analysis and environmental applications.

As a part of ABB, a leader in process automation technology, we offer customers application expertise, service and support worldwide.

We are committed to teamwork, high quality manufacturing, advanced technology and unrivalled service and support.

The quality, accuracy and performance of the Company's products result from over 100 years experience, combined with a continuous program of innovative design and development to incorporate the latest technology.

ISO 9001:2000



Reno, Nevada USA Facility
Cert. No. CERT-9170-2003-AQ-HOU-RAB

Use of Instructions



Warning.

An instruction that draws attention to the risk of injury or death.



Note.

Clarification of an instruction or additional information.



Caution.

An instruction that draws attention to the risk of damage to the product, process or surroundings.



Information.

Further reference for more detailed information or technical details.

Although **Warning** hazards are related to personal injury, and **Caution** hazards are associated with equipment or property damage, it must be understood that operation of damaged equipment could, under certain operational conditions, result in degraded process system performance leading to personal injury or death. Therefore, comply fully with all **Warning** and **Caution** notices.

Information in this manual is intended only to assist our customers in the efficient operation of our equipment. Use of this manual for any other purpose is specifically prohibited and its contents are not to be reproduced in full or part without prior approval of Technical Communications Department, ABB Automation.

Health and Safety

To ensure that our products are safe and without risk to health, the following points must be noted:

1. The relevant sections of these instructions must be read carefully before proceeding.
2. Warning labels on containers and packages must be observed.
3. Installation, operation, maintenance and servicing must only be carried out by suitably trained personnel and in accordance with the information given.
4. Normal safety precautions must be taken to avoid the possibility of an accident occurring when operating in conditions of high pressure and/or temperature.
5. Chemicals must be stored away from heat, protected from temperature extremes and powders kept dry. Normal safe handling procedures must be used.
6. When disposing of chemicals ensure that no two chemicals are mixed.

Safety advice concerning the use of the equipment described in this manual or any relevant hazard data sheets (where applicable) may be obtained from the Company address on the back cover, together with servicing and spares information.

CONTENTS

Section	Page
CONTENTS	3
INTRODUCTION.....	3
SUPPLEMENTARY DOCUMENTATION.....	3
TRANSPORT	4
STORAGE	4
HANDLING	4
PRODUCT IDENTIFICATION.....	4
PRINCIPLE OF OPERATION	5
INSTALLATION.....	7
ELECTRICAL CONNECTIONS.....	8
LOCAL HMI OPERATING PROCEDURES	10
MEASURE MODE.....	11
CALIBRATE MODE.....	11
Process Variable Calibrate State	11
Temperature Calibrate State.....	12
Edit Calibrate State	13
Reset Calibrate State.....	13
OUTPUT/HOLD MODE.....	14
CONFIGURE MODE.....	14
Analyzer State.....	15
Temperature Sensor State.....	16
Temperature Compensation State	16
Linearity Type State	17
Diagnostic State	17
SECURITY MODE.....	18
SECONDARY DISPLAY MODE.....	18
UTILITY MODE	19
Reset Configuration State.....	19
Reset Security State	19
Reset All State	19
Reset Software State	19
PROFIBUS PA Address (PA.ADR) State.....	19
Serial Number (SER.NUM) State.....	20
Device Identification Select (ID.SEL) State	20
Damping State	20
TRANSMITTER'S FIELDBUS FUNCTIONALITY.....	20
Electronic Device Data (GSD Files).....	20
Identification Number.....	21
Electronic Device Description (EDD).....	21
Device Type Manager (DTM).....	21
DEVICE BLOCKS	21
Cyclical Configuration Data	33
HARDWARE DIP SWITCH FUNCTIONS	34
SIMPLE FAULT FINDING.....	35
DIAGNOSTIC INFORMATION.....	36
Calibration Diagnostic Messages	38
Additional Diagnostic Messages	38
SENSOR TROUBLESHOOTING	38
Visual Sensor Inspection.....	38
Sensor Electronic Test	39
DIAGNOSTIC INFORMATION RECEIVED FROM THE FIELDBUS.....	40
DISMANTLING AND REASSEMBLY	43
SPECIFICATIONS	44
GLOSSARY OF PROGRAMMING TEXT PROMPTS	47
PRODUCTS & CUSTOMER SUPPORT	50

INTRODUCTION

The **TB82PH pH/ORP/pION PROFIBUS PA Transmitters** are a modular range of field mounted, microprocessor-based instruments. Accurate and reliable measurement of pH, ORP (Oxidation-Reduction Potential) and pION (specific ion) parameters is provided, in the even most difficult and hazardous industrial environments.

The TB82 family of transmitters offers Analog (4-20 mA output), Analog with HART digital communication, PROFIBUS PA, and FOUNDATION Fieldbus product versions.

This manual describes the features, installation requirements, configuration, commissioning, and calibration procedures related to the TB82PH pH/ORP/pION PROFIBUS PA Transmitter.

The delivery of the TB82PH PROFIBUS PA device includes the device data (GSD) and Device Type Manager (DTM) files.

Refer to the supplementary documentation section to obtain additional information on the PROFIBUS communication protocol and device installation.

SUPPLEMENTARY DOCUMENTATION

Reference information regarding PROFIBUS design and structure can be found in the following documents:

- Document 30 Fb 10 Fieldbus Solutions from ABB - Technical brochure
- IEC 61158-2 Fieldbus standard for use in industrial control systems – Part 2: Physical Layer specification and service definition
- EN 50170-2 General Purpose Field Communication System
- DIN 19245 Measurement and Control PROFIBUS

Visit the Internet site for online/up-to-date information: www.abb.com or www.profibus.com.

TRANSPORT

After factory calibration, the instrument is packed in a carton, intended to provide protection from physical damage.

STORAGE

The instrument does not require any special treatment if stored as dispatched and within the specified ambient conditions level listed in the Specification section. The storage period does not have a limit.

HANDLING

The instrument does not require any special precautions during handling, though care should be observed.

PRODUCT IDENTIFICATION

The following data plates shown in Figure 1 identify the instrument.

The Nameplate (Reference A) provides information concerning the product identity code (i.e., nomenclature), product name, operating voltage range, output type, serial number, test personnel badge number, and dielectric strength verification stamp.

The Agency Approval label (Reference B) is included when the transmitter is purchased for compliance with hazardous area regulations (e.g., intrinsic safety protection) for a specific country (e.g., CSA, FM, or ATEX).

EC conformance is identified using a CE label (Reference C). Optional tagging specified by customer requirements is provided via a supplementary tag (Reference D).




Figure 1 – Product Identification

PRINCIPLE OF OPERATION

The TB82PH pH/ORP/pION PROFIBUS PA Transmitter provides on-line measurement of liquid properties in industrial environments using an advanced microprocessor-based technology. Fieldbus wiring provides transmitter power and digital communication based on the PROFIBUS PA protocol. The TB82PH transmitter can be installed indoors or outside due to its IP65 and NEMA 4X environmental enclosure ratings. Cable glands for field wiring ensure adequate sealing barriers to ambient conditions while maintaining the environmental ratings of the transmitter.

The Human Machine Interface (HMI), shown in Figure 2, consists of a tactile keypad having four universal keys, one hidden key, and a custom LCD. The LCD has a three and one-half digit numeric region that displays the process variable, a six-digit alphanumeric region that displays secondary information and programming prompts, and several status-indicating and programming icons. Each of the four universal keys is located under a set of icons. In each of the instrument modes and states, one icon over a given key will be illuminated and will represent that key's function. These assignments vary and depend upon the programming mode or state the transmitter is currently occupying. In addition to the key assignments, text strings located in the six character alphanumeric field are used as programming prompts.




Figure 2 – TB82PH HMI

The signal conditioning circuitry contained in the transmitter is designed to process the high-impedance, galvanic signal generated by glass electrode pH sensors. This circuit processes the sensor signal into a format that is transferred to a secondary circuit. The secondary circuit uses a microprocessor to compute the precise primary variable compensating for the combined effects of circuit tolerances, sensor calibration information, and temperature effects. Permanent memory stores

transmitter and sensor specific information such as:

- Non-modifiable data such as the Manufacturer's Identifier, the Device Identifier, the hardware and software versions.
- Modifiable data such as transmitter configuration information, sensor calibration data, and security passwords.

The sensor and all electronic parts are galvanically isolated from the transmitter body. This isolation is verified at the factory using a Dielectric Strength Test.

The instrument consists of three functional circuits that have been divided into three unique Printed Circuit Board (PCB) assemblies:

- Signal Conditioning Input Assembly
- Microprocessor/Display Assembly
- Power Supply/Communication Assembly

A block diagram representing the electronic functional areas is shown in Figure 3. The flow of information starts from the sensor input and moves through the transmitter to the fieldbus interface that produces a digital signal compliant with IEC-61158-2 (see Supplementary Documentation). The digital communication and HMI capabilities provide for remote or local access to transmitter parameters for configuration and maintenance operations.

The fieldbus furnishes transmitter power and can be configured as a point-to-point, tree, Daisy Chain, or Trunk/Spurs network. Modulating the base quiescent current generates the communication signals. The quiescent current value is used as a reference in order to establish the number of devices that can be installed on a single bus line.

Data is transmitted over the bus using digital, bit-synchronous Manchester II coding at a baud rate of 31.25 kbit/sec. Figure 4 shows an example of a typical bus configuration.

... PRINCIPLE OF OPERATION




Figure 3 – Functional Block Diagram for TB82 PROFIBUS PA Transmitter




Figure 4 – Typical Bus Configurations

INSTALLATION

Besides the normal precautions for storage and handling of electronic equipment, the transmitter contains static sensitive devices. Since semiconductors can be damaged by the direct discharge of static electricity, avoid contact with terminal block conductors and electronic components on the circuit board.

When mounting the transmitter, choose a location that has ample clearance for the removal of the front bezel and rear cover. The location should provide easy access for maintenance procedures and not be in a highly corrosive environment. Excessive mechanical vibrations and shocks as well as relay and power switches should not be in the immediate area. Signal wiring should not be placed in conduit or open trays that contain power wiring for heavy electrical equipment. Field wiring should meet wiring practices appropriate for fieldbus devices (See Supplementary Documentation).

The transmitter can be pipe, hinge, wall or panel mounted. Use the appropriate figure below to assist in the mechanical installation of the transmitter.



Warning.

For installation in Hazardous Areas, i.e. areas with danger of fire and/or explosion, irrespective of the protection mode used, the installation must be carried out in accordance with local authority regulations. Ensure also that the temperature of the transmitter does not exceed the value indicated in the Safety Marking plate.




Figure 5 – Pipe Mounting Detail




Figure 6 – Hinge Mounting Detail




Figure 7 – Wall Mounting Detail




Figure 8 – Panel Mounting Detail

ELECTRICAL CONNECTIONS



Warning.

Use this equipment only in those classes of hazardous locations listed on the nameplate. Uses in other hazardous locations can lead to unsafe conditions that can injure personnel and damage equipment.

The bus powers the transmitter; thus, power and fieldbus signals share the same pair of wires. Separate conduit for power and sensor wiring is encouraged. Prior to entering the instrument housing, terminate rigid conduit and install a short length of flexible conduit to reduce stress to the housing. Signal wiring must not come in close proximity to high-power equipment or to cabling from such equipment. Wiring must be in accordance to the applicable local codes and fieldbus requirements (see Supplementary Documentation). Bus cabling must conform to IEC 61158-2.

The terminal blocks located in the rear of the transmitter accept wire sizes from 12 to 24 AWG. Pin-style terminals should be used for all connections. The terminal block label identifies all electrical connections and should be followed when wiring the transmitter. Observance to polarity for power connections is not required; however, polarity indications have been provided for consistence. Voltage requirements are listed in the Specifications and must be observed. Ensure the power supply that provides bus power is complaint with IEC 61158-2.

Normal grounding practice is to terminate all grounds in the control room side, in which case the field side of the screen should be adequately protected to avoid contact with metallic objects. For bus-powered systems, the grounding of the shield should be close to the power supply unit. For IS systems, the grounding should be at the safety barrier earth connection. The transmitter case should be grounded. Ground connections are internally (in the terminal compartment) and externally provided.




Figure 9 – Sensor and Power Wiring

... ELECTRICAL CONNECTIONS




Figure 10 – BNC Adapter Sensor Connections

To ensure fault-free communication, the bus must be properly terminated at both ends. Only approved bus terminators must be used for intrinsically safe circuits. The specific noise immunity and emitted interference are only guaranteed when bus screening is fully effective (e.g., ensuring that screening is maintained through any existing junction boxes.) Appropriate equi-potential bonding must be provided to avoid differences in potential among the individual plant components.

The address range for PROFIBUS devices is 0 to 126. Per the PROFIBUS specification, the default device address is set to 126. This address must be changed before two or more field devices are placed on a PROFIBUS segment. Usually lower addresses are reserved for master devices; thus, use an address that lies between 30 through 125. Marking the device with the set address is also recommended.

The number of transmitters or devices that can be connected to a bus is primarily dependent on the transmitters'/devices' power consumption, the type of cable, number of spurs, total cable length of the bus, and intrinsically safe requirements.

The table below lists some considerations that have been identified:

Parameters	Specification	
Data Rate	31.25 Kbits/s	
Type	Voltage	
Topology	Bus/tree	
Bus Power	DC	
Intrinsically Safe	No	Yes
Max Nr of devices (1)	32	6
Max cable length (2)	1900 m	
Max spurs length (3)	120 m	

Notes:

- 1) The number of devices is dependent on several physical parameters (e.g., power consumption, bus cable, device IS parameters, etc.).
- 2) Length includes bus and all spurs lengths.
- 3) The maximum Spur length with one device is 120 m; 30 m less for each addition device.

For further information, see Supplementary Documentation list at the beginning of this manual.

LOCAL HMI OPERATING PROCEDURES

The TB82PH pH/ORP/pION PROFIBUS PA Transmitter has seven main operating modes: Measure, Calibrate, Output/Hold, Configure, Security, Secondary Display and Utility. Within each mode, several programming states containing functions specific to the related mode are available.

Using a patented HMI, programming or accessing information from the transmitter's front panel is quick and easy. The LCD contains nine regions that provide the user with information on the process variable, engineering units, mode of operation, fault indication, secondary variable, and function key assignment (see Figure 2). The primary process variable is displayed in the three and one-half digit region. The Engineering Unit region supports this region. These display regions are active in all modes of operation; however, some programming states also use these regions for data entry.

The secondary variable is displayed in the six-character region. This display region is used for displaying secondary and fault information in the Measure Mode and textual prompting in all other modes.

Due to the limited number of characters supported by the secondary display, many of the prompts take the form of a text abbreviation (see Glossary of Programming Text Prompts for a list of abbreviations.) The secondary display region is active in all modes of operation.

A five-button, tactile keypad is located on the front panel of the instrument. Four of the buttons are embossed to easily show their location. A fifth, hidden button located at the top, center of the keypad provides access to functions that are infrequently used. The embossed keys do not have a pre-assigned function. Icons are energized over the key to indicate their function. If a key does not have an icon energized above its location, this key does not have a function and will not initiate an action when pressed. The first table below lists all key functions.

The Measure Mode is the normal operating mode of the transmitter and is the default mode upon power-up. The Measure Mode is the starting point for entry into other modes of operation. Each mode contains a unique set of transmitter functions or states. These modes and their related functions are listed in the second table below.

Icon	Key Function
Exit to MEASURE	Escapes back to the Measure Mode from all other modes or programming states of operation. This function is not available in the Measure Mode.
FAULT Info	Accesses information on diagnostic problem or error conditions. Displays this information as a short text string and code. This function is only available in the Measure Mode.
SELECT	Selects the mode or programming state of operation shown in the secondary display region.
ENTER	Stores configured items and data into memory.
NEXT	Increments through a series of programming states.
YES	Affirms the action that is about to take place.
NO	Denies the action that is about to take place.
MENU	Increments through the modes of operation.
▲	Increases numeric values or moves through a series of parameters.
▶	Moves the flashing data entry value one space to the right.
▼	Decreases numeric values or moves through a series of parameters.

Mode	Function
Measure	Used to display the process and secondary variables – the normal operating mode for the transmitter.
Calibrate	Used to calibrate input devices (i.e., the process and temperature sensors).
Out/Hold	Used for viewing critical parameters found in the Transducer and Analog Input Function Blocks.
Configure	Used to configure transmitter functions such as temperature compensation, temperature sensor type, and measurement electrode type.
Security	Used to enter password protection for the Calibrate and Configure Modes.
Display	Used to select the variable that will be shown in the secondary display region when the transmitter is in the Measure Mode.

MEASURE MODE

The Measure Mode is the normal operating mode of the transmitter. In this mode, the process variable, fault conditions, and secondary display information are displayed. From the Measure Mode, other modes of operation and fault information can be accessed.

When a user enters an operating mode or state and does not return to the Measure mode as the final step, the transmitter automatically returns to the Measure Mode after 20 minutes of unattended use.

The process variable is shown in the primary display area. The value of this variable is dependent on the configured analyzer, temperature compensation type, temperature value, and sensor output. The engineering units for the process variable are dependent only on the configured analyzer. The table below lists the analyzer types and corresponding engineering units.

Analyzer Type	Engineering Unit
pH	pH
ORP	mV (millivolts)
pION	mV (millivolts)

The secondary display has the ability to show a large variety of information. Since the display area only has six characters, only one item can be shown at any given time. Typically, this region will be used for

displaying the process temperature in degrees Celsius; however, it can be changed to display the process temperature in degrees Fahrenheit, reference impedance in kohms, sensor output in millivolts, function generator output in percent, and firmware revision.

Fault information can only be accessed from the Measure Mode. During a fault condition, the FAULT warning icon above the process variable display region will blink. The FAULT Info key will also become active and can be used to obtain a text description of the fault condition. Pressing the FAULT Info key progressively moves from one fault to the next until all faults have been shown. Once all faults have been interrogated, the FAULT icon stops blinking and will remain energized until all faults have been removed. If a new fault condition is detected, the FAULT icon will begin to blink to inform the user of the newly detected condition.

The MENU key provides access to all other modes of operation. Pressing this key moves the transmitter to the next operating mode. Visual feedback is provided in two manners: the mode indication arrow moves to the next mode of operation (e.g., Calibrate) and the secondary display shows the text string representing the new mode of operation (e.g., CALIBR).

CALIBRATE MODE

The Calibrate Mode provides the ability to calibrate the sensor and temperature inputs. These functions include process variable, temperature, edit, and reset calibration. Figure 11 shows the Calibrate States and key assignments for each state.

Process Variable Calibrate State

The Process Variable Calibrate State contains two calibration procedures: One Point or Process Calibration (1PT.CAL) and Two Point or Buffer/Standard Calibration (2PT.CAL). The One Point Calibration procedure provides the ability to adjust the sensor's offset characteristics to compensate for differences in the ionic strength between buffer solutions and process liquid (i.e., junction potentials). Improved accuracy can be realized by conducting a one-point calibration with the sensor in its final install location. Typically, the transmitter is verified against an external validation device using a grab sample.




Figure 11 – Screen Flow Diagram for Calibrate Mode of Operation.

The Two-Point Calibrate State conducts offset and slope adjustments on the sensor input to determine its response characteristics. This calibration is typically conducted before the sensor is installed into its final location and periodically during the life of the sensor as the response of the sensor begins to decrease. This calibration procedure uses buffers or standards depending on the type of sensor (e.g., pH, ORP).




Figure 12 – Screen Flow Diagram for Process Variable Calibrate and One-Point Calibrate States of Operation

Invalid calibration values will generate the text string BAD.CAL (i.e., Bad Calibration), and the calibration value will not be accepted. If the values are valid, the Efficiency (shown as a percentage of theoretical) will be shown. Pressing the NEXT key displays the Offset value. At this point, the user can return to the Process Sensor Calibrate State by pressing the NEXT key or to the Measure Mode by pressing the Exit to MEASURE key.




Figure 13 – Screen Flow Diagram for Two-Point Process Calibration

Temperature Calibrate State

The Temperature Calibrate State is a smart calibration routine that allows for both single- and dual-point calibration. By calibrating the temperature at two points that are at least 20°C apart, the transmitter adjusts the offset and slope. Since this routine only uses the most recent calibration data, calibrations can be conducted throughout the sensor's life to ensure accurate measurement of the temperature. If an incorrect calibration has been entered, the Reset Calibrate State can restore the calibration to factory settings.




Figure 14 – Screen Flow Diagram for Temperature Calibrate State of Operation

Edit Calibrate State

The Edit Calibrate State allows a user to manually adjust the sensor and temperature slope and offset values. Though this function may not be suitable for many applications, the Edit Calibrate State facilitates quick and easy access to these calibration values for troubleshooting purposes and to make separate adjustments to process variable and temperature data.




Figure 15 – Screen Flow Diagram for Edit Calibrate State of Operation

Reset Calibrate State

The Reset Calibrate State sets the sensor and temperature calibration data to factory values. This state purges calibration history and should be initiated before calibrating a new sensor.

When interrogating the calibration values after a reset has been performed, the slope and offset values for both the process and temperature sensors will be set to 100%/1.000 and 000 millivolts/000C, respectively.




Figure 16 – Screen Flow Diagram for Reset Calibrate State of Operation



Note

The Reset Calibrate State will reset all calibration values; therefore, the process sensor and temperature sensor will require calibration after performing the Reset Calibrate procedure.

OUTPUT/HOLD MODE

The Output/Hold Mode provides the ability to view a limited number of Transducer Block (TB) and Analog Input (AI) Function Block parameters. Parameter viewing is limited to the TB Process Variable Range (RANGE_1), AI Block mode status, and AI Output Value.

The TB Range State contains the process value low and high range limits. These represent the range limits used to define the Output Value.

The AI Block information shows the current mode (i.e., Out of Service – OOS, Auto, or Manual) of the specified function block (i.e., AI1 or AI2). For in-service blocks, information for the Output is shown. If the block is out of service, the output value will be equal to the corresponding AI Block FSAFE_VALUE.




Figure 17 – Screen Flow Diagram for Output/Hold Mode and States of Operation

CONFIGURE MODE

The Configure Mode establishes the operating parameters of the transmitter. These parameters include analyzer type, temperature sensor type, temperature compensation type, linearity type and diagnostic functionality.

Upon selecting the Configure Mode at the local HMI, a query to Modify or View the configuration will be presented. The Modify Configure State enables analyzer options to be set and saved into memory.

Since the Modify State can be secured, the configuration of the transmitter can be viewed using the View Configure State without violating secured settings. To provide quick and easy access to edit transmitter parameters from the View Configure State, a Hot Key function provides immediate access to the viewed parameter using the ENTER key. If the Modify Configure State is secured, the security code will be requested before entering into the Modify Configure State.

Any changes to the transmitter configuration must be saved. Pressing the Exit to MEASURE key prompts the user to “SAVE?” their changes. Pressing the YES key saves the new configuration and returns the transmitter to the Measure Mode. The NO key discards the changes and returns the transmitter to the Measure Mode.




Figure 18 – Screen Flow Diagram for Modify/View and Save States of Operation

The Modify Configure State contains all the available settings that establish the functionality of the transmitter. Upon receipt of the transmitter, the default configuration (unless otherwise specified by the customer when ordering the transmitter) will be active once the transmitter has been powered. See the Configuration Data Sheet at the end of this manual for default configuration settings. Before installing the transmitter, the configuration should be modified to reflect the final installed application. The Table below describes each of the Modify Configure States and their function.

State	Function
ANALYZR	Used to define the type of analyzer. Choices include pH, ORP, and pION.
TMP.SNS	Used to define the type of temperature sensor. Choices include None, Pt100, and 3k Balco.
TC.TYPE	Used to define the type of temperature compensation. Choices include Manual Nernstian, Automatic Nernstian, and Automatic Nernstian with Solution Coefficient.
LIN.TYP	Used to characterize the Function Generator response curve.
DIAGS	Used to set the sensor diagnostics ON or OFF.




Figure 19 – Screen Flow Diagram for Modify Configure States of Operation

Analyzer State

The Analyzer State sets the type of measurement (i.e., Process Value). The setting of this parameter must match with the type of sensor being used. Three choices are available and include pH, ORP, and pION.




Figure 20 – Screen Flow Diagram for Analyzer and pH Analyzer States of Operation

For transmitters configured as a pH Analyzer, three types of measuring electrode settings are available: Glass (PH.GLAS), Antimony (ANTMNY), and CUSTOM. Glass and Antimony measuring electrode types use the following Isopotential Point and Asymmetric Potential settings:

pH Measuring Electrode Type	Isopotential Point (pH)	Asymmetric Potential (mV)
Glass	7	0
Antimony	-0.8	140
Custom	User Defined	User Defined

The CUSTOM Sensor State provides the ability to set the ISO.PT and ASY.POT. This setting would be used on sensors that use non-conventional measuring and reference electrochemical electrode technology.

The ORP and PION Analyzer States do not require measuring electrode information. These states strictly convert the raw millivolt signal from the sensor to a post-calibrated value that is displayed on the local HMI and transmitted onto the bus.

The final step in setting the Analyzer State is defining the reference electrode impedance trigger point (REF Z). When the transmitter detects a reference electrode impedance that exceeds the Ref Z value, a diagnostic alert is displayed at the local HMI and sent onto the bus. This alert indicates that the sensor's reference electrode requires servicing. Typically, a new ABB sensor will have a reference impedance of 1 to 2 kohms. Performance of the reference electrode is typically unaffected up to as high as 100 kohms, the default REF Z value. Adjustment to other resistance values up to 1000 kohms is allowed; however, the user must determine the acceptable performance of the sensor and adjust the resistance values accordingly.

Temperature Sensor State

The Temperature Sensor State configures the transmitter for use with a Pt100, 3 kohm Balco, or no RTD (NONE).




Figure 21 – Screen Flow Diagram for Temperature Sensor State of Operation

Temperature Compensation State

Temperature affects the process variable in two ways. The first effect, Nernstian, causes the sensor output

to increase with increasing temperature. In the case of a pH sensor, the increase is roughly 0.03 pH Units per pH Unit from 7 pH per 10°C. The second temperature effect is on the actual chemistry of the solution. Since ion disassociation can be a function of temperature, ion properties such as pH, ORP, and plon are affected by changes in the process temperature. These effects can be empirically determined and included in the temperature compensation algorithm using the Automatic Nernstian with Solution Coefficient Temperature Compensation option.

The Temperature Compensation State sets the desired compensating method. The three states of temperature compensation include Manual Nernstian (MANUAL), Automatic Nernstian (AUTO), and Automatic Nernstian with Solution Coefficient (AUT.SOL). The table below provides a brief description of each type of temperature compensation.

State	Function
MANUAL	Used when a fixed temperature value can be applied instead of a measured value. The initial value is set at 25°C. Use the Temperature Calibrate State to change the fixed temperature value. Nernstian compensation is applied using the fixed temperature value.
AUTO	Used when a temperature sensor is providing a measured temperature value. Nernstian compensation is applied using the measured value.
AUT.SOL	Used when a temperature sensor is providing a measured temperature value. Nernstian compensation with a solution coefficient is applied using the measured value.

Figure 22 shows the selection of temperature compensation type.




Figure 22 – Screen Flow Diagram for Temperature Compensation State of Operation.

SECURITY MODE

The Security Mode establishes password protection against unauthorized changes to transmitter functions. Password protection can be assigned to the Security, Calibrate, and Configure Modes. Additional Security functions are available in the Physical Block and will be discussed in Physical Block Section.

The Security Mode provides password protection of critical operating environments. When in the Security Mode, toggling the primary display between security OFF and ON sets password protection for the mode displayed in the secondary display area. When one or more modes have been secured, the security password must be correctly entered at the Password State before entry into the Security Mode is allowed. One password assignment applies to all secured modes.

To prevent misuse of the security function by a malicious user, the Security Mode can be password protected without securing one or both other modes of operation.




Figure 25 – Screen Flow Diagram for Security Mode of Operation

SECONDARY DISPLAY MODE

The secondary display region can be configured to display one of a multitude of process, sensor, or transmitter parameters in the Measure Mode. The Secondary Display Mode provides the ability to view these parameters or to set one parameter active in the Measure Mode. These parameters include temperature in °C, temperature in °F, sensor output, reference impedance, function generator output, and software revision. The NEXT key cycles through the parameters, while the ENTER key sets the displayed parameter as the secondary display value when in the Measure Mode.

For temperature parameters, a superscript 'M' at the end of the temperature value indicates that the transmitter's Temperature Compensation State is set to Manual.




Figure 26 – Screen Flow Diagram for Secondary Display Mode of Operation

UTILITY MODE

The Utility Mode provides access to powerful functions not used during normal operating conditions. These functions have been separated into two categories: Factory and User. Factory functions are strictly reserved for factory personnel. User functions include Reset Configuration to default settings, Reset Security password, Reset All parameters to default settings, Software Reboot, setting the Device Address, entering the Device Serial Number, setting the Device Identification that determines the active device profile, and Damping functions.

The User States can be accessed using the hidden fifth key located top, center of the keypad above the display window (see Figure 2). Once the hidden key has been pressed, the secondary display will have the prompt 'USER' shown. The SELECT key provides access to the User States.




Figure 27 – Screen Flow Diagram for User States of Operation

Caution
 Since the Utility Mode contains functions that can have a dramatic effect on the proper function of the transmitter, the Transducer Block should be put Out Of Service until all transmitter parameters have been properly set. For convenience, the Transducer Block can be put Out Of Service at the local HMI; however, once the transmitter is returned to the Measure Mode of Operation using the Exit to MEASURE key, the transmitter will automatically return the Transducer Block into its previous state.

Reset Configuration State

The Reset Configuration State returns the configuration to factory default settings. If the Configure Mode has been password secured, the same password will be required to perform a reset to the transmitter's configuration. See the Configuration Worksheet at the end of this manual for software default settings.

Reset Security State

The Reset Security State returns the security to factory default settings. The factory default is security OFF for all applicable modes (i.e., Security, Calibrate, and Configure). To reset the security, the password **732** must be entered when requested by the transmitter.

Reset All State

The Reset All State returns all transmitter parameters back to factory defaults. This includes calibration, configuration, security, and secondary display values. To reset all transmitter parameters, the password **255** must be entered when requested by the transmitter.

*** Note:**
 All user specific information will be lost once a Reset All or Reset Configuration has been initiated. Before initiating these reset functions, record configuration data to make reconfiguration quicker.

Reset Software State

The Soft Boot State initiates a software reset. A software reset repeats the boot-up and self-test process. All programmable instrument parameters are unaffected by this function.

PROFIBUS PA Address (PA.ADR) State

Each device on a bus segment must have a unique address. An address range of 0 to 126 is possible. The default address of the TB82PH PROFIBUS PA Transmitter as well as most competitive devices is 126; thus before operating two or more new devices on a single segment, the address should be set to a new value.

The PA Address State facilitates access to the device address. When changing the address to a value less than 100, always use a leading zero (e.g., 050).

Serial Number (SER.NUM) State

The device serial number represents a unique production number of the device assigned by the manufacturer. Since this identifier must have a unique value, the Serial Number State is password protected to prevent the accidental modification of its value; however, if access is required, contact the factory for further instructions.

Device Identification Select (ID.SEL) State

A PROFIBUS host uses the device address and identification number to identify PROFIBUS devices. Identification (ID) numbers can be Profile or Manufacturer specific. The TB82PH transmitter ID can be set to one of the following:

- Profile specific ID for PROFIBUS PA 3.0 Analyzer (9750 Hex).
- Manufacturer specific ID provided by PNO (5101 Hex).

The TB82PH device meets all requirement of the PROFIBUS PA 3.0 Analyzer Profile using either setting; however, the Manufacturer Specific ID fully utilizes all the built-in functionality of the TB82 transmitter. When using the Manufacturer Specific ID, the manufacturer GSD (ABB 5101.GSD), DTM, or EDD device file must be used.

When using the Profile Specific ID, the standard PROFIBUS PA 3.0 Analyzer GSD device file provided by the PNO (PA139750.GSD) must be used.

Damping State

The Damping State applies a lag function on the process input. The Damping State values affect Process and Secondary Value 4 (Function Generator) transmitted values. Application of the FV_VALUE in the AI blocks will apply an additional damping on the mapped variable. To adjust the Damping State, the password **367** must be entered when requested by the transmitter.

TRANSMITTER'S FIELDBUS FUNCTIONALITY

The TB82 PROFIBUS PA transmitter series meets the requirements outlined in the Analyzer Profile for Process Control Devices, Version 3.0, published by the PROFIBUS-PA Working Group. PROFIBUS is a vendor-independent fieldbus standard for manufacturing and process automation and for building technologies. This fieldbus technology is defined in the international standard EN50170 that is available to all vendors of such equipment. The PROFIBUS family encompasses three types of protocols:

- PROFIBUS-DP (Decentralized Peripherals)
- PROFIBUS-PA (Process Automation)
- PROFIBUS-FMS (Field Message Specifications)

Since these protocols are compatible, they can be combined in a single PROFIBUS network. PROFIBUS-DP and PROFIBUS-PA are specific designed for process automation.

PROFIBUS PA device communications uses the same pair of bus wires that provide power to the device. Two types of digital communication travel on a PROFIBUS network: cyclic and acyclic. Field devices provide real time process data to automation systems. This information is provided by cyclic services and includes information on the quality of the process data. Alarms, diagnostic data, and device configuration settings are also transmitted; however, these communications must be scheduled and acyclically transmitted.

The PA profile provides the necessary structure for field device interchangeability and interoperability by using the internationally recognized function block model. Below is a complete list of the function block contained in the transmitter:

- **Physical Block:** This block contains general device information such as device name, manufacturer, version and serial number.
- **Analog Input Function Block:** This block provides the value measured by the sensor and includes parameter status and scaling. Two Analog Input Function Blocks are available for control loop operations.
- **Transducer Block with calibration capability:** This block contains configuration parameters, calibration functions, and diagnostic data.

The transmitter allows different types of communication services as described by the Fieldbus Message Specification (FMS) Communication Profile. This profile defines the monitoring, control, regulation, operation, alarm handling, and archiving of automation systems.

Electronic Device Data (GSD Files)

Electronic device data sheets (i.e., GSD files) contain device information for device configuration and commissioning tools. The definition of each device parameter within the GSD reduces the need of an operator to consult the product instruction manual. TB82 GSD files are available free of charge from the GSD library on the PROFIBUS homepage at www.profibus.com.

Identification Number

PROFIBUS slaves and Class 1 master devices must be assigned an Identification (ID) number. Class 1 master devices use the ID numbers to identify the types of devices on a particular segment. These numbers are used to compare the connected devices to the ID number specified by the configuration tool. Data transfer from the configuration tool will not be initiated unless the ID numbers match. The TB82PH PROFIBUS PA transmitter can be configured to use either the Manufacturer Specific ID number (5101 Hex) or the standard Analyzer Profile 3.0 ID number (9750 Hex).

Electronic Device Description (EDD)

Electronic Device Description files define the device properties of the field device. These files provide the information that is used by engineering tools to simplify configuration and commissioning tasks. Device diagnostics are also decoded and quite

DEVICE BLOCKS

All variables and parameters of the transmitter are structured in blocks with respect to their assignment of components or functions. This structure represents the hardware and software makeup of the device and has been designed to support primary operational characteristics of the transmitter.

Blocks are logical groups of device functionality that define a particular application using a common model. In general, blocks process input parameters and events through one or more process algorithms and execution controls in order to produce the expected output parameters and events. Block parameters control the function and execution of the block and are visible over the fieldbus network.

Three types of blocks contain the profile parameters: Function Block, Transducer Block, and Physical Block.

The Physical Block contains the hardware specific characteristics associated with a device. This block does not have input and output parameters; instead, it contains an algorithm that monitors and controls the general operation of the physical device hardware. Physical Block parameters include but are not limited to the manufacturer's name, device name, and identification number. Only one Physical Block is included per device.

The Transducer Blocks connect input and output functions to the function blocks residing in the same device. It interfaces with sensor input hardware and provides a measured value and status to the connected function blocks. Transducer Block parameters include but are not limited to sensor type, temperature sensor type, calibration data and routines, calibration date and diagnostic conditions.

usefully when maintenance of the field device is necessary.

Device Type Manager (DTM)

The PROFIBUS User Organization has defined a system-wide device management technology: Fieldbus Device Tool (FDT). FDT provides a manufacturer-independent method of configuring, commissioning, and managing intelligent field devices using one engineering tool. Device parameterization is provided in the form of a Device Type Manager (DTM). A DTM functions in the same manner as a device driver, similar to those used on Personal Computers (PC). For PC's, device drivers integrate hardware components into the overall computer system (i.e., software and other hardware components). In a similar manner, a DTM contains all the functions and dialogs, including the user interface for the configuration, diagnosis and servicing of the fieldbus device.

Usually at least one Transducer Block is present per device.

The Function Blocks are fundamental for providing the control system behavior. Typical Function Blocks include Analog Input (AI) and Analog Output (AO) Blocks. The number of Function Blocks within a device is not limited.

The TB82PH PROFIBUS PA Transmitter has one Physical Block, two Analog Input Function Blocks (AI), and one Transducer Block with calibration and function generator capability. The following figure shows block elements for the TB82PH PROFIBUS PA Transmitter.




Figure 28 – Function Block Model Diagram

The following tables and diagrams contain information regarding block parameters and the structure of these parameters within the block. To assist in the interpretation of this information, the following list of column definitions is provided.

- Object Name – Lists the mnemonic character designation for the block object.
- Slot Number (Snum) -
- Slot Index (Sidx) – Defines the number corresponding to the sequence of the parameter relative to the beginning of the corresponding block in the object dictionary.
- Relative Index (Ridx) – The relative index is a logical offset of a parameter in a block.
- Object Type – Object type of the parameter value.
- Data Type – Data type of the parameter value. This value is either a simple variable name or a PROFIBUS Data Structure number (DS-n).
- Description – Provides a short text description of the block object.
- Bytes – Lists the memory size of the block parameter.
- Store - Defines the type of variable for the block parameter. 'S' represents a Static, non-volatile variable that is typically a device parameter such as the type of temperature sensor or variable linearization function. This variable can only be written during an acyclic process and if the

Access is Read/Write. Writing to a static parameter changes the static revision of the counter ST_REV. 'N' represents a Non-volatile variable that does not update the static revision. 'D' represents a Dynamic variable. The value for this variable is calculated by the block and can be read by another block. 'C' represents a Constant. This parameter does not change in the device.

- Access – Defines the access rights of the block parameter. 'R' represents a parameter that only has Read access. 'R/W' represents a parameter that has Read and Write access.
- Default – Lists the default setting for the listed block parameter during initial start up or when a Cold Start is initiated.
- Valid Range – Lists the valid range of selections for the listed block parameter.
- Note – Identifies additional information for the listed block parameter that is available at the end of the block object tables.

Device Management defines the directory of supported blocks and block parameters. The following table lists the Device Management parameter information.

DEVICE MANAGEMENT

Object Name	Description	Slot	Slot Index	Relative Index	Object Type	Data Type	Bytes	Store	Access	Default	Valid Range	Note
Standard Parameters												
HEADER	Directory Object Header	1	0		Array	Unsigned16	12	C	R			
COMPOSITE_LIST_DIRECTORY_ENTRY	Directory Index	1	1		Array	Unsigned16	12	C	R			
COMPOSITE_DIRECTORY_ENTRY	Directory Entries	1	2		Array	Unsigned16	16	C	R			
Reserved	Reserved	1	3 to 13									

The Physical Block includes data and parameters that defined the overall operation of the device. These parameters describe the hardware specific characteristics of the device. The following table lists the Physical Block parameter information.

PHYSICAL BLOCK

Object Name	Description	Slot	Slot Index	Relative Index	Object Type	Data Type	Bytes	Store	Access	Default	Valid Range	Note
Standard Parameters												
BLK_DATA	Block Data	0	180	0	Record	DS-32	20	C	R			
ST_REV	Static Revision	0	181	1	Simple	Unsigned16	2	N	R			
TAG_DESC	Tag Description	0	182	2	Simple	OctetString	32	S	RW	Spaces		
STRATEGY	Strategy	0	183	3	Simple	Unsigned16	2	S	RW	0		
ALERT_KEY	Alert Key	0	184	4	Simple	Unsigned8	1	S	RW	0		
TARGET_MODE	Target Mode	0	185	5	Simple	Unsigned8	1	S	RW	0x08	0x08=AUTO	
MODE_BLK	Block Mode	0	186	6	Record	DS-37	3	D	R			
	Actual				Simple	Unsigned8	1	D	R	0X08=AUTO		
	Permitted				Simple	Unsigned8	1	D	R	0X08=AUTO		
	Normal				Simple	Unsigned8	1	D	R	0X08=AUTO		
ALARM_SUM	Alarm Summary	0	187	7	Record	DS-42	8	D	R			
	Current				Simple	OctetString	2	D	R			L
	Unreported				Simple	OctetString	2	D	R			M
	Unacknowledged				Simple	OctetString	2	D	R			M
	Disabled				Simple	OctetString	2	D	R			M
Standard Physical Block Parameters												
SOFTWARE_REVISION	Software Revision	0	188	8	Simple	VisibleString	16	C	R	Current Revision		
HARDWARE_REVISION	Hardware Revision	0	189	9	Simple	VisibleString	16	C	R	Current Revision		
DEVICE_MAN_ID	Manufacturer Identification	0	190	10	Simple	Unsigned16	2	C	R	26 (ABB)		
DEVICE_ID	Device Identification	0	191	11	Simple	VisibleString	16	C	R	TB82PH PA 3.0		
DEVICE_SERIAL_NUM	Device Serial Number	0	192	12	Simple	VisibleString	16	C	R			
DIAGNOSIS	Device Diagnosis Information	0	193	13	Simple	OctetString	4	D	R			
DIAGNOSIS_EXTENSION	Additional Device Diagnosis Information	0	194	14	Simple	OctetString	6	D	R			
DIAGNOSIS_MASK	Diagnosis Definition	0	195	15	Simple	OctetString	4	C	R	0x33, 0xBC, 0x00, 0x80		
DIAGNOSIS_MASK_EXTENSION	Extended Diagnosis Definition	0	196	16	Simple	OctetString	6	C	R	0x07, 0x00....		
DEVICE_CERTIFICATION	Device Certification	0	197	17	Simple	VisibleString	32	C	R			
WRITE_LOCKING	Software Write Protection	0	198	18	Simple	Unsigned16	2	N	RW	2457	0=Locked; 2457=Unlocked	
FACTORY_RESET	Restore Factory Defaults	0	199	19	Simple	Unsigned16	2	S	RW		1=Reset; 2506=Warm Start; 2712=Reset Bus Address	
DESCRIPTOR	Descriptor	0	200	20	Simple	VisibleString	32	S	RW	Spaces		
DEVICE_MESSAGE	Device Message	0	201	21	Simple	VisibleString	32	S	RW	Spaces		
DEVICE_INSTAL_DATE	Device Installation Date	0	202	22	Simple	VisibleString	16	S	RW	Spaces		
LOCAL_OP_ENA	Local Operator Interface Enable	0	203	23	Simple	Unsigned8	1	N	RW	1	0=Disabled; 1=Enabled	
IDENT_NUMBER_SELECTOR	Identification Number Selector	0	204	24	Simple	Unsigned8	1	S	RW		0=Profile-Specific ID 1=Mfgr-Specific ID	
HW_WRITE_PROTECTION	Hardware Write Protection	0	205	25	Simple	Unsigned8	1	D	R	0	0=Disabled; 1=Enabled	
Analyzer Specific Physical Block Parameters												
DEVICE_CONFIGURATION	Device Configuration	0	216	36	Simple	VisibleString	32	N	R	"Transducer Block PV = pH Value"	"Transducer Block PV = pH Value" "Transducer Block PV = ORP Value" "Transducer Block PV = pION Value" (Based on TB_PRIMARY_VALUE_TYPE)	
INIT_STATE	Initialization State	0	217	37	Simple	Unsigned8	1	S	RW	2	2=Run	
DEVICE_STATE	Device State	0	218	38	Simple	Unsigned8	1	D	RW	2	2=Run; 5=Maintenance	K
GLOBAL_STATUS	Global Status	0	219	39	Simple	Unsigned16	2	D	R			
TB82PH Specific Physical Block Parameters												
LCD_SECONDARY	Local Secondary Display	0	228	48	Simple	Unsigned8	1	S	RW	0	0=Deg.C; 1=Deg.F; 2=Sensor Input; 3=Ref.Z; 4=Function Generator; 5=Firmware Revision Table 5	
SECURITY_LOCK	Security Lock	0	229	49	Simple	Unsigned8	1	S	RW	1	0=Locked; 1=Unlocked	
CONFIGURATION_LOCK	Configuration Mode Lock	0	230	50	Simple	Unsigned8	1	S	RW	1	0=Locked; 1=Unlocked	
CALIBRATION_LOCK	Calibration Mode Lock	0	231	51	Simple	Unsigned8	1	S	RW	1	0=Locked; 1=Unlocked	
PASSWORD	Security Password	0	232	52	Array	Unsigned8	3	S	RW	000	000 to 999	
DEV_ADD	Device Address	0	233	53	Simple	Unsigned8	1	S	RW	126	2 to 126	
PRIVATE_SW_REV	Private Software Revision	0	234	54	Simple	VisibleString	6	C	R	Current Revision		
PRIVATE_HW_REV	Private Hardware Revision	0	235	55	Simple	VisibleString	6	C	R	Current Revision		
VIEW_1	View 1	0	240	60	View_1	OctetString	20	C	R			H

The Transducer Block contains block parameters that configure the device's functionality. It insulates the sensor characteristics and signal conditioning from the other device Function Blocks. Specifically, it interprets the sensor signal based on configured values, applies factory and process calibration data, compensates for temperature and process effects, and converts the resulting values in the configured Engineering Units that can be used by the Analog Input Blocks contained within the device.

The following diagram illustrates the Transducer Block design. Note, AI1 is permanent linked to the Primary Variable. Only AI2 can be set to either the Primary Variable or any one Secondary Variable.




Figure 29 – Transducer Block Design Diagram

The following table lists the Transducer Block parameter information.

pH/ORP/pION TRANSDUCER BLOCK

Object Name	Description	Slot	Slot Index	Relative Index	Object Type	Data Type	Bytes	Store	Access	Default	Valid Range	Note
Standard Parameters												
BLK_DATA	Block Data	1	80	0	Record	DS-32	20	C	R			
ST_REV	Static Revision	1	81	1	Simple	Unsigned16	2	N	R			
TAG_DESC	Tag Description	1	82	2	Simple	OctetString	32	S	RW	Spaces		
STRATEGY	Strategy	1	83	3	Simple	Unsigned16	2	S	RW	0		
ALERT_KEY	Alert Key	1	84	4	Simple	Unsigned8	1	S	RW	0		
TARGET_MODE	Target Mode	1	85	5	Simple	Unsigned8	1	S	RW	0x08	0x08 =AUTO	
MODE_BLK	Block Mode	1	86	6	Record	DS-37	3	D	R			
	Actual				Simple	Unsigned8	1	D	R	0X08=AUTO		
	Permitted				Simple	Unsigned8	1	D	R	0X08=AUTO		
	Normal				Simple	Unsigned8	1	D	R	0X08=AUTO		
ALARM_SUM	Alarm Summary	1	87	7	Record	DS-42	8	D	R			
	Current				Simple	OctetString	2	D	R			L
	Unreported				Simple	OctetString	2	D	R			M
	Unacknowledged				Simple	OctetString	2	D	R			M
	Disabled				Simple	OctetString	2	D	R			M
Analyzer Profile Specific Transducer Block Parameters												
COMPONENT_NAME	Measurement Value	1	88	8	Simple	OctetString	32	S	RW	"TB82PH pH, ORP, pION		
PV	Primary Variable	1	89	9	Record	DS-60	12	D	R			
	PV Value in Primary Variable Unit				Simple	Float	4	D	R			
	PV Status				Simple	Unsigned8	1	D	R			
	PV Time (Not Used)				Simple	Date	7	D	R			
PV_UNIT	Primary Variable Unit	1	90	10	Simple	Unsigned16	2	S	RW	1422	1422=pH; 1243=mV	
PV_UNIT_TEXT	Additional Unit Information	1	91	11	Simple	OctetString	8	S	RW	Spaces		
ACTIVE_RANGE	Number of the currently active range	1	92	12	Simple	Unsigned8	1	S	RW	1	1	
AUTORANGE_ON	Auto-range Switch	1	93	13	Simple	Boolean	1	S	RW	1	0 = Auto range OFF 1 = Auto range ON	
SAMPLING_RATE	Sampling Rate in milliseconds	1	94	14	Simple	Time_diff	4	S	RW	50 msec	50 msec	
NUMBER_OF_RANGES	Number of Ranges	1	105	25	Simple	Unsigned8	1	N	R	1		
RANGE_1	Primary Value Range	1	106	26	Record	DS-61	8	N	RW			
	Beginning of range				Simple	Float	4	N	RW	0 pH	Table 3	
	End of range				Simple	Float	4	N	RW	14 pH	Table 3	
TB82PH Specific Transducer Block Parameters												
PRIMARY_VALUE_TYPE	Primary Value Type	1	107	27	Simple	Unsigned16	2	S	RW	111	111=pH; 114=ORP; 118=plon Table 1 & 3	A
CAL_POINT_HI	High Calibration Point	1	108	28	Simple	Float	4	S	RW	14 pH	Table 3	
CAL_POINT_LO	Low Calibration Point	1	109	29	Simple	Float	4	S	RW	7 pH	Table 3	
CAL_MIN_SPAN	Minimum Calibration Span	1	110	30	Simple	Float	4	N	R	1 pH		B
CAL_UNIT	Calibration Unit	1	111	31	Simple	Unsigned16	2	N	RW	1422	1422=pH; 1243=mV	
CAL_TEMP	Two-Point Calibration Temperature	1	112	32	Simple	Float	4	S	RW	25 °C		
EXIT_REMOTE_2_POINT_CAL	Exit Remote Two-Point Calibration Procedure	1	113	33	Simple	Unsigned16	1	S	RW	0	0=No; 1=Yes	
CAL_ONE_POINT	One-Point Calibration Value	1	114	34	Simple	Float	4	S	RW	0 pH	Table 3	
SENSOR_TYPE	Sensor Type	1	115	35	Simple	Unsigned16	2	C	R	103	103=mV	
SENSOR_RANGE	Sensor Range	1	116	36	Record	DS-36	11	N	R	-2 to 16 pH	Table 3	
SENSOR_SN	Sensor Serial Number	1	117	37	Simple	Unsigned32	4	S	RW	0		
SENSOR_CAL_METHOD	Sensor Calibration Method	1	118	38	Simple	Unsigned8	1	S	R	104	104=User trim standard calibration	
SENSOR_CAL_LOC	Sensor Calibration Location	1	119	39	Simple	OctetString	32	S	RW	Spaces		
SENSOR_CAL_DATE	Sensor Calibration Date	1	120	40	Simple	OctetString	16	S	RW	Spaces		
SENSOR_CAL_WHO	Person Conducting the Sensor Calibration	1	121	41	Simple	OctetString	32	S	RW	Spaces		
SECONDARY_VALUE_1	Secondary Value 1	1	122	42	Record	DS-33	5	D	R			
	Value				Simple	Float	4	D	R			
	Status				Simple	Unsigned8	1	D	R			
SECONDARY_VALUE_UNIT_1	Secondary Value 1 Unit	1	123	43	Simple	Unsigned16	2	S	RW	1001	1001=°C; 1002=°F	
SECONDARY_VALUE_2	Secondary Value 2	1	124	44	Record	DS-33	5	D	R			
	Value				Simple	Float	4	D	R			
	Status				Simple	Unsigned8	1	D	R			
SECONDARY_VALUE_UNIT_2	Secondary Value 2 Unit	1	125	45	Simple	Unsigned16	2	N	R	1243	1243=mV	
SECONDARY_VALUE_3	Secondary Value 3	1	126	46	Record	DS-33	5	D	R			
	Value				Simple	Float	4	D	R			
	Status				Simple	Unsigned8	1	D	R			
SECONDARY_VALUE_UNIT_3	Secondary Value 3 Unit	1	127	47	Simple	Unsigned16	2	N	R	1284	1284=Kohm	
SECONDARY_VALUE_4	Secondary Value 4	1	128	48	Record	DS-33	5	D	R			
	Value				Simple	Float	4	D	R			
	Status				Simple	Unsigned8	1	D	R			
SECONDARY_VALUE_UNIT_4	Secondary Value 4 Unit	1	129	49	Simple	Unsigned16	2	N	R	1342	1342=%	

Object Name	Description	Slot	Slot Index	Relative Index	Object Type	Data Type	Bytes	Store	Access	Default	Valid Range	Note
FUNC_GEN_LIN_TYPE	Function Generator Linearity Type	1	130	50	Simple	Unsigned8	1	S	RW	0	0=Linear; 1=Function Generator	
PH_SENSOR_TYPE	pH Sensor Type	1	131	51	Simple	Unsigned8	1	S	RW	0	0=Glass; 1=Antimony; 2=Custom	
TEMP_SENSOR_TYPE	Temperature Sensor Type	1	132	52	Simple	Unsigned8	1	S	RW	0	0=Balco; 1=Pt100; 2=None	
TEMP_COMP_TYPE	Temperature Compensation Type	1	133	53	Simple	Unsigned8	1	S	RW	0	0=Manual; 1=Automatic; 2=Automatic Solution	
REFZ	Reference Impedance Limit	1	134	54	Simple	Signed32	4	S	RW	100000 Ohm	100000 to 1000000 Ohm	
ISO_POTENTIAL	pH Iso-potential Point	1	135	55	Simple	Float	4	S	RW	7.0 pH	-19.9 to +19.9 pH	F
ASY_POTENTIAL	pH Asymmetric Point	1	136	56	Simple	Signed16	2	S	RW	0 mV	-1999 to +1999 mV	F
PH_10C	pH Solution Coefficient Value	1	137	57	Simple	Float	4	S	RW	0 pH	-9.99 to +9.99 pH	
MV_10C	ORP/plon/Ion Concentration Solution Coefficient Value	1	138	58	Simple	Float	4	S	RW	0 mV	-19.99 to +19.99 mV	
FUNC_GEN_END_POINTS	Function Generator End Point Values	1	139	59	Record	DS-61	8	S	RW			
	Lower end point				Simple	Float	4	N	RW	0 pH	Table 3	
	Upper end point				Simple	Float	4	N	RW	14 pH	Table 3	
FUNC_GEN_TABLE	Function Generator Relationship Table	1	140	60	Array	Float	40	S	RW	x,y 16.7, 16.7 33.3, 33.3 50.0, 50.0 66.7, 66.7 83.3, 83.3	Each point: 0.1 to 99.9 Monotonically increasing	
DIAGNOSTICS_ACTIVE	Sensor Diagnostic Enable/Disable Toggle	1	141	61	Simple	Unsigned8	1	S	RW	0	0=Disable; 1=Enable	
MANUAL_TEMP_SETPOINT	Manual Temperature Compensation Setpoint	1	142	62	Simple	Float	4	S	RW	25 °C	0 to 140 °C	G
MANUAL_TEMP_SETPOINT_UNIT	Manual Temperature Compensation Setpoint Unit	1	143	63	Simple	Unsigned16	2	S	RW	1001	1001=Deg. C; 1002=Deg. F	
TEMP_CAL-POINT	Temperature Calibration Point	1	144	64	Simple	Float	4	S	RW	25 °C	0 to 140 °C	G
TEMP_CAL_UNIT	Temperature Calibration Point Unit	1	145	65	Simple	Unsigned16	2	S	RW	1001	1001=Deg. C; 1002=Deg. F	
PV_CAL_SLOPE	Process Variable Calibration Slope Value	1	146	66	Simple	Float	4	S	RW	100%	40 to 150%	
PV_CAL_SLOPE_UNIT	Process Variable Calibration Slope Unit	1	147	67	Simple	Unsigned16	2	N	R	1342	1342=%	
PV_CAL_OFFSET	Process Variable Calibration Offset Value	1	148	68	Simple	Float	4	S	RW	0 mV	-1000 to +1000 mV	
PV_CAL_OFFSET_UNIT	Process Variable Calibration Offset Unit	1	149	69	Simple	Unsigned16	2	N	R	1243 (mV)	1243 = mV	
PV_CAL_RESET	Process Variable Reset	1	150	70	Simple	Unsigned8	1	S	RW	0	0=No; 1=Yes	
TEMP_CAL_SLOPE	Temperature Calibration Slope Value	1	151	71	Simple	Float	4	S	RW	100%	20 to 150%	
TEMP_CAL_SLOPE_UNIT	Temperature Calibration Slope Unit	1	152	72	Simple	Unsigned16	2	N	R	%	1342=%	
TEMP_CAL_OFFSET	Temperature Calibration Offset Value	1	153	73	Simple	Float	4	S	RW	0 °C	-40 to +40 °C	
TEMP_CAL_OFFSET_UNIT	Temperature Calibration Offset Unit	1	154	74	Simple	Unsigned16	2	N	RW	1001	1001=Deg. C; 1002=Deg. F	
TEMP_CAL_RESET	Temperature Calibration Reset	1	155	75	Simple	Unsigned8	1	S	RW	0	0=No; 1=Yes	
EXTENDED_STATUS	Extended Status	1	156	76	Array	Unsigned8	7	N	R			
VIEW_1	View 1	1	157	77	View_1	OctetString	26	N	R			

The Analog Input (AI) Function Blocks are used to publish Primary and Secondary Variable data onto the fieldbus segment. AI1 is fixed to the Primary Variable; however, AI2 can be mapped to any one of the five variables. These include and are limited to the primary process variable (i.e., pH or mV depending on PRIMARY_VALUE_TYPE) or any one of the secondary process variables (i.e., temperature, sensor input in mV, reference electrode impedance value in kohms, and function generator output in percentage units).

The following diagram illustrates the Analog Input One Function Block design.




Figure 30 – Analog Input One Function Block Design Diagram

The following table lists the Analog Input One Function Block parameter information.

ANALOG INPUT 1 - FUNCTION BLOCK

Object Name	Description	Slot	Slot Index	Relative Index	Object Type	Data Type	Bytes	Store	Access	Default	Valid Range	Note
Standard Parameters												
BLK_DATA	Block Data	1	16	0	Record	DS-32	20	C	R			
ST_REV	Static Revision	1	17	1	Simple	Unsigned16	2	N	R			
TAG_DESC	Tag Description	1	18	2	Simple	OctetString	32	S	RW	Spaces		
STRATEGY	Strategy	1	19	3	Simple	Unsigned16	2	S	RW	0		
ALERT_KEY	Alert Key	1	20	4	Simple	Unsigned8	1	S	RW	0		
TARGET_MODE	Target Mode	1	21	5	Simple	Unsigned8	1	S	RW	8	128=OOS, 16=MAN, 8=AUTO	
MODE_BLK	Block Mode	1	22	6	Record	DS-37	3	D	R			
	Actual				Simple	Unsigned8	1	D	R			
	Permitted				Simple	Unsigned8	1	D	R	128 (OOS) 16 (MAN) 8 (AUTO)		
	Normal				Simple	Unsigned8	1	D	R	8=AUTO		
ALARM_SUM	Alarm Summary	1	23	7	Record	DS-42	8	D	R			
	Current				Simple	OctetString	2	D	R			L
	Unreported				Simple	OctetString	2	D	R			M
	Unacknowledged				Simple	OctetString	2	D	R			M
	Disabled				Simple	OctetString	2	D	R			M
BATCH	Batch	1	24	8	Record	DS-67	10	S	RW			
Standard Analog Input Block Parameters												
OUT	Output	1	26	10	Record	DS-33	5	D	RW			C
PV_SCALE	Process Variable Scale	1	27	11	Array	Float	8	S	RW			
	High Range				Simple	Float	4	N	RW	14 pH	Table 3	D-2
	Low Range				Simple	Float	4	N	RW	0 pH	Table 3	D-2
OUT_SCALE	Output Scale	1	28	12	Record	DS-36	11	S	RW			
	High Range				Simple	Float	4	S	RW	14 pH		D-1 D-2
	Low Range				Simple	Float	4	S	RW	0 pH		D-1 D-2
	Units				Simple	Float	2	S	RW	pH	Table 7	
	Decimal Point				Simple	Interger8	1	S	RW	2		
LIN_TYPE	Linearity Type	1	29	13	Simple	Unsigned8	1	S	RW	0	0 = Linear	
CHANNEL	Channel	1	30	14	Simple	Unsigned16	2	S	RW	265	265 = PV Channel	
PV_FTIME	Process Variable Filter Time Constant	1	32	16	Simple	Float	4	S	RW	0	0 to 32 Seconds	
FSAFE_TYPE	Fail Safe Reaction Type	1	33	17	Simple	Unsigned8	1	S	RW	1	Table 6	
FSAFE_VALUE	Fail Safe Output Value	1	34	18	Simple	Float	4	S	RW	0		
ALARM_HYS	Alarm Hysteresis	1	35	19	Simple	Float	4	S	RW	0		
HI_HI_LIM	High-High Alarm Limit	1	37	21	Simple	Float	4	S	RW	14 pH		E-1
HI_LIM	High Alarm Limit	1	39	23	Simple	Float	4	S	RW	14 pH		E-1
LO_LIM	Low Alarm Limit	1	41	25	Simple	Float	4	S	RW	0 pH		E-1
LO_LO_LIM	Low-Low Alarm Limit	1	43	27	Simple	Float	4	S	RW	0 pH		E-1
HI_HI_ALM	High-High Alarm State	1	46	30	Record	DS-39	16	D	R			
HI_ALM	High Alarm State	1	47	31	Record	DS-39	16	D	R			
LO_ALM	Low Alarm State	1	48	32	Record	DS-39	16	D	R			
LO_LO_ALM	Low-Low Alarm State	1	49	33	Record	DS-39	16	D	R			
SIMULATE	Simulate	1	50	34	Record	DS-50	6	S	RW			
	Simulate Status					Unsigned8	1	S	RW	0x80		
	Simulate Value					Float	4	S	RW	0		
	Simulate Enable/Disable					Unsigned8	1	S	RW	0	0 = Disabled Not 0 = Enabled	
OUT_UNIT_TEXT	Output Unit Text	1	51	35	Simple	OctetString	16	S	RW	Spaces		

Object Name	Description	Slot	Slot Index	Relative Index	Object Type	Data Type	Bytes	Store	Access	Default	Valid Range	Note
TB82PH Specific Analog Input Block Parameters												
TREND_VAR	AI OUT Trend	1	61	45	Record	Device Specific	97	S	RW			
	Block Index					Unsigned16	2	S	RW	3	3 = AI1 Block	
	Parameter relative index					Unsigned16	2	S	RW	26	26 = AI OUT parameter	
	Sample type					Unsigned8	1	S	RW	0	0=Not initialized (Trend Disabled) 1=Instantaneous value	
	Sample interval (in milliseconds)					Float	4	S	RW	0		
	Last update (time of last trend value update relative to device startup)					DS-21	8	D	R			
	Sample value 1 to 16 (Sample value 1 = value of latest sample, sample value 16 = value of oldest sample)					Float	4x16	D	R			
	Sample status 1 to 16 (Sample status 1 = status of latest sample, sample status 16 = status of oldest sample)					Unsigned8	1x16	D	R			
VIEW_1	View 1	1	62	46	View_1	OctetString	18	N	R			J

The following diagram illustrates the Analog Input Two Function Block design.





Figure 31 – Analog Input Two Function Block Design Diagram

The following table lists the Analog Input Two Function Block parameter information.

ANALOG INPUT 2 - FUNCTION BLOCK

Object Name	Description	Slot	Slot Index	Relative Index	Object Type	Data Type	Bytes	Store	Access	Default	Valid Range	Note
Standard Parameters												
BLK_DATA	Block Data	2	16	0	Record	DS-32	20	C	R			
ST_REV	Static Revision	2	17	1	Simple	Unsigned16	2	N	R			
TAG_DESC	Tag Description	2	18	2	Simple	OctetString	32	S	RW	Spaces		
STRATEGY	Strategy	2	19	3	Simple	Unsigned16	2	S	RW	0		
ALERT_KEY	Alert Key	2	20	4	Simple	Unsigned8	1	S	RW	0		
TARGET_MODE	Target Mode	2	21	5	Simple	Unsigned8	1	S	RW	8	128=OOS; 16=MAN; 8=AUTO	
MODE_BLK	Actual Block Mode	2	22	6	Record	DS-37	3	D	R			
	Actual				Simple	Unsigned8	1	D	R	128 (OOS) 16 (MAN) 8 (AUTO)		
	Permitted				Simple	Unsigned8	1	D	R	8=AUTO		
	Normal				Simple	Unsigned8	1	D	R			
ALARM_SUM	Alarm Summary	2	23	7	Record	DS-42	8	D	R			
	Current				Simple	OctetString	2	D	R			L
	Unreported				Simple	OctetString	2	D	R			M
	Unacknowledged				Simple	OctetString	2	D	R			M
	Disabled				Simple	OctetString	2	D	R			M
BATCH	Batch	2	24	8	Record	DS-67	10	S	RW	0		
Standard Analog Input Block Parameters												
OUT	Output	2	26	10	Record	DS-33	5	D	RW			C
PV_SCALE	Process Variable Scale	2	27	11	Array	Float	8	S	RW			
	High Range				Simple	Float	4	N	RW	140 °C	Table 3	D-2 to D-6
	Low Range				Simple	Float	4	N	RW	0 °C	Table 3	D-2 to D-6
OUT_SCALE	Output Scale	2	28	12	Record	DS-36	11	S	RW			
	High Range				Simple	Float	4	S	RW	140 °C		D
	Low Range				Simple	Float	4	S	RW	0 °C		D
	Units				Simple	Unsigned16	2	S	RW	°C	Table 7	
	Decimal Point				Simple	Integer8	1	S	RW	2		
LIN_TYPE	Linearity Type	2	29	13	Simple	Unsigned8	1	S	RW			
CHANNEL	Channel	2	30	14	Simple	Unsigned16	2	S	RW	298	265=PV, 298=Temp (SV1); 300=Sensor mV (SV2); 302=Ref. Z (SV3); 304=Function Generator (SV4)	
PV_FTME	Process Variable Filter Time Constant	2	32	16	Simple	Float	4	S	RW	0	0 to 32 Seconds	
FSAFE_TYPE	Fail Safe Reaction Type	2	33	17	Simple	Unsigned8	1	S	RW	1	Table 6	
FSAFE_VALUE	Fail Safe Output Value	2	34	18	Simple	Float	4	S	RW	0		
ALARM_HYS	Alarm Hysteresis	2	35	19	Simple	Float	4	S	RW	0		
HI_HI_LIM	High-High Alarm Limit	2	37	21	Simple	Float	4	S	RW	140 °C		E
HI_LIM	High Alarm Limit	2	39	23	Simple	Float	4	S	RW	140 °C		E
LO_LIM	Low Alarm Limit	2	41	25	Simple	Float	4	S	RW	0 °C		E
LO_LO_LIM	Low-Low Alarm Limit	2	43	27	Simple	Float	4	S	RW	0 °C		E
HI_HI_ALM	High-High Alarm State	2	46	30	Record	DS-39	16	D	R			
HI_ALM	High Alarm State	2	47	31	Record	DS-39	16	D	R			
LO_ALM	Low Alarm State	2	48	32	Record	DS-39	16	D	R			
LO_LO_ALM	Low-Low Alarm State	2	49	33	Record	DS-39	16	D	R			
SIMULATE	Simulate	2	50	34	Record	DS-50	6	S	RW			
	Simulate Status					Unsigned8	1	S	RW	0X80		
	Simulate Value					Float	4	S	RW	0		
	Simulate Enable/Disable					Unsigned8	1	S	RW	0	0 = Disabled Not 0 = Enabled	
OUT_UNIT_TEXT	Output Unit Text	2	51	35	Simple	OctetString	16	S	RW	Spaces		

Object Name	Description	Slot	Slot Index	Relative Index	Object Type	Data Type	Bytes	Store	Access	Default	Valid Range	Note
TB82PH Specific Analog Input Block Parameters												
TREND_VAR	AI OUT Trend	2	61	45	Record	Device Specifc	97					
	Block Index					Unsigned16	2	S	RW	3	3 = AI2 Block	
	Parameter relative index					Unsigned16	2	S	RW	26	26 = AI OUT parameter	
	Sample type					Unsigned8	1	S	RW	0	0=Not initialized (Trend Disabled) 1=Instantaneous value	
	Sample interval (in milliseconds)					Float	4	S	RW	0		
	Last update (time of last trend value update relative to device startup)					DS-21	8	D	R			
	Sample value 1 to 16 (Sample value 1 = value of latest sample, sample value 16 = value of oldest sample)					Float	4x16	D	R			
	Sample status 1 to 16 (Sample status 1 = status of latest sample, sample status 16 = status of oldest sample)					Unsigned8	1x16	D	R			
VIEW_1	View 1	2	62	46	View_1	OctetString	18	N	R			



Note.

- A) PRIMARY_VALUE_TYPE parameter establishes the type of measurement the device is performing. The default measurement type is pH. When writing to this parameter (i.e., switching the device measurement type to ORP or pION), the AI Block linked to PV channel should be kept in OOS mode until all the necessary TB and AI variables are properly configured. If not, a modification to PRIMARY_VALUE_TYPE automatically switches the AI block mode to OOS. PV is the only available input for AI1. The PV_UNIT object determines the PV Engineering Unit.
- B) CAL_MIN_SPAN value is 1 pH when PRIMARY_VALUE_TYPE is pH. It is 100 mV for ORP and pION.
- C) OUT variable can only be written when the AI is set to the Manual Mode.
- D) AI OUT_SCALE parameters:
 - 1) The OUT_SCALE parameters of the AI use the values established by the PV_SCALE.
 - 2) When the AI channel is set to the PV (Primary Variable), the OUT_SCALE and PV_SCALE parameters of AI1 are set to the corresponding TB_RANGE_1.
 - 3) When the AI channel is set to the SECONDARY_VALUE_1 (Temperature), the OUT_SCALE and PV_SCALE parameters of the AI are set to the default temperature limits of 0 to 140°C (32 to 284°F).
 - 4) When the AI channel is set to the SECONDARY_VALUE_2 (Sensor Input - mV), the OUT_SCALE and PV_SCALE parameters of the AI are set to the default sensor limits of -2000 to +2000 mV.
 - 5) When the AI channel is set to the SECONDARY_VALUE_3 (Reference Impedance), the OUT_SCALE and PV_SCALE parameters of the AI are set to the default reference impedance limits of 0 to 10000 kohm.
 - 6) When the AI channel is set to the SECONDARY_VALUE_4 (Function Generator Output), the OUT_SCALE and PV_SCALE parameters of the AI are set to 0 and 100 %.
- E) AI HI_HI_LIM, HI_LIM, LO_LO_LIM, and LO_LIM parameters:
 - 1) For AI1, the alarm limits are set to TB_RANGE_1.
 - 2) When the channel for AI2 is set to the SECONDARY_VALUE_1 (Temperature), the limits are set to the default temperature limits of 0 to 140 °C (32 to 284 °F).
 - 3) When the channel for AI2 is set to the SECONDARY_VALUE_2 (Sensor Input - mV), the limits are set to the default sensor limits of -2000 to +2000 mV range.
 - 4) When the channel for AI2 is set to the SECONDARY_VALUE_3 (Reference Impedance), the limits are set to the default reference impedance limits of 0 to 10000 kohm.
 - 5) When the channel for AI2 is set to the SECONDARY_VALUE_4 (Function Generator Output), the limits are set to 0 to 100 % of the input range.
- F) The ISO_POTENTIAL and ASY_POTENTIAL parameters can only be written when the PH_SENSOR_TYPE is set to CUSTOM.
- G) MANUAL_TEMP_SETPOINT or TEMP_CAL_POINT parameters are to set the temperature value for Manual Temperature Compensation (i.e., when TEMP_COMP_TYPE is set to MANUAL).
- H) Physical Block View_1 is comprised of ST_REV, MODE_BLK, ALARM_SUM, DIAGNOSIS, DEVICE_STATE and GLOBAL_STATUS objects.
- I) Transducer Block View_1 is comprised of ST_REV, MODE_BLK, ALARM_SUM, PV and ACTIVE_RANGE objects.
- J) Analog Input Block View_1 is comprised of ST_REV, MODE_BLK, ALARM_SUM and OUT objects.
- K) If the DEVICE_STATE is set to Maintenance by the user, the Transducer Block PV and SV status and Analog Input Block OUT status are marked as "Good-Maintenance required", provided the previous status was "Good".
- L) Alarm Summary - Current Octet 0: bit 0 = not used; bit 1 = HI_HI_Alarm; bit 2 = HI_Alarm; bit 3 = LO_LO_Alarm; bit 4 = LO_Alarm; bit 7 = Update Event.
- M) Alarm Summary – Unreported, Unacknowledged and Disabled are for future use.

TABLE 1

PRIMARY_VALUE_TYPE Codes

- 111 pH
- 114 ORP
- 118 PION

TABLE 2

Engineering unit codes related to PRIMARY_VALUE_TYPE

- 1422 pH for PRIMARY_VALUE_TYPE = 111 (pH)
- 1243 mV for PRIMARY_VALUE_TYPE = 114 (ORP) and 118 (PION)

TABLE 3

Valid ranges for PRIMARY_VALUE_TYPE

- PRIMARY_VALUE_TYPE 111: -2 pH to 16pH
- PRIMARY_VALUE_TYPE 114: -1999 to +1999mV
- PRIMARY_VALUE_TYPE 118: -1999 to +1999mV

TABLE 4

Temperature Unit Codes

- 1001 Degree Celsius
- 1002 Degree Fahrenheit

TABLE 5

LCD Secondary display options

- 0 Temperature in degree Celsius (Secondary variable 1)
- 1 Temperature in degree Fahrenheit (Secondary variable 1)
- 2 Sensor input mV (Secondary variable 2)
- 3 Reference Impedance (Secondary variable 3)
- 4 Function generator output (Secondary variable 4)
- 5 Software Revision

TABLE 6

FSAFE_TYPE options

- 0 FSAFE_VALUE is used as OUT value (Status = Uncertain + Substitute value).
- 1 Use of stored last valid OUT value (Status = Uncertain + Last usable value; If there is no valid value available, Status = Uncertain + Initial value).
- 2 OUT has the wrong calculated value (Status = Bad + any actual sub-status).

TABLE 7

AI Engineering unit codes

AI CHANNEL = PRIMARY_VALUE (Channel 1)
 1422 pH for PRIMARY_VALUE_TYPE = 111 (pH)
 1243 mV for PRIMARY_VALUE_TYPE = 114 (ORP) and 118 (PION)

AI CHANNEL = Temperature (Channel 2;
 SECONDARY_VALUE_1)
 1001 Degree Celsius
 1002 Degree Fahrenheit

AI CHANNEL = Sensor Input mV (Channel 3;
 SECONDARY_VALUE_2)
 1243 mV

AI CHANNEL = Reference Impedance (Channel 4;
 SECONDARY_VALUE_3)
 1284 K Ohm

AI CHANNEL = Function Generator output (Channel 5;
 SECONDARY_VALUE_4)
 1342 Percent

The following figure shows the possible connections that can be made between the Transducer Block outputs and the two AI's.




Figure 32 - Possible Connections Between the TB and AI's

The table below gives a summary of the relation between the selected measurement and available variables/channels that can be used as an input for the Analog Input Function Blocks.

	TYPE OF MEASURE (TB_PRIMARY_VALUE_TYPE)		
	pH	ORP	pION
Channel 1 (AI1 and AI2) (TB PV)	pH Value	ORP value in mV	PION value in mV
Channel 2 (AI2 Only) (TB SECONDARY_VALUE_1)	Temperature	Temperature	Temperature
Channel 3 (AI2 Only) (TB SECONDARY_VALUE_2)	Sensor Input in mV	Sensor Input in mV	Sensor Input in mV
Channel 4 (AI2 Only) (TB SECONDARY_VALUE_3)	Reference Impedance in kohm	Reference Impedance in kohm	Reference Impedance in kohm
Channel 5 (AI2 Only) (TB SECONDARY_VALUE_4)	Function Generator output in %	Function Generator output in %	Function Generator output in %

Cyclical Configuration Data

For maximum configuration (i.e., both AI blocks are in use), the cyclic data structure of TB82 PROFIBUS PA devices would be:

Data index	Data	Access	Data format
0,1,2,3	AI1 OUT value	Read	32-bit floating point number (IEEE-754) in the configured AI1 block OUT_SCALE units.
4	AI1 OUT status	Read	Standard PROFIBUS PA status
5,6,7,8	AI2 OUT value	Read	32-bit floating point number (IEEE-754) in the configured AI2 block OUT_SCALE units.
9	AI2 OUT status	Read	Standard PROFIBUS PA status

The AI1 and AI2 OUT value is selected using the respective AI block CHANNEL parameter.

TB82 PA configuration data includes:

Cyclic data block	Sequence in Chk_Cfg	Configuration for Data block active (h=hexadecimal number)	Configuration for Data block inactive (h=hexadecimal number)
AI1 OUT parameter	1	42h, 84h, 81h, 81h	00h
AI2 OUT parameter	2	42h, 84h, 81h, 81h	00h

Possible combinations of configuration would be:

Activated data blocks	Configuration data string (Chk_Cfg)	Length of configuration
AI1 OUT value and status + AI2 OUT value and status	42h, 84h, 81h, 81h, 42h, 84h, 81h, 81h	8 bytes
AI1 OUT value and status	42h, 84h, 81h, 81h, (00h) ¹	4 or 5 bytes
AI2 OUT value and status	00h ¹ , 42h, 84h, 81h, 81h	5 bytes

The above combinations are included in the GSD file and DTM.

¹ A zero as a placeholder in the configuration string should identify data blocks that are not activated. Zeroes at the end of the configuration string are optional and can be omitted.

HARDWARE DIP SWITCH FUNCTIONS

There are four switches on the Microprocessor/Display PCB Assembly that perform unique transmitter functions. The figure below shows the location and function of these switches.




Figure 33 – Hardware Dip Switch Location and Function

Switch number 1 is the Write Lock. When this switch is in the ON position and the HD_WRITE_PROTECTION is enabled in the Physical Block, the transmitter prevents any modification of data or parameters that can be performed both locally and from a class 1 or 2 MASTER device.

Switch number 2 is not used and has been reserved for future use.

Switch number 3 is used for Cold Startup. When this switch is in the ON position before powering up the transmitter, most transmitter parameters are set to default values (See Device Blocks for default settings). These default parameters are found in all support blocks.

Switch number 4 is not used and has been reserved for future use.



Note.

A Cold Startup will adjust several parameters to a defined default value. Cold Startup may be used to reset the initial operating condition of the transmitter. When the Cold Start switch is in the ON position on transmitter power up, critical transmitter parameters will be reset to default values. The SW3 switch must be in the OFF position to ensure user configured data is not overwritten on transmitter power up.

SIMPLE FAULT FINDING


If the transmitter does not appear to be working satisfactory, carry out the following troubleshooting checks before contacting your nearest Service Center or Factory Representative.

If the instrument is to be returned for repair, ensure that it is adequately packed using the original packing material and box or using high-density chip foam. **The Return Materials Authorization (RMA) number must be sent with the instrument. Equipment returned to ABB Inc. with incorrect or incomplete information may result in significant delays or non-acceptance of the shipment.** At the time the RMA number is given, an estimate of the repair costs will be provided, and a customer purchase order will be requested. **The RMA and purchase order numbers must be clearly marked on all paperwork and on the outside of the return package container (i.e., packing box).**


Equipment needed:

PROFIBUS configuration software or communication Host/System

High, Low or Irregular Process Variables



No Output



Since the transmitter has an integral display, diagnostic codes are shown in the secondary display region when interrogated using the FAULT Info key. In addition, the transmitter status is available through most configuration or system/host tools.

DIAGNOSTIC INFORMATION

The TB82PH PROFIBUS PA transmitter performs a number of diagnostic checks on hardware, software, and sensor functions. If a nonconforming condition is detected, the user is alerted to faults locally by a flashing FAULT indicating icon and remotely by a configuration and/or system/host tool.

When using the local HMI, diagnostic faults are interrogated using the FAULT Info key while the transmitter is in the Measure Mode. A short text string and fault code is alternately shown in the secondary display region. If multiple faults exist, the FAULT Info key moves the user to the next fault. Once all faults have been interrogated, the transmitter returns to the Measure Mode. A flashing FAULT icon indicates a new fault condition that has not been interrogated. Conversely, a non-flashing FAULT icon indicates all fault conditions have been interrogated but not resolved. When all fault conditions are resolved, the FAULT icon and FAULT Info key are de-energized.

Fault conditions are grouped into two categories based on severity. Conditions that result in degradation of transmitter performance are reported as Problem Codes (PC), while conditions that render the transmitter inoperable are reported as Error Codes (EC). Fault codes are reported in the secondary display region in a first in, first out order (i.e., the first detected fault condition is the first condition that is displayed upon interrogation). The table below lists all applicable Error and Problem codes and the suggested Corrective Actions. See Text Prompt Definitions for fault code description.

Fault Code	Fault Text String	Corrective Action
EC1	PV.AD	Contact Factory.
EC4	TC.PCB	Incorrect Input PCB assembly has been detected. Toroidal Conductivity Input PCB Assembly is being used with TB82PH product firmware.
EC5	DO.PCB	Incorrect Input PCB assembly has been detected. Dissolved Oxygen Input PCB Assembly is being used with TB82PH product firmware.
EC6	TE.PCB	Incorrect Input PCB assembly has been detected. Two-Electrode Conductivity Input PCB Assembly is being used with TB82PH product firmware.
EC7	EC.PCB	Incorrect Input PCB assembly has been detected. Four-Electrode Conductivity Input PCB Assembly is being used with TB82PH product firmware.
PC1	LO.GLS.Z	<ol style="list-style-type: none"> 1) Verify sensor wiring is properly connected. 2) Verify sensor wiring is not shorted to other wiring or metal surfaces. 3) Verify terminal blocks and other connections are free of any liquids, oils, scale or corrosion. 4) Verify configuration settings are correct. Diagnostics should be set to OFF if the sensor being used does not have a solution ground connection. 5) Verify glass electrode is intact. Replace sensor if glass electrode is broken. 6) Verify sensor responds to pH buffers. Replace sensor if sensor does not respond.
PC2	HI.REF.Z	<ol style="list-style-type: none"> 1) Verify sensor wiring is properly connected. 2) Verify sensor wiring is free of nicks, cuts, breaks and/or open connections. 3) Verify configuration settings are correct. Diagnostics should be set to OFF if the sensor being used does not have a solution ground connection. 4) Verify reference electrode is clean. Remove any foreign material. Verify sensor responds to pH buffers. Replace sensor if sensor does not response.
PC4	GND LP	<ol style="list-style-type: none"> 1) Verify sensor wiring is properly connected. 2) Verify sensor wiring is not shorted to other wiring or metal surfaces. 3) Verify terminal blocks and other connections are free of any liquids, oils, scale or corrosion. 4) If a sensor extension is being used, verify connections are dry and free of corrosion. 5) Verify configuration settings are correct. Diagnostics should be set to OFF if the sensor being used does not have a solution ground connection.
PC5	OPEN	<ol style="list-style-type: none"> 1) Verify sensor wiring is properly connected. 2) Verify sensor wiring is free of nicks, cuts, breaks and/or open connections. 3) Verify configuration settings are correct. Diagnostics should be set to OFF if the sensor being used does not have a solution ground connection.
PC8	HI.PV	<ol style="list-style-type: none"> 1) Verify process conditions are within transmitter range values. 2) Verify sensor wiring is properly connected. 3) Verify sensor wiring is free of nicks, cuts, breaks and/or open connections. 4) Verify configuration settings are correct. 5) Verify manual or measured temperature value is correct. If a temperature sensor is not being used, verify that TMP.SNS is set to none in the transmitter configuration.

Fault Code	Fault Text String	Corrective Action
PC9	LO.PV	See PC8 corrective actions.
PC10	HI.TEMP	See PC8 corrective actions.
PC11	LO.TEMP	See PC8 corrective actions.
PC12	TEMP.AD	See PC8 corrective actions. If all items check out properly, replace Input PCB Assembly. Transmitter can be used; however, the Temperature Compensation must be set to Manual and a Temperature Calibration should be conducted in order to set the Manual Temperature Value close to the operating conditions.
PC14	+HI.OFF	1) Clean sensor and repeat a buffer and/or process calibration. If sensor is functioning properly, order a spare sensor to replace the existing sensor when failure occurs. Replace existing sensor if sensor is not functioning properly. 2) Verify sensor wiring is free of nicks, cuts, breaks, shorts and/or open connections. If wiring is damaged, replace wiring and/or sensor and recalibrate.
PC15	-HI.OFF	See PC14 corrective actions.
PC16	HI.EFF	1) Verify the proper buffer values were used for calibration. Repeat calibration with correct buffer values. 2) Clean sensor and repeat a buffer and/or process calibration. If sensor is functioning properly, order a spare sensor to replace the existing sensor when failure occurs. Replace existing sensor if sensor is not functioning properly.
PC17	LO.EFF	1) Verify the proper buffer values were used for calibration. Repeat calibration with correct buffer values. 2) Clean sensor and repeat a buffer and/or process calibration. If sensor is functioning properly, order a spare sensor to replace the existing sensor when failure occurs. Replace existing sensor if sensor is not functioning properly. 3) Verify terminal blocks and other connections are free of any liquids, oils, scale or corrosion. 4) Verify sensor wiring is free of nicks, cuts, breaks, shorts and/or open connections. If wiring is damaged, replace wiring and/or sensor and recalibrate.
PC20	BAD.SEE	Contact Factory
PC21	NO.F.CAL	
PC23	SEE.EMI	
PC30	PV.F.CAL	
PC31	BA.F.CAL	
PC32	PT.F.CAL	
PC33	RZ.F.CAL	
PC34	PV.CHKS	
PC35	BA.CHKS	
PC36	PT.CHKS	
PC37	RZ.CHKS	
PC40	HI.R.CKT	
PC41	LO.R.CKT	
PC42	RZ.AD	
PC44	HI.G.CKT	
PC45	LO.G.CKT	
PC46	GL.AD	
PC48	HI.C.CKT	
PC49	LO.C.CKT	
PC50	CA.AD	

Calibration Diagnostic Messages

The transmitter performs automatic efficiency and offset calculations relative to a theoretically perfect electrochemical and/or temperature sensor during each calibration cycle. Calibration history is retained for future interrogation using the Edit Calibrate State. The calibration constants that are displayed are Efficiency and Offset for the Process Variable and Slope and Offset for the Temperature.

An Efficiency of less than 60% or greater than 110% indicates a potentially bad process calibration point or poorly performing sensor. Calibration values that yield Efficiency values less than 40% or greater than 150% are not accepted. In these cases, the text string BAD.CAL (bad calibration) is displayed in the secondary display region. The user is returned to the beginning of the calibration cycle after the bad calibration has been reported.

An Offset value of less than -180.0 mV or greater than +180 mV also indicates a potentially bad process calibration or poorly performing sensor. Calibration values that yield Offset values less than -1000 mV or greater than +1000 mV are not accepted. Again a

bad calibration will be reported, and the user returned to the beginning of the calibration cycle.

For temperature, a bad calibration will be reported and calibration values will not be accepted for Slope values that are less than 0.2 or greater than 1.5 and Offset values that are less than -40°C or greater than +40°C. Temperature calibrations use smart software routines that automatically adjust the Slope, Offset, or both values based on the calibration value being entered and calibration history if it exists.

Additional Diagnostic Messages

Other diagnostic messages may appear during analyzer programming. These messages include BAD.VAL (bad value) and DENIED.

BAD.VAL indicates the attempted numeric entry of a value that is out of the allowed analyzer range. See the Specifications section for analyzer range limits.

DENIED indicates incorrect entry of a security password. See the Security Mode section for information.

SENSOR TROUBLESHOOTING

If the sensor is suspected of being the source of problems, a quick visual inspection in many cases will identify the problem. If nothing can be seen, a few electrical tests using a digital multimeter can be performed to determine if the sensor is at fault. Some of these tests can be performed with the sensor either in or out of the process stream.

Visual Sensor Inspection

Remove the sensor from the process and visually check the following:

Sensor body

Inspect the sensor body for cracks and distortions. If any are found, contact your local ABB representative for alternative sensor styles and materials.

Cable and connectors

Inspect the sensor cable for cracks, cuts, or shorts. If a junction box and/or extension cable are used, check for moisture, oil, corrosion, and/or particulates. All connections must be dry, oil-free, corrosion-free, and particulate-free. Even slight amounts of moisture, skin oils, corrosion, and particulates can short sensor signals due to the high impedance of these signals. If a BNC connector is used, check to see that it is dry and not shorting against any metal, earth grounds, or conduit.

Measuring electrode

Inspect the glass electrode for breaks or cracks. If breakage is a problem, contact your local ABB representative for alternative electrode choices or

suggestions regarding alternate sensor mounting locations.

Inspect the measurement electrode for fouling or scales. Many scales are not noticeable when the sensor is wet. Using a tissue, dry the glass electrode and hold it up to a bright light. Scaling will appear as a whitish, textured material on the surface of the electrode. Films will usually have a streaky, multi-colored appearance. Clean the electrode if it is fouled or scaled.

Reference junction

Inspect the reference junction (the area between the sensor body and measuring electrode) for heavy fouling or scaling. If fouling or hardness scales are present, remove foreign material. When mechanically cleaning the sensor, always use a soft bristle brush in order to avoid damaging the insulating coating on the solution ground (the metallic collar around the measuring electrode if present). This coating is only present on the outer diameter next to the reference junction and must be intact for the reference diagnostics to properly function.

If the junction (especially a wood junction) has been attacked by the process chemicals, contact your local ABB representative for alternate junction materials.

Solution ground and O-ring seals

On TBX5 sensors, inspect the solution ground (i.e., the metallic collar around the measuring electrode) and sealing O-rings for attack by the process liquid. If the solution ground shows evidence of corrosion or deterioration and/or the O-rings appear distorted or

swollen, contact your local ABB representative for alternate material choices.

Sensor Electronic Test

The pH/ORP/pION sensor can be electronically tested to verify the integrity of the sensor elements and cable. These tests require a Digital Multimeter (DMM) that has a conductance function capable of measuring from 0 to 200 nS.

The sensor leads and automatic temperature compensator leads must be disconnected from the transmitter before these tests can be performed. Also the sensor must be placed in a container of water or buffer solution. If the sensor does not have a solution ground and has a BNC, the center conductor of the BNC will be equivalent to the blue Sense lead and the shell will be equivalent to the black Reference lead. Check the sensor using the following procedure.

1. Check the resistance of the Temperature Sensor. For a 3 kohm Balco RTD, the expected resistance can be calculated from:

$$R_{TC} = (((T - 25) * 0.0045) + 1) * 3000$$

where T is in degrees Celsius. The measured resistance should be within the expected value by $\pm 15\%$. At room temperature (i.e., 25°C), the resistance value should be approximately 3 kohms.

For a Pt100 RTD, the expected resistance can be calculated from:

$$R_{TC} = 100 + (T * 0.385)$$

where T is in degrees Celsius. The measured resistance should be within the expected value by $\pm 5\%$. At room temperature (i.e., 25°C), the resistance value should be approximately 110 ohms.

2. Check the conductance between the red Temperature Sensor lead and each of the other sensor leads (i.e., blue, yellow, black, green, and heavy green leads). The reading must be less than 0.05 nS.

3. Check the conductance between the yellow Guard lead and each of the other sensor leads (i.e., blue, black, green, red, white, and heavy green leads). The reading must be less than 0.05 nS.

4. Check the conductance between the heavy green lead (i.e., Shield) and each of the other sensor leads (i.e., blue, yellow, black, green, red, and white leads). The reading must be less than 0.05 nS.

5. Check the conductance of the sensor measurement electrode by measuring across the blue and green leads. The conductance must be 1 to 10 nS when the sensor and solution in contact with the sensor is at 25°C. (If the sensor and solution are above or below 25°C, the conductance value can be estimated as one-half the conductance for every eight degrees above 25°C or double the conductance for every eight degrees below 25°C.)

6. Check the voltage of the sensor reference electrode by measuring across the black lead for the sensor under test and the black lead of a known good sensor. For this test, the sensor under test must be removed from the process and placed into a buffer solution. The known good sensor must also be placed in the same buffer solution. The voltage must be between -180 mV and +180 mV.

DIAGNOSTIC INFORMATION RECEIVED FROM THE FIELDBUS

Dynamic variables and diagnostic information are continually passed onto the fieldbus during each device transmission. Most engineering tools and/or system/host workstations provide the ability to view such information. Dynamic variable status contains two components: data quality and sub-status. The following table briefly outlines the dynamic variable status.

Quality	Sub-status
Good (non-cascade)	1) OK. 2) Update event. 3) Block has active advisory alarm (priority < 8). 4) Block has active critical alarm (priority > or = 8). 5) Block has unacknowledged update event. 6) Unacknowledged advisory alarm. 7) Unacknowledged critical alarm. 8) Initiate fail safe. 9) Maintenance required.
Uncertain	1) Nonspecific. 2) Last usable value. 3) Substitute set. 4) Initial value. 5) Sensor conversion not accurate. 6) EU range violation. 7) Sub-normal. 8) Configuration error. 9) Simulated value. 10) Sensor Calibration.
Bad	1) Nonspecific. 2) Configuration error. 3) Not connected. 4) Device failure. 5) Sensor failure. 6) No communication, with last usable value. 7) No communication, with no last usable value. 8) Block Out of Service.

In addition to the dynamic variable status, Physical Block Diagnosis and Global Status provide information on the condition of hardware or software components that are associated with and/or directly impact the correct operation of the transmitter. The following table lists the possible diagnostic information:

Physical Block Diagnosis		Physical Block Global Status
Object	Problem Description	
1) DIA_HW_ELECTR 2) DIA_HW_MECH 3) DIA_MEM_CHKSUM 4) DIA_MEASUREMENT 5) DIA_CONF_INVALID 6) DIA_WARMSTART 7) DIA_COLDSTART 8) DIA_MAINTAINANCE 9) IDENT_NUMBER 10) EXTENSION_AVAILABLE 11) Calibration Error	1) Hardware Electronic Failure 2) Hardware Mechanical Failure 3) Memory Error 4) Measurement Failure 5) Invalid Configuration 6) Initiated a Warmstart 7) Initiated a Coldstart 8) Maintenance Required 9) ID Violation 10) Additional Diagnostics Available 11) Calibration Error (Device Specific)	1) Failure 2) Maintenance Request 3) Limits

Transmitter diagnostic conditions (i.e., Problem and Error Codes) are displayed as Extended Status information. Since these conditions have an impact on the Dynamic Variable quality and Block parameters, each diagnostic condition has been mapped as follows:

Problem/Error Code and Text Prompt		Problem & Error Description	PV Status	SV1 Status	SV2 Status	SV3 Status	SV4 Status	PB Diagnosis	PB Global Status
Code	Text								
EC1	PV.AD	Process Variable Over/Under Range	Bad (Device failure)	N/A	Bad (Device failure)	N/A	Bad (Device Failure)	Hardware Electronic Failure, Measurement Failure, Maintenance Required	Failure
EC3 To EC7	xx.PCB	Incorrect Input Board	Bad (Device Failure)	Hardware Electronic Failure, Measurement Failure, Maintenance Required	Failure				
PC1	LO.GLS.Z	Low glass electrode impedance	Bad (Sensor Failure)	N/A	Bad (Sensor Failure)	N/A	Bad (Sensor Failure)	Measurement Failure, Maintenance Required	Maintenance Request
PC2	HI.REF.Z	High reference electrode impedance	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	Uncertain (EU Range Violation)	Uncertain (Sub-normal)	Maintenance Required	Maintenance Request, Limits
PC4	GND.LP	Ground loops present or shorted sensor cable.	Bad (Sensor Failure)	N/A	Bad (Sensor Failure)	N/A	Bad (Sensor Failure)	Maintenance Required	Maintenance Request
PC5	OPEN	Open sensor cable or sensor out of solution.	Bad (Sensor Failure)	N/A	Bad (Sensor Failure)	Uncertain (EU Range Violation)	Bad (Sensor Failure)	Maintenance Required	Maintenance Request, Limits
PC8	HI.PV	PV above/below transmitter range.	Uncertain (EU Range Violation)	N/A	N/A	N/A	Uncertain (EU Range Violation)	Hardware Mechanical Failure, Maintenance Required	Maintenance Request, Limits
PC9	LO.PV	PV above/below transmitter range.	Uncertain (EU Range Violation)	N/A	N/A	N/A	Uncertain (EU Range Violation)	Hardware Mechanical Failure, Maintenance Required	Maintenance Request, Limits
PC10	HI.TEMP	Temperature above/below transmitter range.	Uncertain (Sensor Conversion Not Accurate)	Uncertain (EU Range Violation)	N/A	N/A	Uncertain (Sensor Conversion Not Accurate)	Hardware Mechanical Failure, Invalid Configuration, Maintenance Required	Maintenance Request, Limits
PC11	LO.TEMP	Temperature above/below transmitter range.	Uncertain (Sensor Conversion Not Accurate)	Uncertain (EU Range Violation)	N/A	N/A	Uncertain (Sensor Conversion Not Accurate)	Hardware Mechanical Failure, Invalid Configuration, Maintenance Required	Maintenance Request, Limits
PC12	TEMP.AD	Open, missing or shorted temperature sensor.	Uncertain (Sensor Conversion Not Accurate)	Bad (Sensor Failure)	N/A	N/A	Uncertain (Sensor Conversion Not Accurate)	Invalid Configuration, Maintenance Required	Maintenance Request
PC14	+HI.OFF	Large Positive Sensor Offset (>180mV).	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	Hardware Mechanical Failure, Maintenance Required	Maintenance Request
PC15	-HI.OFF	Large Negative Sensor Offset (<-180mV).	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	Hardware Mechanical Failure, Maintenance Required	Maintenance Request
PC16	HI.EFF	High Sensor Efficiency (>110%).	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	Calibration Error, Maintenance Required	Maintenance Request
PC17	LO.EFF	Low Sensor Efficiency (<60%).	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	Calibration Error, Maintenance Required	Maintenance Request
PC30 To PC37	xx.F.CAL xx.CHKS	SEE checksum and bad fac cal errors	Uncertain (Sensor Conversion Not Accurate)	Memory Error	Maintenance Request				
PC40	HI.R.CKT	Reference impedance circuit failure-high/low range error.	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	Bad	Uncertain (Sub-normal)	Maintenance Required	Maintenance Request
PC41	LO.R.CKT	Reference impedance circuit failure-high/low range error.	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	Bad	Uncertain (Sub-normal)	Maintenance Required	Maintenance Request
PC42	RZ.AD	Reference impedance above/below transmitter A/D range.	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	Maintenance Required	Maintenance Request
PC44	HI.G.CKT	pH measuring electrode impedance circuit failure – high/low range error.	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	Maintenance Required	Maintenance Request
PC45	LO.G.CKT	pH measuring electrode impedance circuit failure – high/low range error.	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	Maintenance Required	Maintenance Request
PC46	GL.AD	pH measuring electrode impedance above/below transmitter A/D range.	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	Maintenance Required	Maintenance Request
PC48	HI.C.CKT	Cable diagnostic circuit failure – high/low range error.	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	Maintenance Required	Maintenance Request
PC49	LO.C.CKT	Cable diagnostic circuit failure – high/low range error.	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	Maintenance Required	Maintenance Request
PC50	CA.AD	Cable diagnostic signal above/below transmitter A/D range.	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	N/A	Uncertain (Sub-normal)	Maintenance Required	Maintenance Request

PV represents Primary Value and SV represents Secondary Value.

Alarm Summary

Whenever an alarm is enabled and the alarm condition occurs, the relevant bit in the ALARM_SUM object of the corresponding block is set.

Alarm Type	Description
HI_HI_Alarm	Supported by AI. Indicated when the OUT value goes above the HI_HI_LIM value and cleared when the OUT value drops back down below the HI_HI_LIM minus ALARM_HYS values.
HI_Alarm	Supported by AI. Indicated when the OUT value goes above the HI_LIM value and cleared when the OUT value drops back down below the HI_LIM minus ALARM_HYS values.
LO_LO_Alarm	Supported by AI. Indicated when the OUT value goes below the LO_LO_LIM value and cleared when the OUT value rises back over the LO_LO_LIM plus ALARM_HYS values.
LO_Alarm	Supported by AI. Indicated when the OUT value goes below the LO_LIM value and cleared when the OUT value rises back over the LO_LIM plus ALARM_HYS values.
Update Event	Supported by PB, TB and AI. Indicated when a static revision increment occurs in the block due to modification of a static parameter.

Limit alarm bits are set to 1 or 0. A '1' represents an active alarm and a '0' represents an inactive alarm in the ALARM_SUM object.

DISMANTLING AND REASSEMBLY



Warning.

Substitution of any components other than those assemblies listed in this section will compromise the certification listed on the transmitter nameplate. Invalidating the certifications can lead to unsafe conditions that can injure personnel and damage equipment.



Caution.

Dismantling and reassembly should not be carried out on site because of the risk of damage to components and printed circuits as a result of adverse environmental conditions such as humidity, dust, etc. The dismantling and reassembly procedures given below should be carried out in the listed order to avoid instrument damage.

Required tools

Medium flat-bladed screwdriver
Small Phillips screwdriver

Dismantling

- Use the bladed screwdriver to loosen the four captive screws that secure the Front Bezel and/or Rear Cover Assemblies (depending on which component is being replaced) and remove the cover(s).

- Remove Power Supply and/or Input PCB Assemblies by unscrewing the two Phillips screws and unplug the assemblies from their connectors.
- Remove Microprocessor/Display PCB Assembly by unscrewing the four Phillips screws and unplug the keypad cable by lifting the locking arms on the side of the connector and remove the cable from the connector.
- Remove the cable hubs by screwing the retaining nut and removing the hub from the Shell Assembly.

Reassembly

Check that the gaskets are not damaged and have a thin layer of silicone grease. If the gaskets are damaged, replace gaskets.

- Install the Microprocessor/Display by securing the assembly with the four Phillips screws and installing the keypad cable into the connector and locking it into place by pushing down the two locking arms on the side of the connector.
- Install the Power Supply and/or Input PCB Assemblies into their respective connector and secure the assemblies with the two Phillips screws per assembly.
- Attach cable hubs by installing the gaskets onto the hubs and insert the hubs into the ports in the Shell assembly. Secure the hubs by tightening the nut onto the hub threads.
- Install the Front Bezel and/or Rear Cover Assemblies and secure by tightening the four captive screws per assembly using a bladed screwdriver.




Figure 34 - TB82PH PROFIBUS PA Transmitter Exploded View

SPECIFICATIONS

Property	Characteristic/Value
Process Display Range pH ORP pION	-2 to +16.00 pH -1999 to +1999 mV -1999 to +1999 mV
Temperature Display Range	-20 to 300°C (-4° to 572°F)
Sensor Temperature Range	0° to 140°C (32° to 284°F)
Resolution, Display pH ORP pION Temperature	0.01 pH 1 mV 1 mV 1°C, 1°F
Accuracy, Display pH ORP pION Temperature	±0.01 pH ±1 mV ±1 mV 1°C
Nonlinearity, Display pH ORP pION Temperature	±0.01 pH ±1 mV ±1 mV 1°C
Repeatability, Display pH ORP pION Temperature	±0.01 pH ±1 mV ±1 mV 1°C
Stability, Display pH ORP pION Temperature	±0.01 pH ±1 mV ±1 mV 1°C
Temperature Compensation	Manual Nernstian Automatic Nernstian Automatic Nernstian with Solution Coefficient
Input Types pH ORP pION Temperature	Glass, Antimony, Custom Isopotential & Asymmetric Potential Platinum, Gold Sodium, Chloride, Sulfide, etc. 3 kohm Balco, Pt100
Dynamic Response	3 sec. for 90% step change at 0.0 sec. damping
Ambient Temperature Effect pH ORP pION Temperature	±0.007 pH/°C @ 95% Relative Humidity ±0.4 mV/°C @ 95% Relative Humidity ±0.4 mV/°C @ 95% Relative Humidity ±0.16 °C/°C @ 95% Relative Humidity
Minimum Span pH ORP pION Temperature	1.00 pH 100 mV 100 mV 10 °C
Maximum Span (full scale settings) pH ORP pION Temperature	14 pH (0 to 14 pH) 3998 mV (-1999 to 1999 mV) 3998 mV (-1999 to 1999 mV) 140 °C, 252 °F (0 to 140 °C, 32 to 284 °F)
Damping	Continuously adjustable from 0.0 to 99.9 seconds

Property	Characteristic/Value
Supply Voltage Range	9 to 32 Vdc (9 to 24 Vdc for agency certified IS applications) 15 mA quiescent current
Turn-On Time	4 seconds typical, 6 seconds maximum
Maximum Sensor Cable Length	100 ft (30.5 m)
Sensor Diagnostic pH ORP pION	Glass and Reference Impedance, Open Cabling, Efficiency and Asymmetric Potential Check Reference Impedance, Open Cabling, Efficiency and Asymmetric Potential Check Reference Impedance, Open Cabling, Efficiency and Asymmetric Potential Check
Diagnostic Notification Local HMI	FAULT icon indication.
Environmental Operating temperature LCD Range Storage temperature	-20° to 60°C (-4° to 140°F) -20° to 60°C (-4° to 140°F) -40° to 70°C (-40° to 158°F)
Mounting Effect	None
Enclosure Classification	NEMA 4X IP65
Size Height Minimum panel depth Maximum panel cutout Recommended panel cutout	144 mm high x 144 mm wide x 171 mm long (5.67 in. high x 5.67 in. wide x 6.75 in. long) 145 mm (5.70 in.) 136.7 mm x 136.7 mm (5.38 in. x 5.38 in.) 135 mm x 135 mm (5.33 in. x 5.33 in.)
Weight	1.9 kg (4.2 lb) without mounting hardware 3.4 kg (7.5 lb) with Pipe Mounting Hardware

Property	Characteristic/Value
EMC Requirements	CE certified: Electromagnetic Conformance - IEC61326-1: 2000 EN55011: 1991 (CISPR11: 1990) Class A EN61000-4-2: 1995 4 kV Contact 6 kV Indirect EN61000-4-3: 1997 10 V/m EN61000-4-4: 1995 1 kV EN61000-4-5: 1995 2kV Line to Earth 1kV Line to Line EN61000-4-6: 2001 3V EN61000-4-8: 1994 30A/m
Agency Approvals ² (pending) Factory Mutual (FM) Intrinsic safety Nonincendive Canadian Standards Association (CSA) Intrinsic safety Nonincendive ATEX (Conforms with ATEX 100A) Intrinsic safety/FISCO	All devices meet IS and FISCO requirements. Class I, II, III; Division 1; applicable Groups A, B, C, D, E, F and G; T3C T _a =60° C when used with appropriate barriers per Drawing PXXXX. Class I, Division 2, Groups A, B, C, and D. T5 T _a =60° C Class II, Division 2, Groups F and G. Class III, Division 2. Class I, II, III; Division 1; applicable Groups A, B, C, D, E, F and G; T3C T _a =60° C when used with appropriate barriers per Drawing PXXXX. Class I, Division 2, Groups A, B, C, and D. Class II, Division 2, Groups E, F and G. Class III, Division 2. ATEX Category II 1G EEX ia, Zone 1; Group IIC, T4 when used with appropriate barriers.

² Hazardous location approvals for use in flammable atmospheres are for ambient conditions of -20C to 60 C (-4 F to 140 F), 86 to 108 kPa (12.5 to 15.7 psi) with a maximum oxygen concentration of 21%.

GLOSSARY OF PROGRAMMING TEXT PROMPTS

TEXT STRING	DESCRIPTION
1PT.CAL	One Point Calibration.
2PT.CAL	Two Point Calibration.
3K.BLCO	3 kohm Balco (Temperature Compensation).
AI.BLK	Analog Input Block where '-' is the block number.
AI.OUT	Analog Input Output value where '-' is the block number.
ANALZR	Analyzer State.
ANTMNY	Antimony (pH Sensor with Antimony Measurement Electrode).
ASY.POT	Asymmetric Potential.
AUT.SOL	Automatic Temperature Compensation (Nernstian) with Solution Coefficient.
AUTO	Automatic Temperature Compensation (Nernstian) or Automatic Block Mode Handling.
BAD.CAL	Bad Calibration - Entered values caused the calculated values to exceed maximum values.
BAD.VAL	Bad Value - Entered value exceeded maximum allowable value for the entered parameter.
CALIBR	Calibrate Mode.
CONFIG	Configure Mode.
CUSTOM	Custom Measurement Electrode with adjustable Isopotential Point and Asymmetric Potential (pH Sensor with Custom Measurement Electrode).
DAMPNG	Damping of the displayed primary value on the transmitter's HMI.
DIAGS	Diagnostics State.
DISABL	Disable.
EDT.CAL	Edit Calibrate State.
ENABLE	Enable.
FG.HIGH	Function Generator upper end point.
FG.LOW	Function Generator lower end point.
HARD.LK	Operation cannot be completed due to Hardware write protection.
HI.VAL	High Calibration (Buffer or Standard) Value.
ID. SEL	Device Profile Identification Select State
ION.CAL	Specific Ion Calibration.
ISO.PT	Isopotential Point.
---KRZ	Reference Impedance in kohms where '---' is the impedance value.
LIN.TYP	Linearity Type (Linear or Function Generator).
LO.VAL	Low Calibration (Buffer or Standard) Value.
MANUAL	Manual Temperature Compensation (Nernstian).
MODIFY	Modify Configure State.
MV/10C	Millivolt per 10°C (Solution Coefficient value for Automatic Nernstian with Solution Coefficient Temperature Compensation).
NEW.VAL	New Calibration Value - The PV or Temperature value expected during a One Point or Temperature Calibration.
NEW.VL.C	New Temperature Value in degrees Celsius.
NEW.VL.F	New Temperature Value in degrees Fahrenheit.
NONE	None.
OFFSET	Offset Value.
OOS	Out Of Service.
ORP	Oxidation-Reduction Potential Analyzer Type.
ORP.CAL	ORP Calibration State.
OUTPUT	Output Mode.
PA. ADR	PROFIBUS PA Address.
PASSWD	Security Password.
PH	pH Analyzer Type.
PH/10C	pH units per 10°C (Solution Coefficient value for Automatic Nernstian with Solution Coefficient Temperature Compensation).
PH.CAL	pH Calibration State.
PH.GLAS	pH Glass (pH Sensor with Glass Measurement Electrode).
PION	Potential of a Specific Ion.
PT 100	Pt100 Ohm RTD.
PV OFF	Process Variable Offset Value for the installed sensor.
PV SLP	Process Variable Slope Value for the installed sensor.

TEXT STRING	DESCRIPTION
REF.Z	Reference Impedance.
RESET?	Query to Reset parameters to default values.
REV.A10	Software Revision A10.
RST.ALL	Reset All Parameters to Factory Settings.
RST.CAL	Reset Calibration Constant and Data to Factory Settings.
RST.CON	Reset Configurations to Factory Defaults.
RST.SEC	Reset Security - Remove any existing security.
RST.SFT	Software Reset - Initiate a reboot and self-test function.
SEC.DSP	Secondary Display Mode.
SECUR	Security Mode.
SER.NUM	Device Serial Number State
SLOPE	Slope for the installed sensor (Process Variable or Temperature).
STABL?	Is the displayed Process Variable Stable?
TB.PV.LO	Transducer Block Process Value Low Range Value.
TB.PV.HI	Transducer Block Process Value High Range Value.
TB.RNGE	Transducer Block Range Value State.
TC.TYPE	Temperature Compensation Type State
T.OFF°C	Temperature Sensor Offset Value in degrees Celsius.
T.OFF°F	Temperature Sensor Offset Value in degrees Fahrenheit.
TMP.CAL	Temperature Calibration State.
TMP.SLP	Temperature Slope Value.
TMP.SNS	Temperature Sensor Type State.
TMP°C	Temperature in degrees Celsius.
UNITS	Units.
USER	User State.
VIEW	View Current Configuration.
WRT.ERR	Error saving data.
X-1	Non-linear Input Value for the first point (numeric value changes for each point).
Y-1	Non-linear Output Value for the first point (numeric value changes for each point).

TB82PH WORKSHEET

Tag: _____	Date: _____	
Analyzer Type:		
<input type="checkbox"/> pH <input type="checkbox"/> GLASS <input type="checkbox"/> ANTIMONY <input type="checkbox"/> CUSTOM ISO PT: _____ pH ASY POT: _____ mV REF Z: _____ kohm	<input type="checkbox"/> ORP REF Z: _____ kohm	<input type="checkbox"/> pION REF Z: _____ kohm
Temperature Sensor: <input type="checkbox"/> None <input type="checkbox"/> 3k Balco <input type="checkbox"/> Pt 100		
Temperature Compensation Type: <input type="checkbox"/> Manual <input type="checkbox"/> Auto <input type="checkbox"/> Auto Solution		Coeff.: _____
Diagnostics: <input type="checkbox"/> Enabled <input type="checkbox"/> Disabled		
Security: <input type="checkbox"/> Configure <input type="checkbox"/> Calibrate <input type="checkbox"/> Security		
Password: _____		

Factory Default Settings		
Software		Hardware
Analyzer	Type: pH, Glass	Microprocessor/Display PCB SW1 (Hardware Lockout): OFF, Disable Lockout SW2 (Not Used): OFF SW3 (Cold Start): OFF, Disable Cold Start SW4 (Not Used): OFF
Temperature Sensor	Type: 3k, Balco	
Temperature Compensation	Type: Manual	
Linearity Type	Linear	
Sensor Diagnostics	State: Disable	

EC DECLARATION OF CONFORMITY

ABB Inc.
9716 S. Virginia St., Suite E
Reno, Nevada 89511
USA

We declare under our sole responsibility that the product:

TB82PH PROFIBUS PA Transmitter Series

is in conformity with the following standards:

Electromagnetic Conformance - IEC61326-1: 2000

EN55011: 1991 (CISPR11: 1990)	Class A
EN61000-4-2: 1995	4 kV Contact
	6 kV Indirect
EN61000-4-3: 1997	10 V/m
EN61000-4-4: 1995	1 kV
EN61000-4-5: 1995	2kV Line to Earth
	1kV Line to Line
EN61000-4-6: 2001	3V
EN61000-4-8: 1994	30A/m

following the provisions of the EMC Directives 89/336/EEC and 93/68/EEC.

ABB Incorporated
Technical Manager
Stewart Thoeni

Products and customer support

Automation Systems

For the following industries:

- Chemical & Pharmaceutical
- Food & Beverage
- Manufacturing
- Metals and Minerals
- Oil, Gas & Petrochemical
- Pulp and Paper

Drives and Motors

- AC and DC Drives, AC and DC Machines, AC Motors to 1kV
- Drive Systems
- Force Measurement
- Servo Drives

Controllers & Recorders

- Single and Multi-loop Controllers
- Circular Chart and Strip Chart Recorders
- Paperless Recorders
- Process Indicators

Flexible Automation

- Industrial Robots and Robot Systems

Flow Measurement

- Electromagnetic Flowmeters
- Mass Flowmeters
- Turbine Flowmeters
- Wedge Flow Elements

Marine Systems & Turbochargers

- Electrical Systems
- Marine Equipment
- Offshore Retrofit and Refurbishment

Process Analytics

- Process Gas Analysis
- Systems Integration

Transmitters

- Pressure
- Temperature
- Level
- Interface Modules

Valves, Actuators and Positioners

- Control Valves
- Actuators
- Positioners

Water, Gas & Industrial Analytics Instrumentation

- pH, Conductivity and Dissolved Oxygen Transmitters and Sensors
- Ammonia, Nitrate, Phosphate, Silica, Sodium, Chloride, Fluoride, Dissolved Oxygen and Hydrazine Analyzers
- Zirconia Oxygen Analyzers, Katharometers, Hydrogen Purity and Purge-gas Monitors, Thermal Conductivity

Customer support

We provide a comprehensive after sales service via a Worldwide Service Organization. Contact one of the following offices for details on your nearest Service and Repair Centre.

USA

ABB Inc.

Tel: +1 800 HELP 365 (435 7365)

Fax: +1 860 298 7669

UK

ABB Limited

Tel: +44 (0)1453 826661

Fax: +44 (0)1453 829671

China

ABB Engineering (Shanghai) Limited

Tel: +86 (0) 21 6105 6666

Fax: +86 (0) 21 6105 6992

Client Warranty

Prior to installation, the equipment referred to in this manual must be stored in a clean, dry environment, in accordance with the Company's published specification. Periodic checks must be made on the equipment's condition. In the event of a failure under warranty, the following documentation must be provided as substantiation:

- A listing evidencing process operation and alarm logs at time of failure.
- Copies of all storage, installation, operating and maintenance records relating to the alleged faulty unit.

Contact us

ABB Inc.

Process Automation

843 N Jefferson Street
PO Box 831
Lewisburg 24901-9509
USA

Tel: +1 304 647 4358

Fax: +1 304 645 4236

ABB Limited

Process Automation

Oldends Lane
Stonehouse
Gloucestershire GL10 3TA
UK

Tel: +44 1453 826 661

Fax: +44 1453 829 671

ABB Engineering (Shanghai) Ltd.

Process Automation

No5, Lane 369, Chuangye Road
201319, Shanghai
P.R. China

Phone: +86 (0) 21 6105 6666

Fax: +86 (0) 21 6105 6992

www.abb.com

Note

We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail. ABB does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents in whole or in parts – is forbidden without prior written consent of ABB.

Copyright© 2012 ABB

All rights reserved

I-E67-TB82PA-1B



Sales



Service



Software