

- This Version Matrix document helps you to find out what kind of software is available for this field device and which software version you have to use with which kind of Hardware and Firmware Revision.

- You will find the latest software, documentations or this Version Matrix (recommended) available on:

<http://www.abb.com/Fieldbus>

-> select "[Fieldbus protocol] field devices" -> go to [device type name] -> select "latest info"  
Tab "Fieldbus & HART Files" opens

### TB82TC, TB82TC-Combined

#### HART

		Revision	
<b>Hardware</b>  <b>Software</b>  <b>Device</b>		all released	
		≤ D11	E10
	<b>Title (ID-0026)</b> [Doc.-No.]	01	
<b>EDD (General)</b> [3KUS223421S0003] This driver is not needed, if available from your Tool supplier!		01 01(Cond) 01 01(Conc) (Dev./EDD)	01 01 (Cond&Conc) (Dev./EDD)

### TB82TC

#### PROFIBUS PA

		Revision
<b>Hardware</b>  <b>Firmware</b>		all released
	<b>Title (ID-5104)</b> [Doc.-No.]	≤ 01.00
<b>GSD</b> [3KUS223421S0004]		01.00
<b>DTM (FDT 1.2) part of DTM400</b> [3KXD800400S0030]		01.00.02
<b>Supplem. Info.-Driver (DTM)</b> [3KUS223414R39xx]		✓

### TB82TC

#### FOUNDATION Fieldbus-H1

		Revision
<b>Title (ID-0053)</b> [Doc.-No.]	<b>Device</b>	≤ 01.00
<b>EDD/CF (General-registered)</b> [3KUS223421S0007] This driver is not needed, if available from your Tool supplier!		010101